



**NORTEL**

Nortel Communication Server 1000

# SIP DECT Fundamentals

Release: 7.0

Document Revision: 03.01

[www.nortel.com](http://www.nortel.com)

---

NN43120-123

Nortel Communication Server 1000  
Release: 7.0  
Publication: NN43120-123  
Document release date: 4 June 2010

Copyright © 2008-2010 Nortel Networks. All Rights Reserved.

While the information in this document is believed to be accurate and reliable, except as otherwise expressly agreed to in writing NORTEL PROVIDES THIS DOCUMENT "AS IS" WITHOUT WARRANTY OR CONDITION OF ANY KIND, EITHER EXPRESS OR IMPLIED. The information and/or products described in this document are subject to change without notice.

Nortel, Nortel Networks, the Nortel logo, and the Globemark are trademarks of Nortel Networks.

All other trademarks are the property of their respective owners.

---

# Contents

---

<b>New in this release</b>	<b>9</b>
Features	9
Other changes	9
<b>Product overview</b>	<b>11</b>
Navigation	11
Overview of SIP DECT	11
Universal extension support	14
DECT handset features	15
CallPilot and Message Waiting Indication support	16
SIP DECT capacity limitations	17
<b>Site planning and hardware deployment</b>	<b>19</b>
Navigation	19
Components of SIP DECT systems	19
Call server, Signaling server, and SIP Line Gateway	19
PC (DAP controller)	20
DECT Access Points	20
Deployment requirements	21
Navigation	21
Radio synchronization	21
IP network configuration	25
Location requirements	28
DAP power configuration	29
Wire Color Coding for category 5 cables	30
Types of SIP DECT configuration	31
Site planning	35
Site survey	35
Speech quality	36
Coverage calculation	38
Traffic density calculations	41
System deployment	42
DECT Deployment Kit 2	42
Deployment terms	46
Deploying on a single floor	48

- Deploying on multiple floors 63
- Reengineer cells for high traffic areas 67

---

## **Software requirements 83**

- Navigation 83
- Call server and SIP Line Gateway software 83
- DAP controller software 83
  - Firewall protection 84
  - Internet information services 84
  - DHCP and TFTP servers 91
  - DAP Controller 106

---

## **System configuration 111**

- Navigation 111
- Basic (simple) SIP DECT configuration with Communication Server 1000 SIP Line Gateway 111
  - Configuration using IP DECT Configurator 112
  - DAP manager configuration 125
  - SIP Line Gateway configuration 128
  - Configuration of Universal Extension on a Call Server 128 129
- Branch Office configuration 129
- Routed Head Quarter configuration 132
  - Configure Routed Head Quarter 133
- Routed Head Quarter Configuration with Branch Office 135
- Multiple-site mobility network configuration 136
  - SIP DECT Configuration 137
  - Call Server Configuration 137
  - Subscribing DECT handsets and UEXT configuration on the home site 137
  - Importing and exporting subscriptions 138
  - Configuring Universal Extension on remote sites 139
  - MWI for DECT visitors 140
- Operating the MSMN feature 141
- Multiple Gatekeepers Configuration 141
  - Survivable Branch Office Configuration (Communication Server 1000) 141
  - Load Balancing for SIP DECT high capacity 143

---

## **System administration 147**

- Navigation 147
- DAP manager overview 147
- Subscription management 149
  - Subscribing a handset 149
  - Edit a subscription RPN 150
  - Disable a subscription 151
  - Removing a subscription 152

Deleting a number	152
Use the filter	153
Handset status	154
DAP management	156
Changing a DAP Radio Part Number	156
Restarting a DAP	157
Restart all DAPs	157
Deleting a DAP	158
Add a DN range	158
Importing a DN range from a .csv file	159
System backup	160
Subscription export and import	161
Export subscriptions	161
Import subscriptions	164
DAP reboot history	164
System archive	165
Handset firmware update	166
Central directory access tool	170
Supported database types	171
Installation	172
Configure SIP DECT for Central directory access	173

---

## System maintenance

175

Navigation	175
DAP Web interface	175
C4710 DAP LED indications	177
4720 DAP LED indications	177
DAP firmware update	178
Remove and replace a DAP (if a new DAP is available)	180
Remove and replace a DAP (if a new DAP is not available)	181
System synchronization analysis	182
Synchronization Analyzer interface	183
Export and import SIP DECT system	190
Export a system	190
Import a system	191
DAP Controller deactivation	192
Uninstalling DAP Controller software	193
DAP Controller software update	194
Troubleshooting	195
If DAP is not working	195
If you cannot make calls to or from a DECT handset with SIPL configuration	196
If you have problems	197
System survey	198

DAP information file 199  
 System archive 199  
 Network packet capture traces 199

---

## **Appendix 201**

Navigation 201  
 Mount the G.729 daughterboard 201  
 Adjusting the antenna position 203  
 Mounting the 4720 DAP on a wall 205

---

## **Location builder tool 209**

Use the Location builder tool 209  
     Create a location file 211  
     Maintenance 216

---

## **Site survey example 219**

Site planning example: Able-Studio 219  
     The facts for Able-Studio 219  
     The site survey for Able-Studio 219

---

## **Deployment tool 225**

Prepare the tool for deployment 226  
     Charging the deployment tool battery 227  
     Charging the deployment handset battery 228  
     Assembling the deployment tool 229  
     Testing the deployment handset 232  
 How the deployment tool works 233  
 Using the deployment tool 234  
     Handset tones interpretation 235  
     Rules for outdoor deployment 235

---

## **Install the external housing 237**

Installing 4720 DAP with internal antennas 237  
 Installing a DAP/RFP with external antennas 242  
 Installing a C4710 basestation in an external housing 248  
 Installing a C4710E basestation in an external housing with an external antenna 251  
 Mounting the cabinet on a wall 253  
 Mounting the cabinet on a pole 254

---

## **Upgrade a SIPN connection to a SIPL connection 257**

SIPL deployment 258  
 Convert SIPN/SIP3 TNs to SIPL UEXT TNs 259  
 SIP DECT system upgrade 259

---

## **Third Party Software 261**

SRTP 261  
 TLS 262





---

## New in this release

---

The following sections details what is new in *SIP DECT Fundamentals* (NN43120-123).

- [“Features”](#) (page 9)
- [“Other changes”](#) (page 9)

### Features

This document is updated to document SIP DECT on SIP LINE.

### Other changes

This section describes the detailed history of past releases of this document.

#### Revision History

Date	Description
June 2010	Standard 03.01. This document is up-issued to support Communication Server 1000 Release 7.0.
March 2010	Standard 02.02. This document is up-issued with information for SIP DECT on SIP LINE, and to support Communication Server 1000 (CS 1000) Release 6.0.
October 2009	Standard 02.01. This document is up-issued to reflect changes in technical content stemming from SIP DECT 4.2, and to support CS 1000 Release 6.0.
January 2009	Standard 01.07. This document is up-issued for CS 1000 Release 5.5 with editorial changes.
December 2008	Standard 01.06. This document is up-issued for CS 1000 Release 5.5, in response to change requests for content related to SIP DECT 4.1.

Date	Description
July 2008	Standard 01.05. This document is up-issued in response to change requests.
July 2008	Standard 01.04. This document is up-issued in response to change requests.
May 2008	Standard 01.03. This document is up-issued in response to change requests.
March 2008	Standard 01.02. This document is up-issued in response to change requests.
February 2008	Standard 01.01. This is a new document issued to support CS 1000 Release 5.5. Some of the information in this new document was previously contained in the following document: <i>DECT Fundamentals</i> (NN43120-114).

---

# Product overview

---

This section describes the capabilities, configuration, and design of SIP DECT.

## Navigation

- [“Overview of SIP DECT” \(page 11\)](#)

## Overview of SIP DECT

You can use Nortel Session Initiation Protocol (SIP) Digital Enhanced Cordless Telecommunications (DECT) to move without restriction about your work site while conducting telephone conversations, using wireless handsets. The Nortel SIP DECT system includes one or more DECT access points (DAPs or basestations) connected to the TLAN.

The system supports the following connection types for SIP DECT configuration:

- SIPL configuration, which uses SIP Line Gateway

A minimal SIP DECT system has the following main components.

- Call Server
- SIP Line Gateway
- PC with DAP controller software installed
- DAP
- handset

Use the following tools to configure SIP DECT.

- Element manager or overlay program for Call Server
- Element manager for SIP Line Gateway

- IP DECT Configurator—used to enter SIP DECT configuration
- DAP Manager (IP DECT Manager)—a Web interface used for SIP DECT administration tasks such as adding a handset or removing a subscription.

The IP DECT Configurator and the DAP manager IP DECT are available as a part of the DAP controller software package.

The following software releases are required for the main system components:


- Call Server, Release 7.0
- SIP Line Gateway application, Release 7.0
- DAP software 4910b510.dwl or later
- DAP controller 5.0 or later (PC software)

You can connect IP phones to the TLAN, and you can connect TDM phones to the Call Server, Voice Gateway Media Cards, and other required cards in Call Server. Use Voice Gateway Media Cards for IP-to-TDM calls and for conference calls involving IP phones or DECT handsets on basestations. The configuration can also include a PC with DECT Messenger to provide the DECT messaging service on SIP DECT.

Use the Dynamic Host Control Protocol (DHCP) server or the Trivial File Transfer Protocol (TFTP) server unless you use a DAP configuration without DHCP or TFTP. You can configure the system to use two separate servers: one for DHCP and the other for TFTP. If the system requires DAP configuration without DHCP or TFTP, the DHCP or TFTP server is required during installation or configuration changes.

The following figure shows a general SIP DECT configuration.

**Figure 1**  
**SIP DECT configuration**



You can install the DHCP or TFTP services, DECT Messenger, and DAP controller on a single server or PC. However, you can also install them on separate servers to enhance performance or facilitate administration.

You connect the DAP to the Communication Server 1000 (CS 1000) using the SIP Line trunks that you configure for SIP Line Gateway

Each DAP communicates with the subscribed DECT handsets in the coverage area, and each DAP interacts with the CS 1000 and with other configured DAPs in the company network.

You can run SIP DECT on the following configurations:

- Communication Server 1000M or Communication 1000E
- SIP Line Gateway

## Universal extension support

DECT handsets subscribed on DAPs are external to CS 1000. The CS 1000 does not control the state of DECT handsets. Therefore, the CS 1000

- cannot detect individual key presses on DECT handsets
- cannot control cadences on DECT handsets
- cannot control the handset display content

A DECT handset subscribed on a DAP cannot use the same range of features available to analog, digital, or UNiStim IP phones on the CS 1000.

The Universal Extension (UEXT) feature on the Call Server provides Configuration and status information for subscribed DECT handsets.

There is limited support for Associated Telephone (AST) or Computer-Telephone Integration (CTI) capabilities on SIPL for Presence on OCS.

Each DECT handset has a local Directory Number (DN) in CS 1000. Use this local DN to subscribe the corresponding DECT handsets on the SIP DECT system through DAP Manager. DAP manager is available on the server where you installed the DAP controller.

Configure the UEXT associated with a DECT handset as follows:

- For the Primary DN of the UEXT (key 0 SCR), enter the local DN associated with the DECT handset.
- For SIPL configuration for the Target DN of the UEXT (key 1 HOT U), enter the digits of the User agent prefix (SIP Line configuration item) plus the local DN of the handsets.

A UEXT corresponding to a DECT handset on the SIP DECT system reflects the idle or busy status of the associated handset by a check for a call processed between the handset and a DAP.

The Integrated SIP DECT provides the following UEXT features.

- Make and receive simple calls
- Call Hold. Only one active call and one call on hold can exist for a handset
- Consultative or Announced Call Transfer
- Blind Call Transfer
- Conference call participation if another party adds the DECT handset to the conference

- Start a three-way call
- Calling Line ID (CLID) and Calling Party Name Display (CPND) for simple calls not involving call transfer
- CLID and CPND for an internal line (digital or IP phone with display) calling to or receiving a call from a DECT handset
- Sending DTMF tones through the established connection to interact with the called line (party), for example, to work with CallPilot
- Support for a voice mailbox on CallPilot and Message Waiting Indication (MWI)
- Call Forward No Answer
- Call Forward By Time of Day
- Call Forward Busy
- Hunting
- Call Restrictions applicable to a UEXT
- Twinned configuration (typically a desk phone plus a DECT handset)
- Call waiting

### DECT handset features

The user of a DECT handset subscribed on SIP DECT can perform the following actions:

- Make calls to DN's except restricted or blocked DN's.
- Receive and answer calls from the Call Server. If CPND is available, the name of the caller and DN appear on the handset display. The position and appearance of the name DN on the display depend on the firmware installed on the handset. You must configure the required CLS in the UEXT block (CNIA/CNDA/DNDA) and username in LD95. SIP DECT also supports CLID restrictions (for example CLBA, NAMD, DDGD). SIP DECT handsets support display update during established calls; this allows SIP DECT on SIP Line to show a new display name for the connected party. During transfers (both Blind and Consultative) this provides the new party's name on the DECT handset after the transfer is complete. The display name is taken from the CPND block created for SIPL UEXT.

**Note:** During a transfer only the display name updates, not the connected number.

- Place the active call on hold by pressing the R key on the handset. Return to the held call by pressing the R key. If a call is on hold,

another call can be made from the handset. After the second call is established, the user can switch between the two calls with the R key.

- Transfer a call to another DN
  - To perform a Blind Transfer  
Place the current call on hold, call the required DN and immediately release from the call.
  - To perform a Consultative Transfer  
Place the current call on hold, call the required DN, wait for the answer and release the call after the DN answers.
- Press digit keys on the handset during an established call to transmit DTMF tones to the other party on the call.
- Initiate a three-way call. Place an active call on hold, call the third party and wait until the call is answered. Press the star (\*) key to start the conference.
- Receive a second incoming call (call waiting): When a second call is waiting you can see a message "2nd call from <Directory Number>" (the text of the message can be configured) on the screen displays and a beep emits every 3 seconds. The second calling party hears a ring back tone instead of a busy tone.

You can use the "\*" to toggle between calls. When you toggle between calls, the on screen messages changes from <Directory Number> to "Waiting <Directory Number>".

- Observe SIP DECT user status (OCS interaction); if a SIP DECT user has Multiple Appearance Directory Numbers (MADN) then you must configure the SIP DECT handset as an OCS-controlled device (AST 0, CLS t87a). The presence status is updated based on the busy status of either DN.

If a SIP DECT user does not have MADNs, then you must configure the SIP Line UEXT as AST 0, CLS t87a. If a user for the primary DN is configured in OCS, the presence status is updated based on the SIP DECT handset use (busy / available).

- Activate FFC features such as Call Forward, Make Set Busy, Ring Again, Call Park, which are available for SIP Line users from a DECT handset. For more information, see *SIP Line Fundamentals* (NN43001-508)

**Note:** Some of the described features require Call Server configuration.

## CallPilot and Message Waiting Indication support

DECT handsets subscribed on SIP DECT can use CallPilot.

You can configure Call Forward No Answer for the Primary DN of the UEXT so that the unanswered calls on the corresponding DECT handset or IP phone (in the case of a twinned configuration) are forwarded to CallPilot. Calls can also be forwarded to CallPilot as busy treatment for the Primary DN.

A user can call the CallPilot system from a DECT handset and log on to the voice mailbox with the corresponding DN and password. The user can then use the voice menus of the system as usual.

The system can send MWI to the DECT handset through the SIP Trunk; you can enter the MWI primary DN of the SIP DECT user.

CS 1000 supports only the Unsolicited MWI NOTIFY model. An external SIP UA cannot SUBSCRIBE to MWI NOTIFY messages and cannot request the current status of MWI for the DN from the system (by sending SUBSCRIBE messages). Instead, a SIP UA must be ready to receive MWI NOTIFY messages from the system even if it did not SUBSCRIBE, and it must update MWI according to those messages only.

If you use a twinned configuration for a DECT handset, the corresponding IP or TDM phone correctly reflects the current state of MWI, if it receives MWI notifications for the Primary DN from CallPilot.

### **SIP DECT capacity limitations**

The following capacity limitations apply to SIP DECT:

- a maximum of 12 simultaneous calls for each DAP
  - a maximum of 256 DAPs on each network (where handover and synchronization between DAPs is possible)
  - a maximum of 6000 DECT handsets on each SIP DECT system (potentially, several isolated SIP DECT systems can connect to CS 1000)
  - a maximum of 1000 simultaneous calls on each network
  - a maximum of 25 subscription records for each DAP
- If the planned number of DECT handsets in a SIP DECT system is equal to M, and the number of DAPs in that system is equal to N, M must be less than or equal to  $N \times 25$ .

Consider the following additional capacity limitations based on the CS 1000 configuration characteristics.

- The number of available UEXTs is limited by the number of available virtual Telephone Numbers (TN) in the system.
- The number of DNs available for DECT handsets depends on the configured dialing plan and the availability of the Directory Number Expansion (DNXP) package (150).

---

# Site planning and hardware deployment

---

## Navigation

- [“Components of SIP DECT systems” \(page 19\)](#)
- [“Deployment requirements” \(page 21\)](#)
- [“Types of SIP DECT configuration” \(page 31\)](#)
- [“Site planning” \(page 35\)](#)
- [“System deployment” \(page 42\)](#)

## Components of SIP DECT systems

This section contains information about the following topics.

- [“Call server, Signaling server, and SIP Line Gateway” \(page 19\)](#)
- [“PC \(DAP controller\)” \(page 20\)](#)
- [“DECT Access Points” \(page 20\)](#)

### Call server, Signaling server, and SIP Line Gateway

Before you install SIP DECT you must install and configure a CS 1000 system, as follows:

- Install Call Server and SIP Line Gateway.

For more information about SIP Line Gateway, see (NN43001-508).

CS 1000 Release 7.0 introduces the CP PM Co-resident Call Server and Signaling Server (CP PM Co-res CS and SS), which can run the Call Server software, the Signaling Server software, and the System Management software on the same hardware platform operating under the RedHat Linux operating system.

For more information about CS 1000 installation, see *Communication Server 1000E Installation and Commissioning* (NN43041-310).

### PC (DAP controller)

Minimum specifications for the DAP controller PC are as follows.

- 2.4 GHz CPU
- 512 MB RAM
- CD-ROM drive
- 1GB free hard disk space

### DECT Access Points

Four models of DECT Access Points (DAP) are currently available for Nortel SIP DECT: C4710 and C4710E, 4720 and 4720E. The C4710E and 4720E are special versions of C4710 and 4720 Access Points that provide an alternative with an external antenna connection for outdoor use.

- C4710 DAP
- C4710E DAP
- 4720 DAP
- 4720E DAP

#### ATTENTION

The only audio codec supported on the C4710 and C4710E DAPs is the G.711 codec. G.729 codec is supported on the 4720 and 4720E DAPs only in case the G.729 daughterboard is installed. For more information, see ["Mount the G.729 daughterboard"](#) (page 201)

**Note:** If G.729 codec is not supported by your DAPs ensure that the G.711 codec is available in your system. It is not possible to make calls between the Nortel IP Softphone 2050 and DECT handsets when you select the **I use a modem to connect to the network** check box in the Audio settings for the softphone. If you select this setting, the Nortel IP Softphone 2050 uses the G.729 codec for all calls. When using Multimedia PC Client, ensure that you select **Medium Speed** or **High Speed** in the Multimedia PC Client Connection preferences if you plan to make calls between DECT handsets and Multimedia PC Clients.

The DAPs are equipped for EMEA, Latin America and North America. However, the DAP Controller determines the frequency used and the power level. There are three types of DAP Controllers available for the DAPs:

1. DAP Controller – International This version is used in EMEA countries and countries that use the European frequencies and power levels.
2. DAP Controller - North America This version is used in North America.

3. DAP Controller - Selective Countries This version is used in countries with other frequency ranges than EMEA or North America.

**Note:** In North America, only the DAP Controller - North America will be delivered, so no other frequencies than the North America frequencies and power levels are possible in North America. In Europe, only the DAP Controller - International will be delivered, so no other frequencies than the European frequencies and power levels are possible in Europe.

Ensure that the DAPs are installed according to the location recommendations. For more information, see [“Deployment requirements” \(page 21\)](#).

## Deployment requirements

This section describes SIP DECT deployment requirements.

### Navigation

- [“Radio synchronization” \(page 21\)](#)
- [“IP network configuration” \(page 25\)](#)
- [“Location requirements” \(page 28\)](#)

### Radio synchronization

The radio network structure supports seamless handover of existing calls. This means that, during a call, if a handset moves from the coverage area of one DAP into the coverage area of another DAP, the new DAP can take over the call. The call is not interrupted, and the user is not aware of the handover. In the traditional DECT system, synchronization between DAPs occurs over the wired network. SIP DECT requires an accurate synchronization of the radio signals in the air to support handover.


#### ATTENTION

If a DAP cannot receive synchronization signals from at least one other DAP, it operates in a single cell mode and cannot handover to other DAPs or receive handover from them.

Represent each DAP cell as a circle indicating the radio signals around the DAP. [Figure 2 “DAP radio signal synchronization” \(page 22\)](#) shows two circles around the DAP.

- an inner circle in which sufficient radio signal strength exists for acceptable voice quality
- an outer circle in which sufficient signal strength exists for synchronization, but not enough for acceptable voice quality

**Figure 2**  
**DAP radio signal synchronization**



Due to the cellular structure of a DECT radio network, overlap exists in the cells with sufficient voice quality. The wider cell limit around the DAP therefore has some overlap with the other cell and reaches to the radio of the other cell. Consequently, the DAPs of the overlapping cells exchange radio signals. These radio signals are weak relative the signal needed by the handsets, but are strong enough for synchronization.

**ATTENTION**

For signal strength calculation see [“Signal strength and frame errors” \(page 24\)](#).

If one DAP receives a signal from another, the receiving DAP checks the radio signals on Primary Access Right Identity (PARI), to ensure that the signals belong to the same DECT system. If the signals belong to the same DECT system, the DAPs synchronize according to user-configured rules.

**ATTENTION**

If two or more independent SIP DECT systems have overlapping coverage areas, configure these systems so each has a unique subset or portion of carriers. When each system has a unique subset of carriers, interference between the systems is reduced.

Reducing the number of available carriers reduces the maximum number of simultaneous calls in the DECT system. To achieve your desired call capacity, you can be required to install extra DAPs. For more information, see step 4 of [Procedure 49 "Configuring DECT Settings" \(page 119\)](#).


The DAPs transmit with a minimum of two channels carrying primary voice and data, also named bearers. If no voice calls occur over a DAP, the DAP transmits two dummy bearers. If one or more voice calls occur on the DAP, one is one a dummy bearer, while the others are voice calls.

**Synchronization hierarchy**

If two or more DAPs belong to the same system, the DAPs automatically synchronize using a hierarchical structure. In most cases synchronization is automatic, but if your system has a complex DAP cell structure, you must manually configure synchronization.

The DAP controller tracks the synchronization structure and assigns each DAP a unique Radio Part Number (RPN) after the DAP starts the first time. One or more DAPs act as a synchronization source to form the root of the hierarchical structure, as illustrated in [Figure 3 "DAP synchronization hierarchy" \(page 23\)](#).

**Figure 3**  
**DAP synchronization hierarchy**



If more than one synchronization source is present, each one forms a separate hierarchy of DAPs called a synchronization island.

Automatic synchronization occurs within each synchronization island using the following rules.

- After a DAP starts, it searches for existing DAPs. If it finds one with a lower RPN, it synchronizes with it. If no other DAP exists with a lower RPN, the new DAP becomes the synchronization source.

**ATTENTION**

Extra DAPs can be required to establish a synchronization path.

- If a DAP detects more than one other DAP, it synchronizes with the DAP with the shortest path to the synchronization master. If two or more DAPs have the same path length separating them from the master, the new DAP synchronizes to the DAP with the lowest RPN.

**ATTENTION**

After you install SIP DECT, wait at least 15 minutes until you see the results of the automatic synchronization.

To make a DAP a synchronization master or to give a DAP a higher position in the synchronization structure, you can manually assign a lower RPN number to a DAP. You can manually assign RPNs using the DAP Manager Web interface. Automatically assigned RPNs start at 010. If you manually assign a new RPN, ensure that it is in the range 000 to 00F.

**ATTENTION**

You must determine the position of the Synchronization Master before you start site planning. Place the synchronization master, which is the DAP with the lowest RPN, in the middle of your site, building, or buildings.


### Signal strength and frame errors

Signal strength is important for DAP-handset communication (voice quality) and synchronization between DAPs. The following items are relevant for the signal strength for synchronization.

- To achieve a good voice quality, the minimum signal strength at the receiver in the handset and DAP must be -72 Decibels (referenced to milliwatts) (dBm). This includes a margin of -10 dBm for fast fading dips.
- Synchronization is possible if the strength of the received signal from another DAP is -80 dBm to -85 dBm. This is adjustable.
- In an open area, the distance is doubled if the received signal strength is 6 dB lower. This means that at a minimum signal strength for good voice quality of -72 dBm and a distance X, the signal strength at the

double distance, 2X, is -78 dBm. For more information, see [Figure 4 "Signal strength considerations" \(page 25\)](#).

**Figure 4**  
**Signal strength considerations**



- An open area has more than sufficient signal strength for synchronization. The expected level at the double distance is -78 dBm. The required level is -80 dBm to -85 dBm. This leaves a safely margin of 2 to 7 dB.
- Obstructions between the DAPs can introduce loss. Also, many objects cause reflections that let the signal reach the DAPs through other path with sufficient signal strength.
- In rare cases, factors in the surrounding environment can cause the error rate in the received frames to be temporarily much higher than is normal for speech. An occasionally elevated error rate does not indicate a problem with your SIP DECT system. However, if you consistently see a high error rate, then there is a problem with the deployment of your SIP DECT system.

### Frame errors

Frame errors rarely can occur in DECT. The number of frame errors for each reading may not be more than four. The most common cause of frame errors higher than four is a high number of reflections. This causes an audible click during calls.

### IP network configuration

The IP network must be able to support SIP DECT; this section provides information about planning an IP network that is suitable for supporting SIP DECT.

SIP DECT typically uses existing IP network infrastructure and facilities for the network connection. For IP connectivity, you must configure the network to ensure that all SIP DECT components have the following characteristics:

- are equipped with unique IP addresses (some static, some dynamic)
- can reach all the required services
- can be reached by all clients and counterparts

### Ethernet requirements

The following items describe the Ethernet requirements.

- The IP network must offer a Quality of Service (QoS) that is sufficient to support the SIP DECT Voice over IP.
- The IP network must support transparent IP multicast between all DAPs and the DAP controller.
- Connect only one DAP to one IP Switch port.
- DAP supports full duplex and supports autonegotiation if DAP is connected to a port on an Ethernet Switch.

#### ATTENTION

Configure the Ethernet switch ports to which the DAPs are connected to use autonegotiation. If the switch does not support autonegotiation, you can use full-duplex; however SIP DECT can operate incorrectly on some switches when you configure them to use full-duplex.

- Ensure that enough unique IP addresses are available to support both data networking traffic and SIP DECT components. You can configure private IP addresses for local traffic, and you can configure private IP addresses on the local network to connect to public IP addresses if you use Network Address Translation (NAT). However, SIP DECT does not support NAT.
- Ensure that IP addresses and routing are consistent with each other to deliver the required transparency. Also ensure that IP addresses are consistent with routing for normal unicast traffic as well as for the required multicast traffic.
- The maximum cable length between the DAP and IP network equipment, such as a switch, is 100 meters for a Category 5, unshielded twisted-pair, half-duplex cable. If the required cable length between the IP network equipment and the DAP exceeds 100 meters, use Long Range Ethernet equipment in the connection. Several manufacturers offer such a solution, which allows cable lengths of more than one kilometer (km).

**Fixed IP network addresses**

You must provision fixed IP addresses for the following servers:

- The TFTP server stores the configuration file and the firmware that are available to the DAPs. After a DAP starts up, the DHCP server sends the DAP the IP address of the TFTP server. The DAP then downloads the configuration files from the TFTP server. The TFTP server often runs on the DAP controller or manager PC.
- The DHCP server (optional) sends the address of the DNS server to the DAP. The DAP does not support Domain Name Resolution.
- The DAP controller or manager requires a fixed IP address. The DAPs retrieve this fixed IP address from the configuration file that the DAP loads from the TFTP server.
- The IP address of the PABX is reachable either through a router or directly.  
The PABX is sometimes referred to as Gatekeeper or SIP proxy, depending on the type of PABX that is used.

To facilitate network management, Nortel recommends that fixed IP addresses are also assigned by the DHCP server. Ensure that the DHCP server has the hardware MAC addresses of all servers to issue the proper (fixed) IP addresses to each individual server.

The DAP IP address can be stored in flash memory. If the IP address is stored, the DHCP server is needed only for the first startup. Then an IP address is assigned to the DAP.

**Dynamic IP network addresses**

Network stations, which are not servers (PC workstations and DAPs), can use dynamic IP addresses assigned by DHCP. For dynamic IP addresses, you need not specify the MAC addresses of all the network stations in the DHCP server.

Ensure that you configure the DHCP server to assign IP addresses from a specific range to unknown MAC addresses. However, unknown LAN stations have valid IP addresses, which can be a minor network security issue. To solve this, use the Vendor Class Identification (VCI) in the DHCP server. The DHCP server issues IP addresses only to devices that have the DAP VCI. Ensure that the DHCP server can make a distinction in VCIs. The DAP VCI is D(ECT)AP 49.

Each DAP in a SIP DECT system is assigned a dynamic IP addresses by the DHCP server. You can configure the DAPs to store the IP address in flash memory, so the DHCP server is required only during the initial configuration of the system.

### **Multicast addresses**

SIP DECT uses Multicast addresses for the following functions:

- Communication between the SIP DECT network components to locate or address a handset.  
If a handset must be reached, the request must simultaneously go to all DAPs. For example, if you use the page function during an incoming call, a single multicast message is sent to all DAPs to find the DAP for your handset quickly and efficiently.
- Seamless handover from one DAP to the other  
If inter-cell handover is necessary, the media path must be redirected from the existing DAP to another DAP. The handset always initiates a handover. The handset sends request to another DAP (not the DAP with the current connection). This DAP issues a multicast on the network to determine on which DAP the voice connection exists. The DAP, with the existing voice connection, responds and then the connection can be redirected from the DAP with the existing voice connection to the new DAP.
- Synchronization between DAPs  
You must configure multicast before synchronization can occur between DAPs in the SIP DECT system.

All network components must support forwarding of IP multicast packages. The IP DECT Configurator proposes a default multicast IP address (239.192.49.49). This is a multicast address in the private multicast IP address range for use in private IP networks. If you are not sure you can access this address, contact the local IT manager.

#### **ATTENTION**

You must disable IGMP Snooping and Spanning Tree Protocol on switch ports where SIP DECT equipment is connected.

### **Location requirements**

Comply with the following requirements for DAP location:

- Ensure that the location complies with local electrical codes.
- Install DAPs indoors where no condensation occurs and the temperature remains within the range of 0°C to 40°C. (of -20C to +40C for external housing).
- Install the C4710 and C4710E DAPs in a vertical position. The radiation pattern differs between the horizontal and vertical positions. The 4720 and 4720E can be installed horizontally only if you change the antenna position. For more information, see [“Adjusting the antenna position” \(page 203\)](#)
- Do not mount a DAP to a metal surface.

- Do not roll up the extra cabling behind a DAP.
- Position DAPs upright on walls. DAPs must be at least 30 cm from the ceiling.
- Position DAPs at least 1 meter (m) from large concrete or stone columns and from major building structural members such as support beams or columns.
- Position the DAPs high enough to clear obstructions between the DAPs and the cell edge close to the ceiling.
- Mount the DAPs clear of obstacles such as pipes or ducts.

For more information about the 4720 DAP mounting procedure, see [“Mounting the 4720 DAP on a wall” \(page 205\)](#)

To install the DAPs outdoors, see [“Install the external housing” \(page 237\)](#).

### DAP power configuration

The C4710 and C4710E DAPs are powered using one of the following methods:

- Locally, using an RJ-11 connector. The AC voltage must be 40V (+ or --10 percent). Use an AC adaptor that provides at least 10 Watts. For part numbers of available AC adaptors, see [Table 1 “Part numbers” \(page 29\)](#).

**Table 1**  
**Part numbers**

NTCW28AAE5	N0162030	DAP AC/AC adaptor Eur
NTCW28BAE5	N0162032	DAP AC/AC adaptor UK
NTCW28CAE5	N0162033	DAP AC/AC adaptor ANZ

- Through Power over Ethernet (PoE), as defined by IEEE802.3af specifications. The DAPs support both phantom power and power over spare wires. The following specifications apply to PoE power.
  - Minimum 36 Volts and maximum 60 Volts of voltage at the DAP
  - Standard RJ-45 connector, using the spare wires pins (wires)
  - Maximum cable length of 100 meters

Both phantom power and power over spare wires are provisioned on the same DAP to provide system redundancy. The power input providing the highest voltage is active. If one power input fails, the other takes over without service interruption.

The 4720 and 4720E DAPs are powered only through Power over Ethernet (PoE) with the following specifications:

- Voltage at C4720(E) via PoE : 36 . . . . 57 V. DC
- PoE Class ..... : Class 2
- Power Consumption ..... : 6 Watt maximum

### Wire Color Coding for category 5 cables


This section shows you the normal color coding for category 5 cables (4 pair) based on the two standards supported by TIA/EIA: the 568A and 568B standard. These standards apply to the color code used with a single cable run.

#### ATTENTION

Both cable ends must use the same standard!

Which standard to use, is a matter of local decision. However, since they both use the same pin out at the connectors you can mix 568A and 568B cables in any installation.

**Figure 5**  
**Color Schemes for Wires in Category 5 Ethernet Cabling**



## Types of SIP DECT configuration


You can implement SIP DECT in various system configurations to accommodate your needs. The most common SIP DECT configurations are as follows:

- Basic (or Simple) Configuration
- Routed Head Quarter Configuration
- Branch Office Configuration
- Routed Head Quarter Configuration with Branch Office
- Multi Site Mobility Network Configuration

- **Basic (or Simple) Configuration**

In Basic Configuration all DAPs are in the same subnet that is based on one or more IP switches. IP multicast must be able to occur between all DAPs. The configuration supports seamless handover between all DAPs. For an illustration of a simple SIP DECT configuration, see [Figure 6 "Simple SIP DECT network configuration" \(page 31\)](#).

**Figure 6**  
**Simple SIP DECT network configuration**




- **Routed Head Quarter configuration**

Routed Head Quarter Configuration is used for a Large Campus network that is split into several subnets. In this configuration DAPs belong to various subnets and behave as one large SIP DECT system with the full support of seamless handover. IP multicast must be able to occur between all DAPs in the Campus network, through IP switches and the IP routers that connect the various subnets. For an illustration

of a Routed Head Quarter configuration, see [Figure 7 "SIP DECT configuration Routed Head Quarter"](#) (page 32).

**Figure 7**  
**SIP DECT configuration Routed Head Quarter**




In Routed Head Quarter Configuration network settings must comply with the following requirements:

- The network must support Quality of Service (QoS) and IP connectivity throughout the Campus.
- Routers must support IP multicast routing.
- The IP multicast address for SIP DECT must be the same in all subnets.
- Multicast Time to live (TTL) must be greater than 1.
- In the SIP DECT configuration, you must use an “aggregated” subnet mask that covers all the subnets where DAPs are present. For instance, if each subnet is defined by mask 255.255.255.0, then “aggregated” mask 255.255.248.0 covers up to four such subnets.

- **Branch Office Configuration**

Branch Office Configuration is used for a Large Campus network that is split into various (geographical) segments (branch offices). IP multicast must be able to occur between all DAPs in every branch office and no IP multicast is allowed between any two branch offices. In this configuration, each branch office behaves as an isolated site of a large SIP DECT system. Branch Office configuration supports seamless handover within each isolated site (branch office), but not between sites. Support is unavailable for roaming between branch offices. For an illustration of a Branch Office Configuration, see [Figure 8 "Branch Office Configuration" \(page 33\)](#).

**Figure 8**  
**Branch Office Configuration**



For Branch Office Configuration, network settings must comply with the following requirements:


- The network between Branch Offices and Call Server must support QoS.
- Branch Offices must be in separate subnets (IP router(s) needed).
- DAPs in various Branch Offices must be located so that no synchronization can occur between any two DAPs belonging to various Branch Offices.
- Routers must block IP multicast between Branch Offices (multicast TTL = 1, which means that IP multicast packets do not cross IP routers).

- **Routed Head Quarter Configuration with Branch Office**

Routed Head Quarter Configuration with Branch Office makes it possible to create a Routed Head Quarter Configuration in one (and only one) the branch office. Within the Branch Office with Routed Head Quarter, DAPs belong to various subnets and behave as a single site of one SIP DECT system with the full support of seamless handover. As for the whole SIP DECT system, each Branch Office (including the Branch Office with Routed Head Quarter) behaves as isolated site of that SIP DECT system. Branch Office configuration supports seamless handover within each isolated site (branch office), but not between sites. Support is unavailable for roaming between branch offices.

**Figure 9**

**Routed Head Quarter Configuration with Branch Office**



In Routed Head Quarter Configuration with Branch Office the network settings must comply with the requirements for Routed Head Quarter configuration (for the network settings within Routed Head Quarter) and with the requirements for Branch Office configurations (for the network settings between Branch Offices, including the Branch Office with Routed Head Quarter).

- **Multi Site Mobility Network Configuration**

Multi Site Mobility Network (MSMN) Configuration makes it possible to use portable DECT handsets on various MCDN nodes where each node is a CS 1000 system plus the corresponding SIP DECT system. MSMN allows roaming between independent SIP DECT systems installed on separate Call Servers (connected by trunks). Handover between independent SIP DECT systems is not possible.

A SIP DECT system on an individual MCDN node can be any of the previously described configurations: Basic (Simple), Routed Head Quarter, Branch Office, or Routed Head Quarter with Branch Office.

MSMN requires unrestricted MSMN package 370 and a number of free wireless visitors licenses, which are regulated by ISM mechanism. If there are only restricted MSMN packages or if there are no wireless visitors licenses the following occurs:

- A new UEXT SIPL visitor client cannot be created (the VSIT and HMDN prompts are not shown).
- A non-visitor UEXT cannot be changed to UEXT SIPL visitor (the VSIT and HMDN prompts are not shown).
- All visitor UEXT SIPL clients above the maximum licenses number are deleted on sysload.
- All visitor UEXT SIPL clients are deleted on sysload if the MSMN package is restricted.
- Overlay 20 does not print the VSIT and HMDN lines in reports.
- – The visitor UEXT SIPL client cannot move to the new location where the package and license limits exist (Set Relocation feature).

## Site planning

Site planning is an information gathering process that begins with a site survey and ends with deploying SIP DECT. The information received in the site survey determines customer requirements and the number of cells required to support traffic.

You can use the Location builder tool (a part of the DAP controller software package) to plan your site. For more information, see [“Location builder tool” \(page 209\)](#).

### Site survey

- Site maps

Site maps are an essential requirement in advance of a survey. A map of the complete site (if more than one building) and plans of each floor of each building are required. Make sure that dimensions are clearly stated on the maps. Additional information such as the use of buildings (office, hotel, factory, store), construction materials (walls, floors, ceilings), and cabling infrastructure are helpful in estimating DAP positions in advance.

- Number of users (handsets)


Number of users (handsets), both initial and foreseeable growth, and areas of above average and below average traffic density.

- Allowed and prohibited DAP positions  
A customer can prohibit the installation of DAPs in certain areas, or require that DAPs be installed out of sight.
- Details of required coverage  
Determine to what areas coverage must extend; for example: elevators, stairwells, toilets, outdoor areas.
- Position of the DECT System and available cabling  
Ensure that you can use existing cabling for the connection between the DECT System, and that the DAP cables meet or exceed the UTP Cat 5 standard. If the type and quality of the available cabling is not sufficient for the connection and limits the maximum distance between the DAP and DECT System, you may require new cabling.
- Sensitive electronic equipment  
Check whether sensitive electronic equipment is present, for example, laboratory or medical equipment. Although the transmitted power of the DAPs is low (about 250 mW), it can interfere with some sensitive electronic equipment.
- Traffic information  
Gather information about user density, amount of traffic, and whether redundancy is required. You require this information to determine the number of DAPs that are required and therefore the required cabling.  
  
A DAP must always have at least one channel free to allow handover (either intracell or intercell handover). Make sure that the maximum expected traffic density is not more than 11 channels simultaneously.  
  
For more information, see [“Site survey example” \(page 219\)](#).

### Speech quality

A relationship always exists between coverage and speech quality. The greater the distance between the handset and the DAP, the lower the quality. Therefore, you must understand the relationship between the coverage and the expected voice quality. For an illustration of the relationship between coverage and voice quality in an open environment, see [Figure 10 "Coverage and speech quality in an open environment." \(page 37\)](#).

**Figure 10**  
**Coverage and speech quality in an open environment.**



Be aware that DECT is a digital communication system. It incorporates a “transmission errors hiding” system. This means that it tries to hide the transmission errors. The results of this mechanism are as follows:

- A small incidental transmission error is not noticeable in speech.
- A minor transmission error causes audible clicks during speech.
- A major transmission error causes the loss of speech.

The following factors effects the voice quality as well:

- Moving speed

The DECT techniques allow a maximum moving speed of 5 kilometers per hour (km/h). Bear this in mind if your DECT system must cover an elevator.

- Metal Construction

In metal structures, reflection can negatively impact voice quality (clicks and interruptions can occur) even if you are close to the DAP. This effect is made worse when the handset is in motion.

For more information see [“Coverage calculation” \(page 38\)](#).

The required quality depends on the customer requirements and the environment. The following are the various quality levels:

- Excellent and good

In business, office, and first aid environments, the excellent and good voice quality is required to avoid dropped calls, inherent sounds, or pauses in important conversations. Any sounds produced by a lower quality level noticed by the system users, because these environments are usually quiet or produce less background noise.

- **Satisfactory**

In less critical areas like basements, stock rooms, and cold stores, the satisfactory quality level is usually accepted because they are noisy environments. In a noisy environment people do not notice an audible click in a conversation, because the environment produces a lot of background noise. This environmental background noise may also contain audible clicks. Sometimes, the voice of a user is less audible to the other user listening at the other end of the conversation because of the background noise.

Use the following points as general guidelines:

- A maximum of 20 percent of the whole coverage is considered as satisfactory.
- Install a hard-wired emergency telephone in those areas where the quality is satisfactory. This ensures that people can always make a call in case of an emergency.
- If you agree with the customer on lower speech quality, then make sure that this is well documented and signed by the customer. If the customer becomes dissatisfied afterwards, you can refer to the agreement. Also, be aware that, if the speech quality is low in certain areas, the customer may perceive that you delivered a low-quality system.
- If a lower voice quality level is acceptable, ensure that all calls are received and dropped calls are avoided.

### **Coverage calculation**

The coverage can be calculated in advance, before executing a site survey. Calculation is based on the following theory.

The transmission path between the DAP and the handset is subject to radio-propagation related peculiarities, such as:

- Dynamically changing environment
- Signal attenuation due to fixed and moving objects
- Multi-path propagation of the signal

The signal from the transmitter is attenuated in the link before it arrives at the receiver. The link consists of a transmission path through the air and through obstacles such as walls. The air and the obstacles cause attenuation called insertion loss. The following table shows typical insertion losses for some obstacles.

**Table 2**  
**Typical insertion losses of some obstacles**


Material	Insertion loss (dB)
Glass	2
Glass, metal reinforced grid	10
Glass, metal clad sunguard	10
Wall, indoor, plaster, wood	2
Wall, brick, 10 cm	3.5
Wall concrete, 10 cm	6
Wall concrete, 15 cm	9
Wall concrete, 20 cm, large windows	6
Wall concrete, 40 cm	17
Ceiling, concrete, reinforced, tiles	17-20

With the DECT equipment, the available link budget is 38 dB. This is the maximum allowed loss in the link, under constraints of excellent and good speech quality and the ability for the user to move.

To calculate the distance between DAP and handset, use the information in [Figure 11 "DECT range calculation chart" \(page 40\)](#).

Using the building map, start at the possible DAP location. Move away from the DAP location. Calculate the distance. When you encounter an obstacle, calculate the insertion loss. Using the chart below, start in the lower left corner (0,0), move horizontally, to the value for the actual distance. Move vertically to the value for the insertion loss of the encountered obstacle. If the curve in the chart is crossed, read the maximum distance for that specific DAP in that situation. This gives the cell size in that specific direction. Ensure that outside the calculated range communication is possible but a good voice quality is no longer guaranteed.

**Figure 11**  
**DECT range calculation chart**



The range in the air is 80 m from the DAP, for optimal communication quality. The result of this coverage calculation is a map with possible DAP positions indicated.

Use the following DAP ranges as a rough guide for planning the DAP positions:

- In the line of sights the DAP has a range of approximately 80 m.
- In halls the DAP has a range less than 80 m.
- In buildings the DAP has a range of 15 to 40 m. This is based on the assumption that walls are made of light brick, plasterboard or wallboard with metal frames. Normal electrical wiring, central heating pipes, office furniture and desktop computer equipment have no significant effect. Ensure that you consider the signal shadowing effect of stairways, lift shafts, and shielded rooms.

The following items cause shadowing of the radio signal:

- Thick walls, especially cavity walls and reinforced concrete walls.
- Windows or glass in doors with steel wire reinforcement or metallic reflection film.
- Steel doors, partitions, or walls.
- Fire resistant doors.
- A wall of steel cabinets, large computer equipment or machinery.
- Thick concrete floors.

During the site survey, be aware of the following:

- Choose a corridor or other large open space rather than an enclosed area so that the radio signal passes through as few walls as possible to reach as large an area as possible.
- Radio reception inside a vehicle is poor unless the user is close to the DAP.
- Ensure that the DAP is placed high enough to be unaffected by surrounding objects. For example, a DAP in a car park needs to be placed higher than a vehicle that is parked next to it.
- Ensure that DAPs are separated by at least 1 meter.
- The presence of another unsynchronised DECT System, or any similar system in adjacent buildings, causes interference.
- A DAP or a handset interferes with sensitive laboratory equipment and medical equipment (for example, ensure that DAPs are installed outside of an operating room at an hospital.)
- Ensure that significant interference from unsuppressed engines or electric motors is accounted for.

### **Traffic density calculations**

Perform the traffic density calculations so that you have a low blocking probability in the system.

For traffic calculations, you must know

- the number of users
- the type of users

The following table lists the three user types.

**Table 3**  
**Three user types**

Traffic	Application	Erlang/User
Low	normal offices	0.05
Average	Executive and secretary groups	0.1-0.15
High	help desks, Tele-services	0.2-0.25

The Erlang value for DAP C4710(E) and C4720(E) (12 radio channels), with blocking probability of 0.5%, is 5.25.

Calculate the traffic density using the following formula:

$$\text{Nbr of DAPs} = \frac{(\text{nbr of users}) \times \text{Erlang/user}}{\text{Max. load per DAP}}$$

One cell has 20 users: five average traffic and 15 low traffic. The load is:  
 $(5 \times 0.15) + (15 \times 0.05) = 1.5$  Erlang

Therefore, one 12 channel DAP is sufficient for this cell.

## System deployment

This section describes the basics of SIP DECT system deployment.

### DECT Deployment Kit 2

The DECT Deployment Tool (deployment tool) determines cell centers and cell boundaries.

The DECT Deployment Kit 2 is shown in [Figure 12 "Deployment Kit 2 and carrying case" \(page 43\)](#). For more information about the deployment kit, see the DeTeWe User Manual that accompanies each kit.

#### **ATTENTION**

If you use an older deployment tool that differs from the one in the following figure, see ["Deployment tool" \(page 225\)](#).

**Figure 12**  
**Deployment Kit 2 and carrying case**



The following figures shows the assembled kit.

**Figure 13**  
**Assembled Deployment Kit 2 and DeTeWe handsets**



**Figure 14**  
**Deployment Kit 2 basestation**



Use the following information in conjunction with the DeTeWe User Manual that accompanies the deployment tool.

- The two DeTeWe handsets with the kit are subscribed to the basestation and are numbered 13 and 15. To view the assembled basestation and the DeTeWe handsets, see [Figure 13 "Assembled Deployment Kit 2 and DeTeWe handsets"](#) (page 44).
- The key on the handset is the Off-Hook key.



- To enter Site Survey Mode on the handset, perform the following procedure.

Access site survey mode.

**Procedure 1**  
**Entering the site survey mode**

Step	Action
------	--------

1	Press Menu.
---	-------------

- 2 Scroll down to **System**.
- 3 Dial \*\*\*76#.
- 4 Scroll down to **Site Survey**.
- 5 Press **OK**.
- 6 Use the handset to detect frame errors and signal strength.  

The Frame Error value for the handset is the number of detected Sync/ACRC errors within the last 100 receiving frames, for example, 1 second. For proper deployment, ensure the Frame Error value does not exceed 4. An Radio Signal Strength Indication (RSSI) value of –80 dBm to –85 dBm is used to indicate the cell boundary. For more information, see [“Signal strength and frame errors” \(page 24\)](#).

---

--End--

---

- Subscribe a handset that has de-subscribed in error.

**Procedure 2**  
**Re-subscribing a handset**

Step	Action
1	Long-press the button on the basestation to open the DECT system.
2	On the handset, navigate to <b>Menu &gt; System &gt; Subscription &gt; New</b> .
3	Enter the <b>PARK</b> number provided at the bottom of the basestation.
4	Enter the authorization code (the last four digits of the serial number at the bottom of the basestation).
<hr/> <p style="text-align: center;">--End--</p> <hr/>	

## Deployment terms

The following table lists terms associated with deployment.

**Table 4**  
**Deployment terms**


Term	Definition
Estimated number of handsets	The average number of handsets expected in a particular cell.

**Table 4**  
**Deployment terms (cont'd.)**

Term	Definition
Cell	The coverage area provided by a basestation.
Cell boundary	The edge of a cell showing the cell coverage area.
Cell center	The place where all the basestations are installed.
DECT Radio Deployment Tool	The tool used to determine the radio range of a basestation.
Critical point	A point or location defined as an outer corner of a coverage area, or points that can be difficult for the radio signal to reach.
Coverage area	The area defined by the customer in which a handset user can expect to be able to make and receive calls.
Link	If a handset and a basestation are in radio communication with each other.
Range	The distance from a cell center to the cell boundary.
Office	The location where a handset user spends the majority of the day.
Traffic table	Traffic tables record site traffic information from the floor plan and the customer. The traffic table helps to determine the required number of basestations for each cell.

The following figure illustrates some of the preceding terms.

**Figure 15**  
**Example showing deployment terms**



## Deploying on a single floor

Use the information in this section when you are installing SIP DECT on a single floor.


Identify critical points when installing on a single floor.

### Procedure 3

#### Identifying critical points on the floor

Step	Action
1	<p>Mark critical points.</p> <p>A critical point is a place that can be difficult for the radio signal to reach, such as a corner of a room, lifts, and stairwells. Initial critical points are shown in <a href="#">Figure 16 "Example of initial critical points" (page 48)</a> as: P1, P2, P3, P5, P6 and P7.</p>
--End--	

**Figure 16**  
Example of initial critical points



A specific RSSI value on the handset defines the cell boundary range. Links can be made outside the cell boundary but the audio quality of the link is poor. The link drops if the handset and the basestation are too far apart.


As shown in [Figure 17 "Cell boundary terminology" \(page 49\)](#), the cell boundary is the farthest point from the cell center where a clear radio signal can be heard.

Determine the range from the cell center to the cell boundary, or the distance to a potential cell center from a critical point, by using the cell boundary value and the deployment tool.

### ATTENTION

Close all doors, and hold the survey handset about 1.2 m above the ground.

**Figure 17**  
**Cell boundary terminology**



Determine a cell boundary for the cell center by placing the deployment tool at the cell center and using the deployment handset to establish the cell boundary.

Mark the cell contour based on the most distant point.

### Procedure 4

**Demarcating the cell contour for the critical point farthest from the center of the full coverage area**

Step	Action
1	Set up the deployment tool basestation. Raise the deployment tool basestation as high as possible, or until it is at the height recommended for basestations.


- 2 Enter the site survey mode on the handset.  
For more information, see [Procedure 1 "Entering the site survey mode" \(page 45\)](#) if you use Deployment Kit 2, or [Procedure 107 "Entering the monitor mode" \(page 232\)](#) if you use an older Deployment tool.
  - 3 Measure the range into the coverage area in a few directions to determine where a cell center can be located and still be within range of the critical point.  
  
Listen to the deployment tool handset while moving away from the basestation. After the RSSI value changes from 7 to 6 ( $-80\text{dBm}$  to  $-85\text{dBm}$ ), the cell boundary is detected.  
  
For more information about deployment requirements, see ["Radio synchronization" \(page 21\)](#).
  - 4 Mark the cell boundary on the floor plan with a small x.
  - 5 Repeat step 3 and step 4 until you have sufficient Xs to draw a thin contour arc through the Xs.
- In [Figure 18 "Cell contour of the initial critical point" \(page 50\)](#), P1 is the initial critical point.

---

--End--

---

**Figure 18**  
**Cell contour of the initial critical point**



**Procedure 5**


**Demarcating the cell contour of the closest adjacent critical point to the first critical point.**

Step	Action
1	Repeat the described steps in <a href="#">Procedure 4 "Demarcating the cell contour for the critical point farthest from the center of the full coverage area"</a> (page 49) to mark the cell contour of the closest adjacent critical point to the first critical point.  In <a href="#">Figure 19 "Cell contour of the closest adjacent critical point to the initial critical point"</a> (page 51), P2 is the closest adjacent critical point to the first critical point.

--End--


**Figure 19**

**Cell contour of the closest adjacent critical point to the initial critical point**



Locate the cell center.

### Procedure 6 Locating the cell center

Step	Action
1	Place the deployment tool at one critical point and then use the deployment handset to obtain a change in audio quality. The audio quality change determines the cell boundary contour.
2	Repeat step 1 at an adjacent critical point. The call center is where the cell boundaries of both critical points meet. Mark the cell center position on a floor plan.
3	<p>Use the cell contours to locate a cell center.</p> <p>Locate the cell center where the cell contours meet. Choose a position on the floor plan that meets the following requirements:</p> <ul style="list-style-type: none"><li>• is farthest from the critical points</li><li>• provides good audio quality at the critical point,</li><li>• complies with the requirements described in section <a href="#">"Deployment requirements" (page 21)</a></li><li>• is in the coverage area</li></ul> <p>Label the cell center on the floor plan with the following symbol. xCn, where x = the floor and n = is the cell number in sequence of the entire plan.</p> <div></div>


In [Figure 20 "Example of a cell center" \(page 53\)](#), IC1 is a cell center.

---

--End--

---

**Figure 20**  
Example of a cell center



Mark the cell boundary.

#### **Procedure 7** **Demarcating a cell boundary**


Step	Action
1	Set up the deployment tool basestation at the cell center.
2	Enter the site survey mode on the handset. For more information, see <a href="#">Procedure 1 "Entering the site survey mode" (page 45)</a> if you use Deployment Kit 2, or <a href="#">Procedure 107 "Entering the monitor mode" (page 232)</a> if you use an older Deployment tool.
3	See the floor plan and check audio quality in user offices within the cell. If a user office is in a zone where audio quality deteriorates, relocate the cell center closer to the critical point or the office.
4	Walk into all the areas (rooms) necessary to mark the complete cell boundary. Radio signals travel further in uncluttered areas than in cluttered areas. Record the cell boundary.
5	Find the cell boundary by measuring the range and marking it on the floor plan with a small x. Repeat steps <a href="#">Step 3</a> and <a href="#">Step</a>

4 until there you have sufficient Xs so you can draw a contour arc around the cell center.

For an example of a cell boundary, see [Figure 21 "Example of a cell center boundary"](#) (page 54).


--End--

**Figure 21**  
**Example of a cell center boundary**



Mark and label the cell boundary.

**Procedure 8**  
**Marking and labeling the cell boundary on the floor plan**

Step	Action
1	Mark each office within the cell that is isolated from the office area.
2	Label subsequent critical points on the floor plan with the following symbol. 
3	Mark the cell contour on the floor plan by tracing a contour line through the Xs with a marker.

- 
- 4 Trace the cell boundaries and cell centers with colored markers.
- 

--End--

---


Identify new critical points.

**Procedure 9**  
**Identifying new critical points**

Step	Action
1	Identify one new critical point slightly inside of where the cell boundary meets the outside wall.  In <a href="#">Figure 22 "Example of new critical points (P8 and P9)" (page 56)</a> , this new critical point is P9.
2	Identify another new critical point which is adjacent to the first new critical point.  Locate this critical point on the opposite side of the cell boundary area.  In <a href="#">Figure 22 "Example of new critical points (P8 and P9)" (page 56)</a> , the cell boundary area is IC1 and the new critical point is P8.
--End--	


---

**Figure 22**  
**Example of new critical points (P8 and P9)**



Mark and label new critical points.

**Procedure 10**  
**Marking and labeling new critical points**

Step	Action
1	Mark and label these new critical points on the floor plan with the following symbol. <div></div> For more information, see <a href="#">Procedure 8 “Marking and labeling the cell boundary on the floor plan”</a> (page 54).
--End--	


Mark new cell contours and a new cell boundary.

**Procedure 11****Demarcating new cell contours, a new center and a new cell boundary**

Step	Action
1	<p>Using the critical points from <a href="#">Procedure 9 "Identifying new critical points" (page 55)</a>, mark new cell contours, a new cell center and a new cell boundary.</p> <p>For more information, see <a href="#">Procedure 4 "Demarcating the cell contour for the critical point farthest from the center of the full coverage area" (page 49)</a> to <a href="#">Procedure 7 "Demarcating a cell boundary" (page 53)</a>.</p> <p>Cell contour arcs must pass near the cell boundary of adjacent cells. For an example, see <a href="#">Figure 23 "Example of deployment for cell center 1C2" (page 57)</a>.</p>

--End--

**Figure 23**  
**Example of deployment for cell center 1C2**




Mark cell contours, centers, and boundaries at the far end of the intended coverage area.

**Procedure 12**  
**Demarcating additional cell contours, centers and boundaries at the far end of the building**

Step	Action
1	Repeat the procedures <a href="#">Procedure 3 “Identifying critical points on the floor”</a> (page 48) to <a href="#">Procedure 10 “Marking and labeling new critical points”</a> (page 56) as necessary to mark new cell boundaries at the other end of the building. In <a href="#">Figure 24 “Example of deployment for cells 1C3 and 1C4”</a> (page 58), new cells are formed around cell centers IC3 and IC4.
--End--	

**Figure 24**  
**Example of deployment for cells 1C3 and 1C4**



Identify new critical points.

**Procedure 13**  
**Identifying new critical points**


Step	Action
1	Mark critical points adjacent to a critical point and on the opposite side of the cell boundary area. (critical point = P11 in <a href="#">Figure 25 “Identify new critical points (P11, P12, P13, P14, P15, P16, P17)”</a> (page 59), where cell boundary area = IC2),

The critical points must be as follows.

- 2 Mark critical points inside of where the cell boundary meets the outside wall (P12, P13, P14, and P15 in [Figure 25 "Identify new critical points \(P11, P12, P13, P14, P15, P16, P17\)"](#) (page 59), and
- 3 Mark critical points where cell boundaries meet (P16 and P17 in [Figure 25 "Identify new critical points \(P11, P12, P13, P14, P15, P16, P17\)"](#) (page 59).

--End--

Figure 25  
Identify new critical points (P11, P12, P13, P14, P15, P16, P17)



Mark additional cell boundaries and define the extent of the coverage area.

**Procedure 14**  
**Demarcate additional cell boundaries to cover all areas of the building**

Step	Action
1	Repeat the procedures <a href="#">Procedure 3 "Identifying critical points on the floor"</a> (page 48) to <a href="#">Procedure 10 "Marking and labeling new critical points"</a> (page 56) as necessary to mark new cell boundaries at the middle of the building.

Critical points P11, P13 and P16 form the following:

- contours in Figure 26 "Contours formed by critical points P11, P13, and P16" (page 60)
- the cell center 1C5 in Figure 27 "Cell center 1C5 formed by critical points P11, P13, and P16" (page 61)
- a new cell boundary in Figure 28 "Cell boundary 1C5 formed by critical points P11, P13, and P16" (page 61)


Critical points P11, P12, and P17 form the following:

- contours in Figure 29 "Example of critical point cell boundaries" (page 62)
- a new boundary based on cell center 1C6 in Figure 30 "Example of cell center boundary 1C6" (page 62)


Figure 26 "Contours formed by critical points P11, P13, and P16" (page 60) shows a floor plan with complete radio coverage. Cell boundary 1C7 completes the floor plan.

--End--


**Figure 26**  
**Contours formed by critical points P11, P13, and P16**




**Figure 27**  
**Cell center 1C5 formed by critical points P11, P13, and P16**




**Figure 28**  
**Cell boundary 1C5 formed by critical points P11, P13, and P16**



**Figure 29**  
Example of critical point cell boundaries



**Figure 30**  
Example of cell center boundary 1C6



## Deploying on multiple floors

Use the information in this section to deploy SIP DECT in the following situations.

- The coverage area is on more than one floor.
- The floors are not adjacent.

## Checking for through-the-floor coverage

The first step in covering a multi-floor building is to assess the availability of through-the-floor coverage. In buildings mainly constructed of wood, you can use through-the-floor coverage. However, due to the construction of most modern buildings with raised floors, high metal content, and reinforced concrete, through-the-floor coverage with DECT is limited.

### Procedure 15 Checking for through-the-floor coverage

Step	Action
1	Place the deployment tool in a middle floor of the site.
2	<p>Go to the floor above the deployment tool and enter the site survey mode on the handset.</p> <p>For more information, see <a href="#">Procedure 1 “Entering the site survey mode” (page 45)</a> if you use Deployment Kit 2, or <a href="#">Procedure 107 “Entering the monitor mode” (page 232)</a> if you use an older Deployment tool.</p>
3	<p>Measure the deployment contour as if the basestation was on this floor, instead of the floor below.</p> <p>If only a small area is covered (less than a 10 metre radius), no through-the-floor coverage is available on the floor above an installed basestation.</p>
4	<p>Go to the floor below the deployment tool and repeat the preceding process.</p> <p>If only a small area is covered (less than a 10 metre radius), no through-the-floor coverage is available on the floor below an installed basestation.</p>
5	<p>If there is no through-the-floor coverage or coverage is restricted to a small area, deploy each floor using critical points, or if the floors have similar floor plans, you can use the same deployment plan on each floor.</p>
--End--	

### Assess floor layout

The deployment procedure changes according to the similarities and differences of the floors.

- All floors have the same layout.

To begin a multi-floor deployment if all floors have the same layout, deploy one floor and enter the data on the floor plan. Use the data from the deployed floor for other identical floors.

For example, if the second floor of an office tower is laid out with cubicle style offices with a perimeter of enclosed offices, and the third floor is laid out in the same manner, both floors can have the same installation profile for basestations.

- All floors do not have the same layout.

If the floor plan varies from floor to floor, use the critical point method to deploy each distinct floor. For more information, see [“Prepare the tool for deployment” \(page 226\)](#).

Do not underestimate the importance of changes in floor layout. Simple changes in a room from a meeting room to a storage room can have significant impact on the coverage from a basestation.


### Multi floor coverage situations

The following situations require multi-floor coverage.

- [“Atriums” \(page 64\)](#)
- [“High rise buildings” \(page 65\)](#)
- [“Unusual conditions” \(page 65\)](#)

**Atriums** Cells in an atrium, as shown in [Figure 31 "An atrium" \(page 65\)](#), are usually larger than the cells of the remainder of the building. Use the information in this section as a guide help you to plan an atrium. No precise steps to follow when you deploy an atrium, but you must consider several points. For more information, see [“Unusual conditions” \(page 65\)](#).

**Figure 31**  
**An atrium**



Consider the following points to deploy in an atrium:

- Plan atriums to the full height.
- Plan an atrium as one full size room, not floor by floor.
- Place cell centers within an atrium only if you intend for them to cover the atrium.
- Do not place cell centers in an atrium if you intend for them to serve adjacent areas.
- To serve adjacent areas, place the cell centers into these areas.
- Deploy the atrium first if the atrium is more than one-third the size of the building, or more than one cell in size.
- If cell centers in adjacent dense areas serve one floor of an atrium, verify the coverage of the cell on all of the floors that meet with the atrium.

**High rise buildings** Deploy a high rise building as an unusual type of multi-floor deployment.

Test through-the-floor coverage first. If there is no through-the-floor coverage, deploy each floor. Repeat the deployment for all floors with the same layout. In all other cases deploy floor by floor. You must deploy a floor with many meeting rooms differently from how you deploy an area with cubicles.

**Unusual conditions** No precise steps exist to follow when you deploy in unusual condition, but you must consider several points.

To plan an unusual condition, consider the following situations.

- “Cell centers are too close” (page 66)
- “Cell centers are too far apart” (page 66)
- “Too many cell centers” (page 67)

**Cell centers are too close** If you deploy cell centers less than 10 metres apart, the handsets can initiate unnecessary handover. Unnecessary handover results in excessive internal messaging and degraded speech quality.

**Cell centers are too far apart** If you deploy cell centers too far apart, the edge of a cell does not overlap the coverage from another cell.

Cell centers must be within the edge of other cell centers to provide satisfactory overlap.

Overlap can be difficult to achieve where coverage is received from the floor above or the floor below. Internal structures can cause overlap deficiencies.

Place cell centers within the cell boundary, as indicated by the deployment tool.

The installation of basestations in places other than the location shown on the plan can cause coverage problems; for example, if the basestation is mounted on the opposite side of a wall from its planned location.

Consider the following for basestation locations.


- Choose locations where you can easily mount basestations.
- Install basestations as close as possible to planned locations.
- Follow safety codes, and be aware aesthetics.
- Allow sufficient access to install basestations.
- Provide clear installation instructions.
- Test the coverage during post-deployment checks.

**Too many cell centers** The primary concern with deploying too many cell centers is cost. To deploy the correct number of cell centers and minimize cost, perform the following steps:

- Verify the coverage and traffic volume before you add additional cells.
- Remove a cell served by other cells unless it is required for high handset density.
- Verify the coverage area of each cell.
- Verify that at least one area that each cell serves is not served by another cell.

In the example in [Figure 32 "Locating redundant cells" \(page 67\)](#), cell 1C3 is redundant unless required for high handset density.

**Figure 32**  
**Locating redundant cells**



### Reengineer cells for high traffic areas

To accommodate the demand in high traffic areas, follow ["The cell reengineering process" \(page 68\)](#).

### Traffic volume

The deployment process ensures coverage throughout the service area. It does not, however, take into account the effect of traffic. To support the volume of telephone calls in cells that carry high traffic, you must increase the number of cells deployed.

The calculation of expected telephone traffic includes an allowance for the user population in a cell and for the roaming user.

### **The cell reengineering process**

The following sections describe the reengineering process.

- [“Estimating traffic within a cell” \(page 68\)](#)
- [“Separating the coverage area and recording the number of offices” \(page 69\)](#)
- [“Creating an estimate table” \(page 69\)](#)
- [“Calculating the number of users inside the cell with an office” \(page 70\)](#)
- [“Calculating the number of users with an office outside the cell who walk into the cell” \(page 71\)](#)
- [“Calculating the number of users without an office” \(page 72\)](#)
- [“Totalling the estimate for users in a cell” \(page 73\)](#)
- [“Calculating the data for all remaining cells” \(page 74\)](#)
- [“Creating a table to document telephone types in a cell” \(page 75\)](#)
- [“Determining cell reengineering” \(page 75\)](#)

**Estimating traffic within a cell** To adjust the number of users supported by the system, you can modify the deployment procedures you followed in [“Deploying on a single floor” \(page 48\)](#) or [“Deploying on multiple floors” \(page 63\)](#). Perform the following three steps to estimate traffic within a cell:


- Determine the number of handset users with an office within each cell.
- Determine how many users have wired phones.
- Determine how many users without an office are normally in each cell.

Some users have both wired and handset phones; other users rely on handsets only.

Re-engineered cells for high traffic areas are represented by an adjusted estimate for the two groups: handset and wireless, and handset only. Use the adjusted estimate to determine whether the cell sizes can handle the telephone traffic.

If the traffic-handling capacity of the cells is not adequate, use 12-channel basestations and subdivide them into smaller cells to ensure the traffic is handled properly according to the instructions.

**Figure 33**  
Example of dividing the coverage area and recording offices



**Procedure 16**  
**Separating the coverage area and record the number of offices**

Step	Action
1	Divide the floor plan into cell areas.  Mark the cell areas on the floor plan, one area for each cell, and split cell overlap areas in half, as shown in <a href="#">Figure 33 "Example of dividing the coverage area and recording offices"</a> (page 69) as heavy dotted lines.
2	Count the number of user offices in each cell area.
3	Record the number of user offices on the floor plan in each cell area.
--End--	

**Creating an estimate table** Use the following table to estimate the number of handset users for each cell.

**Table 5**  
**Estimate users in a cell**

Estimate for:	1C1	1C2	1C3	1Cn
Users inside the cell with an office				
Users with an office outside of a cell who walk into the cell				
Users without an office				
Users in a cell				

**Procedure 17**  
**Creating an estimate table**

Step	Action
1	Make an estimate table. Include a column for each cell center.
2	Label the rows as shown in <a href="#">Table 5 "Estimate users in a cell" (page 70)</a> .
3	Label each column heading with the cell center indicator. Use this table to determine how many times to subdivide each cell to carry the handset telephone traffic.
--End--	

**Table 6**  
**Example of the table first row calculation**

Estimate for:	1C1	1C2	1C3	1C4	1C5	1C6	1C7
Users inside the cell with an office	8.4						
Users with an office outside of a cell who walk into the cell							

**Table 6**  
**Example of the table first row calculation (cont'd.)**

Estimate for:	1C1	1C2	1C3	1C4	1C5	1C6	1C7
Users without an office							
Users in a cell							

**Procedure 18**  
**Calculating the number of users inside the cell with an office**

Step	Action
1	Estimate the number of users in the first cell with an office. Use the formula: (users with an office in the cell $\times$ 0.7)
2	Enter the result in the row Users inside the cell with an office. In the example in <a href="#">Figure 33 "Example of dividing the coverage area and recording offices" (page 69)</a> , 12 users in cell 1C1 spend 70 percent of their time in their offices ( $12 \times 0.7 = 8.4$ ) .

--End--

**Calculating the number of users inside the cell with an office** Traffic engineering demonstrates that handset users with an office spend 70 percent of their time within their home cell.

**Table 7**  
**Example of the table second row calculation**

Estimate for:	1C1	1C2	1C3	1C4	1C5	1C6	1C7
Users inside the cell with an office	8.4						
Users with an office outside of a cell who walk into the cell	3.2						

Estimate for:	1C1	1C2	1C3	1C4	1C5	1C6	1C7
Users without an office							
Users in a cell							

**Procedure 19**

**Calculating the number of users with an office outside the cell who walk into the cell**

Step	Action
1	Estimate the number of users in the first cell with an office outside of the cell who walk into the cell.
2	Use the following formula:  $\frac{(\text{Total users with an office} - \text{Users with an office inside the cell}) \times 0.3}{(\text{Total number of cells} - 1)}$
3	Enter the result in the row Users with an office outside the cell who walk into the cell.  <p>The example in <a href="#">Figure 33 "Example of dividing the coverage area and recording offices"</a> (page 69), shows 75 telephone users, minus the 12 users already in cell 1C1. Therefore, 63 users can walk into cell 1C1. However, the 63 walk-in users spend only 30 percent of their time outside their offices. Seven cells exist on the floor plan minus cell 1C1. Accordingly, an estimate of 3.2 walk-in users can be in cell 1C1.</p> $\frac{(75 - 12) \times 0.3}{(7 - 1)} = 3.2$
--End--	

**Table 8**  
**Example of the table third row calculation**

Estimate for:	1C1	1C2	1C3	1C4	1C5	1C6	1C7
Users inside the cell with an office	8.4						

**Table 8**  
**Example of the table third row calculation (cont'd.)**

Estimate for:	1C1	1C2	1C3	1C4	1C5	1C6	1C7
Users with an office outside of a cell who walk into the cell	3.2						
Users without an office	0						
Users in a cell							

**Procedure 20**  
**Calculating the number of users without an office**

Step	Action
1	Calculate the estimate for users in the first cell without an office. Use the following formula:  $\frac{\text{Total number of users without an office}}{\text{Number of cells}}$
2	Enter the result in the row Users without an office. In the example shown in <a href="#">Figure 33 "Example of dividing the coverage area and recording offices" (page 69)</a> , no users are without an office.
--End--	

**Table 9**  
**Example of the table first column total**

Estimate for:	1C1	1C2	1C3	1C4	1C5	1C6	1C7
Users inside the cell with an office	8.4						
Users with an office outside of a cell who walk into the cell	3.2						

Estimate for:	1C1	1C2	1C3	1C4	1C5	1C6	1C7
Users without an office	0						
Users in a cell	11.6						

**Procedure 21****Totalling the estimate for users in a cell**

Step	Action
1	Total the number of users in the first cell by adding the three rows in the first column.
2	Enter the result in the bottom row users in a cell.  For the example in <a href="#">Figure 33 "Example of dividing the coverage area and recording offices" (page 69)</a> , the 1C1 handset estimate equals 11.6.  $8.4 + 3.2 + 0 = 11.6$ .
--End--	

**Table 10****Example of a completed estimate table**

Estimate for:	1C1	1C2	1C3	1C4	1C5	1C6	1C7
Users inside the cell with an office	8.4	0.7	21.0	14.7	0.7	4.9	2.1
Users with an office outside of a cell who walk into the cell	3.2	3.7	2.3	2.7	3.7	3.4	3.6
Users without an office	0	0	0	0	0	0	0
Users in a cell	11.6	4.4	23.3	17.7	4.4	8.3	5.7

**Procedure 22****Calculating the data for all remaining cells**

Step	Action
1	Repeat the previous four procedures to calculate the remaining user cell estimates.
2	Enter the result in the estimate table.  The information in <a href="#">Figure 33 "Example of dividing the coverage area and recording offices" (page 69)</a> , is entered into <a href="#">Table 10 "Example of a completed estimate table" (page 74)</a> . This

table shows the results of the calculations for cells that require reengineering.

---

--End--

---

**Creating a table to document telephone types in a cell** Use a table like [Table 11 "Telephone types in a cell" \(page 75\)](#) to record the various telephone types in each cell.

**Table 11**  
**Telephone types in a cell**

Telephone type	1C1	1C2	1C3	1Cn
User telephone types				

Use the following symbols in each cell to denote the type of telephones in use in the cell.

- H&W for a cell in which all the users have both wired and handsets (wireless phones).
- H for a cell in which users have only handsets (wireless phones).
- M for a mix of H and H&W users

**Procedure 23**  
**Creating a table to document telephone types in a cell**

Step	Action
1	Make a Telephone types table.
2	Label the row User telephone types and include a column for each cell center.
3	Label each column heading with the cell center indicator.
	Use the information in this table to determine the number of cells that require reengineering.

---

--End--

---

**Table 12**  
**Example of a completed estimate table**

Estimate for:	1C1	1C2	1C3	1C4	1C5	1C6	1C7
Users inside the cell with an office	8.4	0.7	21.0	14.7	0.7	4.9	2.1

Estimate for:	1C1	1C2	1C3	1C4	1C5	1C6	1C7
Users with an office outside of a cell who walk into the cell	3.2	3.7	2.3	2.7	3.7	3.4	3.6
Users without an office	0	0	0	0	0	0	0
Users in a cell	11.6	4.4	23.3	17.7	4.4	8.3	5.7

**Table 13**  
**Example of a completed telephone types table**

Telephone type	1C1	1C2	1C3	1C4	1C5	1C6	1C7
User telephone types	H&W	H&W	M	M	H&W	H&W	H&W

**Table 14**  
**Cell reengineering**

Estimate for:		
Users with both a handset and a wired telephone	Users with only a handset	Action
From 0 up to 20	From 0 up to 12	Keep cell size as deployed.
Greater than 20	Greater than 12	Subdivide the cell <sup>a</sup> to meet the preceding conditions.
a. For information about how to subdivide cells, see <a href="#">“High handset density deployment” (page 79)</a> .		

**Determining cell reengineering** Use [Table 14 "Cell reengineering" \(page 76\)](#) only for user types H&W and H. For user type M see [“A mix of users with and without wired telephones in a cell” \(page 77\)](#) .

**Note:**

**Procedure 24**  
**Determining cell reengineering**

Step	Action
1	Find the number of users for users in the first cell. In the example shown in <a href="#">Table 12 "Example of a completed estimate table" (page 75)</a> , the handset estimate is 11.6.
2	Determine the telephone types in the first cell. In the example shown in <a href="#">Table 12 "Example of a completed estimate table" (page 75)</a> , the telephone type is H&W.
3	Locate the telephone type column in <a href="#">Table 12 "Example of a completed estimate table" (page 75)</a> . In the example H&W is the users with both a handset and a wired telephone.

- 4 Find the handset estimate range in [Table 14 "Cell reengineering" \(page 76\)](#).  
In the example, 11.6 falls within the From 0 up to 20 category.
- 5 Determine if a cell requires division or uses a 12-channel basestation.  
In the example From 0 up to 20, division is not required.
- 6 Repeat the preceding steps to determine the required number of cells that need subdivision, except for telephone types M. For M see ["A mix of users with and without wired telephones in a cell" \(page 77\)](#).
- 7 Transfer the results into the provisioning records.

---

--End--

---

### Cell division requirements in special cases

This section describes how to determine cell division in the following special cases.

- where no office information is available.
- where a mix of handset users exist with and without wired telephones

**No office information** If the location of the offices of users is not known, calculate the estimated number of handsets for each cell using this formula.

$$\frac{\text{Number of handsets}}{\text{Number of cells}}$$

The formula is based on the assumption that users are located evenly throughout the cells. However, most users offices are clustered in specific areas of a building.

The formula has limitations as cells can vary in size. The method described starting on ["The cell reengineering process" \(page 68\)](#) provides accurate cell division results.

**A mix of users with and without wired telephones in a cell** Use this procedure for mixed handset users. Telephone traffic generated by handset users equates to that of handset and wired users. Combine the two groups for cell size recalculation.

**Table 15**  
**Adjustment for users without wired telephones**

<b>Estimated number of handsets for users without wired telephones</b>	<b>Adjusted estimated number of handsets for each cell</b>
0	0
1	2
2	3
3	5
4	7
5	9
6	11
7	12
8	14
9	16
10	18
11	20
12	22
13	24
14	25
15	27
16	29
17	31
18	34
19	36
20	38
21	40
22	42
23	44
24	46
25	48
26	49
27	50
28	53
29	55
30	57
31	60

Estimated number of handsets for users without wired telephones	Adjusted estimated number of handsets for each cell
32	62
33	64
34	66
35	69
36	71
37	73
38	76
39	78
40	80

**Procedure 25**  
**Adjusting for users without wired telephones**

Step	Action
1	Count the number of user offices with handsets and wired telephones (H&W), and record the number.
2	Count the number of user offices that have only wireless handsets, (H).
3	Use <a href="#">Table 15 "Adjustment for users without wired telephones" (page 78)</a> to determine the equivalent number of H&W users and record this number.
4	Add the numbers received from steps 1 and 3 to determine and adjust the value for the number of users with wired telephones.
5	Use the first column of <a href="#">Table 15 "Adjustment for users without wired telephones" (page 78)</a> to determine if you must resize if the cell as described in <a href="#">"Determining cell reengineering" (page 75)</a> .
--End--	

## High handset density deployment

The high handset density deployment includes limiting the expected number of handsets for each cell center.

Use the high handset density procedure if instructed to in [Table 14 "Cell reengineering" \(page 76\)](#). Do not use more than one basestation for each cell center.

**Limit the anticipated number of handsets** Limit the number of handsets you anticipate for each cell center to the limits shown in [Table 14](#)


"Cell reengineering" (page 76). Subdivide high handset density areas only. If a cell falls into the category of a high density area, use [Procedure 26](#) "High handset density deployment" (page 80) to subdivide the cell.

**Subdivide a cell** To subdivide the area for smaller cells, divide the cell into as many small cells as necessary to accommodate the number of users in the area.

### ATTENTION

If you install two DAPs close to each other for extra traffic density, ensure the distance between the DAPs is always more than one meter and preferably more than 5 meters.

**Figure 34**  
Example of a subdivided cell



In [Figure 34](#) "Example of a subdivided cell" (page 80), cell 1C1 has 140 handset users and cell 1C2 has 100 handset users. For example, [Table 14](#) "Cell reengineering" (page 76) indicates the following:

- If the handset users in cell 1C1 are all handset only users, one cell can support 39 handset only users. Therefore, four cells are needed to support 140 users ( $140 \div 39 = 3.5$  cells).
- If the handset users in cell 1C1 are handset and wired telephone users, and one cell can support 83 users, two cells are needed to support 140 handset and wired telephone users ( $140 \div 83 = 1.6$  cells).

### Procedure 26 High handset density deployment

Step	Action
1	Determine the number of handset users in the high-density handset cell.  Count the number of users. Include users served by through-the-floor coverage of this cell.

- 2 Calculate the cell subdivisions as required.  
Divide the number of users by the appropriate value (12 or 20) shown in [Table 14 "Cell reengineering" \(page 76\)](#). Round up the result to the next whole number. The result equals the number of cells required after subdividing the cell.
- 3 Divide the cell.  
Draw lines from the cell center to the critical points on the cell boundary. In [Figure 34 "Example of a subdivided cell" \(page 80\)](#), the cell 1C1 is divided into four sectors and cell 1C2 is divided into three sectors.
- 4 Relocate new cell centers.  
Mark new cell centers within the sectorized areas.
- 5 Determine the number of handset users in the new cell areas.
- 6 Count the number of user offices within each smaller sector. Ensure fewer user offices exist within the cell than the traffic limit.
- 7 Take the deployment tool to the locations calculated on the floor plan. Ensure that there is a location that meets the requirements in ["Deployment requirements" \(page 21\)](#).
- 8 Ensure the new cells have complete coverage.
- 9 Use the deployment handset to check coverage.
- 10 Repeat the anticipated handsets for each cell calculation to ensure that each smaller cell provides appropriate traffic coverage to the users in the area.

---

--End--

---



---

# Software requirements

---

## Navigation

- [“Call server and SIP Line Gateway software” \(page 83\)](#)
- [“DAP controller software” \(page 83\)](#)

## Call server and SIP Line Gateway software

For information about Call Server 1000E, see *Communication Server 1000E Installation and Commissioning* (NN43041-310). For more information about SIP Line Gateway application installation, see *SIP Line Fundamentals* (NN43001-508).

## DAP controller software

This section contains the steps to configure the SIP DECT system. Before you can use SIP DECT, you must install and configure the following software on the DAP controller PC:

- Microsoft Windows

You can install any of the following operating systems on the DAP controller or manager PC.

- Windows 2000 Professional or Windows 2000 Server Service Pack 4 (SP4)
- Windows 2003 Server SP1 or SP2
- Windows 2003 Release 2
- Windows XP Professional SP2

This document does not provide the steps you must follow to install the operating system. For information about installing Windows, see the documentation that accompanied the Windows software.

If a firewall is installed on your DAP Controller PC, ensure the firewall does not block the ports used for various services. For information, see [“Firewall protection” \(page 84\)](#).

- Internet Explorer 6.0 or later

- Internet Information Services (IIS)  
For information about installing IIS, see [“Internet information services” \(page 84\)](#).
- DHCP and TFTP servers  
For information about installing DHCP and TFTP servers, see [“DHCP and TFTP servers” \(page 91\)](#).
- DAP Controller (IP DECT Configurator and DAP Manager)  
For information about installing the DAP Controller, see [“DAP Controller” \(page 106\)](#).

### Firewall protection

Both Windows XP Professional and Windows 2003 Server have built-in firewalls.

By default, the firewall under Windows XP Professional does not allow incoming access. However, the IP DECT Configurator can automatically change the firewall settings. Verify the firewall settings after installation.

If a third-party firewall program is installed on your DAP Controller PC, ensure the firewall does not block the ports used for the SIP DECT system. By default, some ports are defined in IP DECT Configurator.

The ports defined by default:

- From 3000 to 22229--multicast
- From 28000 to 28017--DAP Controller services
- 30160--CDA services

If you change default ports in the IP DECT Configurator, ensure that the firewall settings are updated correctly.

### Internet information services

The DAP controller or manager runs as a service under Windows. Because the management interface is available through a Web interface, you must install the Web Server IIS.

In Windows 2000 Professional, Windows XP Professional and Windows 2003 Server, IIS is not automatically installed. The next sections describe how to install IIS for Windows XP Professional, Windows 2000 and Windows 2003.

### Install and maintain IIS on Microsoft Windows 2000

Use the information in this section to install IIS on Windows 2000, and to ensure that IIS starts.

## Install IIS on a PC with Windows 2000

Install IIS.

### Prerequisites

- You must have the appropriate Windows installation CD-ROM available to complete this procedure.

#### Procedure 27

##### Installing IIS for Windows 2000 Professional

Step	Action
1	Click <b>Start &gt; Settings &gt; Control Panel</b> . The <b>Control Panel</b> appears.
2	Double-click <b>Add/Remove Programs</b> . The <b>Add/Remove Programs</b> window appears.
3	Click <b>Add/Remove Windows Components</b> . The <b>Windows Components</b> window appears.
4	In the <b>Windows Components</b> window, select the IIS check box.
5	Click <b>Next</b> .
6	Insert the Windows CD-ROM and follow the installation wizard instructions.
--End--	

## Check IIS on PC with Windows 2000

Determine whether IIS is started, and start it if necessary.

#### Procedure 28

##### Checking IIS on PC with Windows 2000

Step	Action
1	Open Internet Explorer on the PC where IIS is installed.
2	In the address bar in Explorer, enter <b>localhost/iisHelp/</b> and then press <b>enter</b> .
3	If <b>Help Information</b> appears, IIS is running. You are finished with this procedure.
4	If <b>Help Information</b> does not appear, check Windows Help and search for IIS. Follow the instructions on Windows Help to check whether or not IIS is started. If IIS is started, you are finished with this procedure.  If IIS is not started, go to step 5.

- 5 If IIS is not started after you perform the instructions in steps 1 to 4 of this procedure, click **Start**, go to **Settings**, and click **Control Panel** to manually start IIS. Double-click **Administrative Tools**, and then double-click **Computer Management**.
- 6 Expand the **Services and Applications** node in the console tree of the MMC and select **Internet Information Services**.
- 7 Click the right mouse button on **Internet Information Services** to restart the services. Click the right mouse button on the lower levels of **Internet Information Services** to stop or start the individual services.

---

--End--

---

### **Install and maintain IIS on Microsoft Windows 2003**

Perform the procedures in this section to install IIS on Windows 2003, restart IIS, or verify that IIS is operating.

#### **Installing IIS on a PC with Windows 2003**


Install the IIS function on a PC with Windows 2003.

- You must have the appropriate Windows installation CD-ROM available to complete this procedure.

#### **Procedure 29**

##### **Installing IIS on a PC with Windows 2003**


Step	Action
1	Click <b>Start &gt; Control Panel</b> .
2	Select <b>Add/Remove Programs</b> The <b>Add/Remove Programs</b> window appears.
3	Click <b>Add/Remove Windows Components</b> .
4	In the <b>Components</b> window, double-click <b>Application Server</b> .
5	In the <b>Components</b> window, check <b>ASP.NET</b> .



6 Select **Internet Information Services** and click **Details**.

The Internet Information Services (IIS) window appears.

7 Select the check boxes for **Internet Information Services Manager** and **Common Files**. Do not change the remaining check boxes.



- 8 Click **OK**.
- 9 Click **OK** again.
- 10 Follow the instructions provided by the installation Wizard, and insert the Windows CD-ROM as prompted.
- 11 Close the Add/Remove Programs window, and close the Control panel window.

---

--End--

---

### Restart IIS on a PC with Windows 2003

Restart IIS.

#### Procedure 30 Restarting IIS

Step	Action
1	Click <b>Start</b> , and open the <b>Control Panel</b> .
2	Click <b>Administrative Tools</b> .
3	Click <b>Computer Management</b> .
4	Expand the <b>Services and Applications</b> node in the MMC and select <b>Internet Information Services</b> .
5	Right-click the Internet Information Services and select <b>All Tasks</b> . The <b>All Tasks</b> menu appears.
6	Select <b>Restart</b> . IIS restarts.

---

--End--


---

### Check IIS on a PC with Windows 2003

Determine whether IIS started.

#### Procedure 31 Checking IIS on a PC with Windows 2003

Step	Action
1	Open Internet Explorer on the PC where IIS is installed.
2	In the address bar in Internet Explorer, enter <b>localhost/iisstart.htm</b> .



If IIS is not running properly you can restart IIS. For more information, see [Procedure 30 "Restarting IIS" \(page 88\)](#).

--End--

## Install and maintain IIS on Microsoft Windows XP

Use the information in this section to install IIS on Windows XP or verify that IIS is operating.

### Installing IIS on PC with Windows XP

Install the IIS function on a PC with Windows XP.

- You must have the appropriate Windows installation CD-ROM available to perform this procedure.

#### Procedure 32

##### Installing Web Server IIS with Windows XP

Step	Action
1	Click <b>Start &gt; Settings &gt; Control Panel</b> .
2	Double-click <b>Add/Remove Programs</b> . The <b>Add/Remove Programs</b> window appears.
3	Click <b>Add/Remove Windows Components</b> .
4	Select <b>Internet Information Services</b> .

**ATTENTION**

Do not select the check box beside Internet Information Services.

- 5 Click **Details**.
- 6 In the details window, select the check box **World Wide Web Service**.
- 7 Click **OK**.
- 8 Click **Next**.
- 9 Insert the Windows XP Professional CD. After the system prompts to you insert the CD, click **OK**.
- 10 If the Welcome to Microsoft Windows XP window appears, click **Exit** in the bottom left corner of the window. The appearance of the window is result of the auto run on the CD.
- 11 In the Windows Components wizard, click **Finish**.
- 12 Close the **Add/Remove Programs** window, and close the **Control panel** window.
- 13 If applicable, remove the CD, DVD, and floppy from your system. Close all windows and restart your computer.
- 14 After the computer restarts, check that IIS is running. If not, consult the Microsoft Web site. To check if IIS is running, see ["Check IIS on PC with Windows XP" \(page 90\)](#).

---

--End--

---

**Check IIS on PC with Windows XP**

Determine whether IIS is started.

**Procedure 33****Checking IIS on a PC with Windows XP**

Step	Action
1	Open Internet Explorer on the computer where you want to install the DAP manager.
2	Enter the URL <b>localhost/localstart.asp</b> .
3	Ensure that the <b>Internet Information Services (IIS)</b> page appears.



If the IIS start page does not appear, continue to [“Installing IIS on PC with Windows XP” \(page 89\)](#) and install IIS on your computer.

If the IIS start page appears, IIS is installed and running. Close the window and proceed to [“DHCP and TFTP servers” \(page 91\)](#).

---

--End--

---

## DHCP and TFTP servers

Each DAP receives an IP addresses, configuration file and firmware from the IP network using a DHCP server and a TFTP server. Choose whether to use the Microsoft Windows DHCP server or the TFTP server or both, or the built-in DAP controller DHCP and TFTP servers.

DHCP servers and TFTP servers are the network components of the Microsoft Windows 2003 Server and the Microsoft Windows 2000 Server. Install these servers as services for the SIP DECT system functions. For more information about Microsoft Windows 2000, 2003 DHCP and TFTP server installation and configuration, see [“DHCP and TFTP servers” \(page 91\)](#).

The DAP controller software Release 4 includes DHCP and TFTP servers that you can configure from the IP DECT Configurator. For more information about built-in DHCP and TFTP servers, see [“Built-in DHCP and TFTP servers” \(page 101\)](#).

You can create a DAP configuration without DHCP or TFTP; however DHCP and TFTP must be available to program or reprogram DAPs. For more information about DAP configuration without DHCP or TFTP, see [“DAP configuration without DHCP or TFTP servers” \(page 106\)](#) .

If you prefer to use Microsoft Windows DHCP and TFTP servers, perform the steps in [Procedure 34 “Installing and configuring Microsoft Windows DHCP server” \(page 92\)](#) to install and configure DHCP servers. Perform the steps in [Procedure 37 “Installing the TFTP server” \(page 99\)](#) to install and configure TFTP servers.

If your DHCP server supports Vendor Class Identification option 60, use a specific IP address range for the DAPs. The Vendor Class Identification of the DAPs is D(ECT)AP 49.

**Procedure 34**  
**Installing and configuring Microsoft Windows DHCP server**


Step	Action
1	<p>Ensure that your DHCP server provides the following data to the DAP.</p> <ul style="list-style-type: none"><li>• IP Address</li><li>• Subnet Mask</li><li>• Default Gateway IP address</li><li>• Next Boot Server IP address that is the IP address of the TFTP server (DHCP option 066)</li><li>• Configuration file name (dapcfg.txt) available through the TFTP server (DHCP option 067)</li></ul> <p>You can install the DHCP server on the same server or on another PC that runs the TFTP server.</p> <p>The Microsoft DHCP server installation files are located on the Microsoft Windows 2000/2003 Server CD-ROM package. Licensing or registration charges or both may apply.</p> <hr/> <p style="text-align: center;">--End--</p> <hr/>

You can install the DHCP server on the same server on the same server or on another PC that runs the TFTP server. The Microsoft DHCP server (Windows 2000 / 2003) is in the Microsoft Windows 2000 / 2003 Server CD-ROM package.

The following procedures give examples of setting up the DHCP server under Windows 2003 Server. This procedure also applies for Windows 2000 DHCP server, but with minor differences.

**Procedure 35**  
**Configuring DHCP server under Windows 2000 / 2003 server**

Step	Action
1	From the Start menu, through the settings in Windows 2000, open the <b>Control Panel</b> in Windows.
2	Open <b>Add/Remove Programs</b> .
3	Click <b>Add/Remove Windows Components</b> .
4	Select <b>Networking Services</b> and click <b>Details</b> . The <b>Components</b> window appears.
5	Select the <b>Dynamic Host Configuration Protocol (DHCP)</b> check box.



- |   |  |
|---|--|
| 6 | Click <b>OK</b> .  |
| 7 | Click <b>Next</b> .  |
| 8 | Insert the Windows 2003 CD-ROM as prompted.                    |
| 9 | Finish the procedure using the instructions in the dialog box. |

- 10 Close the **Add/Remove Programs** window and close the Control panel window.

---

--End--

---

**Procedure 36**  
**Configuring the Settings for SIP DECT**


---

Step	Action
------	--------

---

- |   |  |
|---|--|
| 1 | Start the DHCP manager: <b>Start &gt; Programs &gt; Administrative Tools &gt; DHCP</b> . |
|---|--|

The **DHCP Administration Tools** window appears.



- |   |  |
|---|--|
| 2 | Select the active DHCP server and create a new scope: <b>Action &gt; New Scope</b> . |
|---|--|

The New Scope Wizard starts.

- |   |   |
|---|---|
| 3 | Click <b>Next</b> in the wizard dialog box. |
|---|---|

- |   |  |
|---|--|
| 4 | Enter a name and description for the new scope, for example, SIP DECT. |
|---|--|

- |   |  |
|---|--|
| 5 | Click <b>Next</b> in the naming dialog box see the IP address range. |
|---|--|

The window **New Scope Wizard—IP address range** appears.

**New Scope Wizard**

**IP Address Range**  
You define the scope address range by identifying a set of consecutive IP addresses.

Enter the range of addresses that the scope distributes.

Start IP address: 192 . 168 . 100 . 200

End IP address: 192 . 168 . 100 . 210

A subnet mask defines how many bits of an IP address to use for the network/subnet IDs and how many bits to use for the host ID. You can specify the subnet mask by length or as an IP address.

Length: 24


Subnet mask: 255 . 255 . 255 . 0

< Back   Next >   Cancel

- 6 Define a range of IP addresses for the DAPs used, for example, 192.168.100.200 to 210.
- 7 Define the associated subnet mask, for example, 255.255.255.0.
- 8 Click **Next**.  
The window **New Scope Wizard—Exclusion of an IP address range** appears.
- 9 Enter the Start IP address and End IP address values to exclude, for example, the IP addresses of DHCP server and the TFTP server.  
This is necessary only if the IP address or addresses of equipment with a fixed IP address is within the DHCP address range. If it is not within the DHCP address range, leave this field blank.
- 10 If you entered IP address ranges in step 6, click **Add** to save the exclusion list.
- 11 Click **Next**.  
The **Lease Duration** window appears.
- 12 Set the desired lease duration of the granted IP addresses to the desired value.

- 13 Click **Next**.


The **New Scope Wizard—Configure DHCP options** appears.




- 14 Select **No**, and click **Finish**.

The newly created scope appears with a new line called Scope Options.

- 15 Right-click **Scope Options**, and select **Configure Options**. The **Scope Options** page appears.



- 16 Select the Option 066 check box, and enter the IP address of the TFTP server, for example, 192.168.100.10.  
This can be the IP address of your DAP controller or manager, if the TFTP server is running there.
- 17 Check **Option 067** for the boot file name. Enter **dapcfg.txt**.
- 18 Select the **Option 3** check box, and enter the Router or Default Gateway IP address, for example, 192.168.100.1, and click **Add**.



- 19 Click **Apply** to save the changes and **OK** to close the dialog box.
- 20 Right-click **Scope** , and select **Activate**.  
Now your DHCP server is configured correctly.
- 21 Close the DHCP window.

---

--End--

---

### TFTP server


Many types of TFTP servers are available, including shareware and freeware. A TFTP server must handle several accesses at the same time, because several accesses occur at the same time, when the DAPs start

simultaneously. Only a few TFTP servers can handle more than one access at the same time. Some of these crash if the number of accesses is too high.

Install a TFTP server on the Windows 2000 Server and the Windows 2003.

### Procedure 37 Installing the TFTP server

Step	Action
1	If you have Windows 2003, go to <b>Start &gt; Control Panel</b> in Windows. If you have Windows 2000, go to Control Panel through Settings.
2	Open <b>Add/Remove Programs</b> .
3	Click on the <b>Add/Remove Windows Components</b> . The <b>Windows Components Wizard</b> window appears.



- 4 In the Components window, select the Remote Installation Services check box.
- 5 Click **Next**.
- 6 Insert the Windows 2000 or Windows 2003 CD-ROM as prompted.
- 7 Follow the instructions in the dialog box to complete the procedure.

- 8 Close the **Add/Remove Programs** window and close the **Control panel** window.
- 9 Click **yes** after you are prompted to restart the computer.

---

--End--

---

**Procedure 38**  
**Starting the TFTP server**


---

Step	Action
------	--------

---

- |   |  |
|---|--|
| 1 | If you have Windows 2003, go to <b>Start &gt; Control Panel</b> . If you have Windows 2000, go to <b>Settings &gt; Control Panel</b> . |
| 2 | Open <b>Administrative Tools</b> .   |
| 3 | Open <b>Services</b> .   |


The **Services** window appears.



- 4 Select **Trivial FTP Daemon**.
- 5 Right-click the **Trivial FTP Daemon** , and then select **Start**.
- 6 Right-click the **Trivial FTP Daemon**, and then select **Properties**.
- 7 Change the Startup Type setting to Automatic.
- 8 After you install TFTP on your PC with Windows 2000, a folder named **tfptdroot** is created.

**ATTENTION**

If you run Windows 2003, you must create the TFTP folder on drive C:, as shown in the following figure.



--End--

### Built-in DHCP and TFTP servers

The DAP controller software has a built-in DHCP and TFTP server. The built-in DHCP and TFTP servers do not require manual configuration, because the IP DECT Configurator performs the configuration.

#### ATTENTION

You can configure a Built-in DHCP and TFTP server only after you install the IP DECT Configurator. For more information, see [“DAP Controller” \(page 106\)](#).

### Built-in DHCP server

The DAP controller software has a built-in DHCP server. This server runs as an application that requires you to log on to Microsoft Windows. You can use the IP DECT Configurator tool available under DAP controller to start or stop the DHCP server program.

This DHCP server responds to DHCP requests from DAPs because it checks on Vendor Class Identification D(ECT) AP 49 from a DAP.

You can configure built-in DHCP server using the Network Settings window of IP DECT Configurator.


**Prerequisites** If you are configuring a new system, perform the following procedures before you configure the built-in DHCP server.

- [Procedure 43 “Starting the IP DECT Configurator” \(page 112\)](#)
- [Procedure 44 “Adding a new system using the IP DECT Configurator” \(page 113\)](#)

**Procedure 39**

**Configuring the built-in DHCP server using the IP DECT Configurator  
Network Settings Window**

Step	Action
1	Start the IP DECT Configurator, and select <b>Modify the system</b> .
2	Choose the system to modify.
3	Select the <b>Run DHCP server on this PC</b> check box.
4	Enter the <b>DAP IP range</b> , for example, 192.168.100.200-210.
5	Select the <b>DAP IP Range exclusive for DAPs only</b> .
6	Enter the <b>Subnet Mask</b> , for example, 255.255.255.0.
7	Enter the <b>Default gateway</b> , for example, 192.168.100.1.
8	Enter the <b>TFTP IP address</b> on the PC where the DAP controller software is installed, for example, 192.168.100.10.
9	If you must assign manually IP addresses to the DAP, click <b>More</b> .
10	Enter <b>MAC address</b> of the DAP and the <b>IP address</b> assigned to the DAP.  You can add DAPs to the list, delete DAPs from the list, or edit the addresses.
11	Click <b>Apply</b> to save the changes, or <b>Close</b> to exit.



- 12 Click **Apply**.
- 13 Start the DHCP server with **Start > All Programs > DAP controller**.
- 14 Restart the DAPs.  
If you are configuring a new system, follow the steps in [Procedure 45 "Configuring IP Settings" \(page 114\)](#) instead of restarting DAP.

--End--

### Built-in TFTP server

The DAP controller has a built-in TFTP server that runs as a service under Microsoft Windows. You can use the IP DECT Configurator tool available with the DAP controller to start or stop the TFTP server program. You can start or stop the service through the services window in Microsoft Windows.

### Configuration without DHCP or TFTP

#### ATTENTION

DAP configuration without DHCP or TFTP requires DHCP and TFTP to be temporarily available to program or reprogram DAPs.

You can perform DAP configuration without DHCP or TFTP only after you install the IP DECT Configurator. For more information, see ["DAP Controller" \(page 106\)](#).

You can install the DAPs in an IP environment without a DHCP server, a TFTP server, or both. The IP environment can be a VLAN within the company network where the IT manager does not allow a DHCP server. This IP environment can also be a branch office where a few DAPs are installed without a DHCP server.

If a DAP must operate without a DHCP server, a TFTP server, or both, the DAP requires that the IP address and configuration data are stored in the DAP on a semipermanent basis in FEPRM.

To store the IP address and configuration data on DAP, you must temporarily connect a DHCP server and a TFTP server. The DHCP and TFTP server can be on a stand alone PC with a network interface and a DAP connected. The DHCP and TFTP server can also be on any other computer in the network.

The DHCP server and TFTP server are required while you configure the DAP, but are not required during normal operation.

**ATTENTION**

To store the data in the DAP, it is necessary that the DAP have a DHCP offer with an Unlimited or Infinite lease. Ensure the DHCP server issues an Unlimited or Infinite lease. The DHCP server with IP DECT issues such a lease by default.

If a Microsoft Windows DHCP server is configured, enable unlimited lease.

**Procedure 40**  
**Enabling unlimited lease**

Step	Action
1	Start the DHCP manager: <b>Start &gt; Programs &gt; Administrative Tools &gt; DHCP</b> .
2	Right-click <b>Scope</b> , and select <b>Properties</b> . The DHCP Administrative tools page appears.
3	Select <b>Unlimited for Lease duration for DHCP clients</b> .

The screenshot shows the 'General' tab of a DHCP Scope configuration window. The 'Scope' folder icon is visible. The 'Scope name' is 'DAPs'. The 'Start IP address' is '192.168.100.200' and the 'End IP address' is '192.168.100.210'. The 'Subnet mask' is '255.255.255.0' with a 'Length' of '24'. Under 'Lease duration for DHCP clients', the 'Unlimited' radio button is selected. The 'Description' field is empty. At the bottom are 'OK', 'Cancel', and 'Apply' buttons.

- 4 Click the **Advanced Tab**, and select **Both** for Assign IP addresses dynamically to clients of and **Unlimited** for **Lease duration for OOTF clients**.

The screenshot shows the 'Advanced' tab of the same DHCP Scope configuration window. Under 'Assign IP addresses dynamically to clients of:', the 'Both' radio button is selected. Under 'Lease duration for BOOTP clients:', the 'Unlimited' radio button is selected. The 'OK', 'Cancel', and 'Apply' buttons are at the bottom.

- 5 Click **OK** to save changes.

---

--End--

---

**DAP configuration without DHCP or TFTP servers** You can perform DAP configuration without DHCP or TFTP servers using the Network Settings window of the IP DECT Configurator.

Configure a DAP to store IP address and configuration data.

**Procedure 41**

**Storing IP address and configuration data on a DAP**

Step	Action
1	Start the IP DECT Configurator and select <b>Modify the system</b> .
2	Select the system to modify.
3	Click <b>More</b> .
4	Select the <b>DAP Boot Options</b> check box.
5	Select <b>Store IP configuration into flash memory</b> .
6	Click <b>Apply</b> .
7	Click the <b>Save system</b> button in the left pane.
8	Ensure that the DHCP server is running and that the TFTP server is running.
9	Restart the DAPs.
	The IP data and configuration data is now stored into the DAPs and the DAPs can function without the DHCP and TFTP servers.
<hr/> <p>--End--</p> <hr/>	

**DAP Controller**

Perform the procedures in this section to install the DAP Controller from the CD. You must execute this procedure only once, and thereafter use the installation for any number of system configurations. You can change settings later.

## Prerequisites

- Install and configure IIS software.  
For more information, see [“Internet information services”](#) (page 84).
- Install and configure DHCP and TFTP servers if you use Microsoft Windows DHCP and TFTP servers. For more information, see [“DHCP and TFTP servers”](#) (page 91).
- Ensure that you have DAP controller or manager software Release 5 or later.
- Ensure that you have DAP firmware 4910b510.dwl or later.
- Ensure that you have configured the IP addressing on the network adaptor.

## Procedure 42 Installing the DAP Controller

Step	Action
1	<p>Insert the CD-ROM in the CD drive, and run setup.exe.</p> <p>Depending on the directory structure on the CD-ROM, the setup.exe file is on Disk1.</p> <p>The <b>InstallShield Wizard</b> appears. This window remains visible while you install the DAP controller components and gives you information about the installation progress.</p>
2	<p>If Microsoft .NET Framework 2.0 is already installed, the <b>Welcome to the InstallShield Wizard for DAP controller</b> window appears. Go to step 6.</p> <p>If the Microsoft .NET Framework 2.0 software is not yet installed, an <b>Installshield</b> dialog appears, with the following statement: <b>DAP Controller optionally uses the Microsoft (R) .NET 2.0 Framework. Would you like to install it now?</b></p>
3	<p>The <b>Microsoft .NET Framework 1.1 Setup: End User License Agreement</b> page appears.</p> <p>Click <b>Yes</b> to install Microsoft .NET Framework 2.0 software. The <b>Microsoft .NET Framework 2.0 Setup: End User License Agreement</b> page appears.</p>
4	<p>Click <b>I agree</b>, and then click <b>Install</b>.</p> <p>The Microsoft .NET Framework 2.0 installs, and the <b>Microsoft .NET Framework 2.0 Setup: Setup Complete</b> page appears.</p> <p>Installation can take several minutes. The DAP controller - InstallShield Wizard indicates activity with a progress bar.</p>
5	<p>Click <b>OK</b>.</p>

- A message appears requesting that you restart the PC.
- 6 Click **OK** to restart the PC.
- After the PC restarts, it automatically continues with the DAP controller installation. The **DAP controller - InstallShield Wizard** page appears.
- 7 Click **Next**.
- The **System Type** page appears.
- 8 Two types of DAP Controller installation are available. Select one of the following:
- Select **Single System** if plan to manage only one SIP DECT system with your PC. Nortel recommends this option unless you install DAP Controller on a laptop PC to be carried between SIP DECT systems, to manage them.  
**OR**
  - Select **Multiple Systems** to manage more than one SIP DECT system with your PC. This option is meaningful for a laptop PC to be carried from one SIP DECT system to another to configure and maintain them. You can select this option when installing a DAP Controller dedicated to a specific SIP DECT system, in such a case the DAP Controller operates as it would in Single System mode.

You cannot use DAP Controller PC in more than one system at the same time. With a Multiple Systems installation type, you can activate one of the configured SIP DECT systems and make changes.

The DAP Controller PC can work with only one active SIP DECT system. Nortel recommends that you configure a dedicated DAP Controller PC in each SIP DECT system. If you cannot dedicate a DAP Controller PC in each SIP DECT system, then you can use a laptop PC with DAP Controller installed and temporarily connect that laptop PC to the networks where each SIP DECT system is installed (the option Multiple Systems exists to support that configuration). Some functions of SIP DECT system are not available when no dedicated DAP Controller PC is available in the system.

- 9 Click **Next**.
- The **Setup Type** page appears.
- 10 Select **Standard**, and click **Next**. To customize the installation, select **Custom**.
- 11 Click **Next**. The **Select Installation Address** page appears.
- Do not change the default values in the fields CDS and Port Number.

- 12** Click **Next**.  
The **Ready to install the program** page appears.
- 13** Click **Install** to start the installation.  
The system installs the software.  
The **InstallShield Wizard Completed** page appears when the installation is complete.
- 14** Click **Finish**.  
The IP DECT Configurator starts automatically, so that you can configure your SIP DECT system.

---

--End--

---



---

## System configuration

---

Traditional Digital Enhanced Cordless Telecommunications (DECT) is an application on the system that allows digital wireless capabilities. With DECT, users can move around their work sites while answering a call, making a call, continuing a call, or transferring a call.

Session Initiation Protocol (SIP) DECT on SIP Line provides the features of traditional DECT so that the SIP DECT system can interact with Communication Server 1000 through the SIP Line gateway.

Prior to Communication Server 1000 (CS 1000) Release 7.0, it was possible to connect SIP clients using the SIPN connection method. Beginning in CS 1000 Release 7.0 the SIPN connection method is no longer supported; however, you can migrate your SIPN connection to a SIPL connection. For more information on the Upgrade procedure, see [“Upgrade a SIPN connection to a SIPL connection” \(page 257\)](#)

### Navigation

This section contains the following navigation links to SIP DECT configuration procedures:

- [“Basic \(simple\) SIP DECT configuration with Communication Server 1000 SIP Line Gateway” \(page 111\)](#)
- [“Routed Head Quarter configuration” \(page 132\)](#)
- [“Multiple-site mobility network configuration” \(page 136\)](#)

### Basic (simple) SIP DECT configuration with Communication Server 1000 SIP Line Gateway

To configure the SIP DECT system, you must configure the following three components: the Call Server, the SIP LINE Gateway, and the DAP manager. Use the DAP manager to configure and monitor DAPs.

Use the following tools to configure a SIP DECT system:

- Element manager or overlay program for Call Server
- IP DECT Configurator and DAP manager IP DECT, which are available as a part of the DAP controller software package

### Configuration using IP DECT Configurator

Use the IP DECT Configurator tool to create configuration files for the DAP controller and DAPs. The IP DECT Configurator is installed and starts automatically when you install the DAP controller software. You can also start the IP DECT Configurator by using the shortcut to the IP DECT Configurator tool under the Start menu at Programs > DAP controller > DAP Applications.


For information about IP DECT Configurator installation, see [Procedure 42 “Installing the DAP Controller” \(page 107\)](#).

Perform the following procedures to configure the settings in the IP DECT Configurator.

- [Procedure 43 “Starting the IP DECT Configurator” \(page 112\)](#)
- [Procedure 44 “Adding a new system using the IP DECT Configurator” \(page 113\)](#)
- [Procedure 45 “Configuring IP Settings” \(page 114\)](#)
- [Procedure 46 “Configuring Network Settings” \(page 115\)](#)
- [Procedure 51 “Configuring other settings—Performance/Email Settings” \(page 120\)](#)
- [Procedure 52 “Configuring other settings—Customer Information settings” \(page 123\)](#)
- [Procedure 53 “Saving the system” \(page 123\)](#)
- [Procedure 54 “Enabling or re-enabling the DAPs” \(page 124\)](#)

#### Procedure 43 Starting the IP DECT Configurator

Step	Action
1	Select <b>Start &gt; Programs &gt; DAP controller &gt; DAP Applications &gt; DAP Configurator</b> .  If your network card does not have a fixed IP address, the following error message appears after the application starts.



To correct this error, assign a fixed IP Address to the network card in your DAP controller PC and restart the application.

The IP DECT Configurator main window has three panes.

1. The top pane shows the Settings buttons.
2. The left pane shows the System Control buttons.
3. The middle pane shows the information.

---

--End--

---

#### Procedure 44

#### Adding a new system using the IP DECT Configurator

Step	Action
1	<p>In the <b>IP DECT Configurator</b> main window, click <b>New System</b> in the <b>System Control</b> settings pane.</p> <p>The <b>General settings</b> page appears.</p>

**Figure 35**  
**IP DECT Configurator**

- 2 Enter the System name, for example, System\_1.  
Use no special characters in your SIP DECT system name. The folder and the SIP DECT system share the same name.
- 3 Select **SIP on CS1000 SIPL** in PBX menu.
- 4 In the **General Settings** window, enter the path to the firmware, the DAP package file, for example, C:\tftpdroot\4910b510.dwl.
- 5 Click **Apply**.

--End--

#### Procedure 45 Configuring IP Settings

Step	Action
1	On the Settings pane, click <b>IP Settings</b> . The <b>IP Settings</b> page appears.

- 2 In the **Multicast address** field, enter **239.192.49.49**.
- 3 Enter the **DAP controller Configuration: DC IP address**, which is the IP address of the PC where your DAP controller is installed. An example of this address is 192.168.100.10.
- 4 Enter the **Proxy IP address**, which is the SIP LINE Gateway Node IP address, for example, 192.168.100.105.
- 5 Click **Apply**.

--End--

#### Procedure 46 Configuring Network Settings

Step	Action
------	--------

- |   |   |
|---|---|
| 1 | In the Settings pane, click <b>Network Settings</b> . |
|---|---|

The **IP DECT Configurator Network Settings** window appears.

- 2 Select the network card that is connected to the SIP DECT system.

- 3 Select the **Run TFTP server on this PC** check box, and choose one of the following options:
- If you use a Microsoft Windows TFTP server, select **Windows TFTP server on this PC**.  
**OR**
  - If you use a built-in TFTP server, select **3com TFTP server on this PC**.
- 4 Configure the DHCP server.
- If you use a Microsoft Windows DHCP server, click **Apply**.  
**OR**
  - If you use a built-in DHCP server, see Built-in DHCP server.

**ATTENTION**

If you plan to create a configuration without DHCP and TFTP servers, see [“Configuration without DHCP or TFTP” \(page 103\)](#).

- 5 Optionally, select the **Monitor TFTP server** check box to monitor the TFTP activity of the built-in TFTP server. The results appear in the **System Status** window, which appears when you click **Activate / Deactivate / System Status**.
- 6 Optionally, select the **Monitor DHCP server** check box to monitor the DHCP activity of the built-in DHCP server. The results appear in the **System Status** window, which appears when you click **Activate / Deactivate / System Status**.

---

--End--

---

**Procedure 47**  
**Configuring System Settings**

Step	Action
1	In the Settings pane, click <b>System Configuration</b> .
2	Choose one of the following: <ul style="list-style-type: none"><li>• To create a Basic (simple) configuration, select <b>Simple configuration</b>, and click <b>Apply</b>.</li><li>• To create a Routed Head Quarter configuration, see <a href="#">“Configure Routed Head Quarter” (page 133)</a>.</li></ul>

- To create a Branch office configuration, see “Branch Office configuration” (page 129).
- To create a Routed Head Quarter with Branch office configuration, see “Routed Head Quarter Configuration with Branch Office” (page 135).

--End--

#### Procedure 48 Configuring SIP Settings

Step	Action
1	In the Settings pane, click <b>SIP Settings</b> . The <b>SIP Settings</b> window appears.

**Figure 36**  
**SIP settings**

The screenshot shows the 'IP-DECT Configurator' window with the 'SIP Settings' tab selected. The window is titled 'System 1'. The 'SIP Settings' section includes fields for 'SIP Server' (CS1000 SIPL), 'Local time zone' (GMT + 06 hours 00 minutes), and 'Advanced SIP Settings'. The 'Advanced SIP Settings' section includes fields for 'SIP domain' (mera.ru), 'Registrar IP address' (192.168.100.105), and five 'Authentication Realm' entries. Each realm has 'User' and 'Pswd' fields. A 'Configuration items' list is on the right, showing various SIP-related settings with checkboxes. The bottom of the window has buttons for 'Exit', 'Default', 'Apply', and 'Cancel'. The status bar at the bottom indicates 'Nortel | Multiple System Mode | Advanced Mode'.

2 In the **SIP Domain** field, enter the domain name.

The SIP domain you enter here must be the same as the SIP domain name you enter as the domain in SIP LINE Gateway, in [“SIP Line Gateway configuration” \(page 128\)](#).

- 3 Click **Proxy IP** to use SIP Line Gateway as Registrar. This option is not available if your system uses Multiple Gatekeepers.
- 4 Configure the following values for Authentication Realm 1:
  - In the **Authentication Realm 1** field, enter the domain name (capital letters)
  - In the **User** field, enter %s
  - In the **Pswd** field, enter %s

The password is encrypted, and does not appear in a readable form if you reopen the SIP settings tab.

To change the password, enter a new value in the **Pswd** field, save the system, and restart all connected DAPs.

All required SIP Settings are set automatically to required values according to CS1000 SIPL configuration. Optionally, you can configure the following:

1. Select the check box for max\_intern\_dnr\_len and enter the maximum number of digits in the internal DNs. DNs that contain more digits than configured for this parameter are defined as external. Depending on DECT handset capabilities, different ringing melodies can be used for internal and external calls.
2. Select the check box for t\_overlap\_first and enter the value (in seconds) to define how long the DAP waits for the user to dial the first digit. If no new digit is dialed within the specified period of time, the DECT handset goes on-hook automatically.
3. Select the check box for t\_overlap\_final and enter the value (in seconds) to define how long the DAP waits for the user to dial the next digit of the number (when the user has already dialed in at least one digit). If no new digits are dialed within the specified period of time, the dialed number is called.

**Note:** This setting is applied to the predial mode as well.

4. Select the check box for Call\_waiting\_indication and enter the text that will be displayed on the screen of the handset for second incoming call.
5. select the check box for 404 and enter the text that will be displayed on the screen of the handset if a called user is not found.

6. Select the check box for 480 and enter the text that will be displayed on the screen of the handset if a called user is busy.
7. Select the check box for 486 and enter the text that will be displayed on the screen of the handset if a called user is not available.

5 Click **Apply**.

--End--

#### Procedure 49 Configuring DECT Settings

Step	Action
------	--------

- |   |  |
|---|--|
| 1 | In the Settings pane, click <b>DECT Settings</b> .<br>The <b>DECT Settings</b> window appears. |
|---|--|

- |   |   |
|---|---|
| 2 | Enter an eight-digit hexadecimal string for the Primary Access Right Identity or <b>PARI</b> , for example, 1F12345A. |
|---|---|

The worldwide unique PARI for your DECT system must be issued by the European Telecommunications Standards Institute (ETSI). For information, see [www.etsi.org](http://www.etsi.org).

**ATTENTION**

Ensure you enter the correct PARI. You must reinstall the DAP Controller software and resubscribe all DECT handsets if you change the PARI.

If you plan to configure an MSMN configuration enter an eight-digit hexadecimal string for the Secondary Access Right Identity or SARI, for example, 1F12345F.

SARI must be the same on all systems used as MCDN sites.

- 3 Click **Apply**.

---

--End--

---

The following procedure applies to SIPL configurations only.

**Procedure 50****Configuring other settings—PBX Settings**

Step	Action
1	In the Settings pane, click <b>PBX Settings</b> . The PBX Settings window appears.
2	In <b>Conference ID</b> field, enter <b>conference</b> .
3	In the <b>Conference IP address</b> field, enter the SIP Line Gateway Node IP address.
4	Click <b>Apply</b> .
<hr/> <p>--End--</p> <hr/>	

**Procedure 51****Configuring other settings—Performance/Email Settings**

Step	Action
1	Click <b>Performance/Email Settings</b> . The <b>Performance/Email Settings</b> window appears.

**IP-DECT Configurator**

General Settings | IP Settings | Network Settings | System Configuration | SIP Settings | DECT Settings | PBX Settings | Performance / Email Settings | Customer Information

Home | New System | Modify System | Import System | Activate / Deactivate / System Status | Export System | Delete System | Save System | Exit | Default

**Performance and email settings** System 1

**NOTE: PCR Service must be running for performance retrieval and automatic email generation!**

Generate UPM data every:  minutes Keep performance data for:  days

Generate EPM data every:  minutes

Start measurement at:  Create performance data every: ☐ Sun ☒ Mon ☒ Tue ☒ Wed ☒ Thu ☒ Fri ☐ Sat

Stop measurement at:

**Advanced Settings:**

Alarm notification:  Email from:

SMTP Server:  ☐ Email nightly created archive

Email address(es):  Email address(es):

Channel occupation: Threshold:  % Time:  sec.

Alarm reaction time:  hours

Send archive every: ☐ Sun ☒ Mon ☒ Tue ☒ Wed ☒ Thu ☒ Fri ☐ Sat

Stop sending archive after:

HTTP execution timeout:  sec. Max. archive size:  Mb

☐ Use client resolution

Nortel | Multiple System Mode | Advanced Mode

- 2 In **Performance Settings**, under **Performance Counters Configuration** enter a value for **Interval UPM generation every \_\_\_\_\_ minutes**, or accept the default of 1440 minutes, which equals one day.  
This interval specifies how often User Performance Measurement files are generated.
- 3 Enter a value in **Interval EPM generation every \_\_\_\_\_ minutes** or accept the default of 15 minutes.  
This interval specifies how often Equipment Performance Measurement files are generated.
- 4 Enter a value next to **Start measurement at** with the time you want performance measurement to start each day.
- 5 Enter a value next to **Stop measurement at** with the time you want performance measurement to stop each day.
- 6 Under **Create performance counters every**, select the check boxes under the days of the week you want performance counter retrieval to occur.

- 7 In the field **Keep Performance data for \_\_\_\_\_ days** fill in the number of days you want the performance data stored on the hard disk.
- 8 Click **More** to access **Advanced Email Settings**.
- 9 In **Advanced Email Settings**, Enter a value next to **SMTP Server** with the DNS name or the IP address of your SMTP mail server.

With **Advanced Email Settings**, email messages can be sent automatically if a DAP fails or if the channel occupation threshold is exceeded for more than a specified number of seconds. Automatic email messages can be sent only if the DAP controller or manager is running, and the PCR service is running on the DAP controller or manager PC.

If you enter the DNS name of your SMTP Server, ensure that the DNS server address is configured for the network connection on the DAP Controller.
- 10 Select the **Send alarm emails** check box , which enables SIP DECT to send email messages to the SMTP Server.
- 11 Fill the field next to **Email addresses** with one or more destination email addresses.
- 12 Enter a value next to **Email from** with the email address of the originator.

Normally, the SMTP server does not verify the email address of the originator. This means you can enter any email address in this field.
- 13 Fill in the two boxes after **Channel Occupation**. In the Threshold box, specify the percentage. In the Time box, specify a time in seconds.

Channel Occupation defines the conditions for generating an email on DAP channel occupation. If the channel occupation is higher than the percentage of the available channels for a specified time period, an email is generated. The threshold is specified in percentage, the time is specified in seconds.
- 14 Fill in the box next to **Alarm reaction time** with the hours as an interval to send email messages.

The default Alarm reaction time is 24 hours. This means that the minimum interval between two alarm email messages is 24 hours; after the system sends an alarm email, 24 hours must pass before the system can send another alarm email. Enter 0 (zero) if you want alarm email messages to be sent immediately after an alarm event occurs.
- 15 Select the **Email nightly created archive** check box to automatically receive archives for each email.

- 16 Enter a value next to **Email addresses** with one or more destination email addresses.
- 17 Select the days to receive archives, the date to stop sending archives, and the maximum size of the attached archive.
- 18 Optionally, enter **HTTP execution time out**. HTTP execution time out (specified in seconds) is a guarding timer for the ASP scripts. For example, if the ASP Web pages tries to send an archive and it takes longer than the time specified here, the attempt is terminated.
- 19 If you check **Use client resolution**, you can no longer scroll through lists; instead, the available information is broken into pages. You can select pages using tabs. If this box is unchecked, you can scroll through the information using the scroll bar. The information is still separated into pages, but each page contains more information.
- 20 Click **Apply**.

---

--End--

---


**Procedure 52**  
**Configuring other settings—Customer Information settings**

Step	Action
1	Click <b>Customer Information</b> .  The <b>Customer Information</b> window appears.
2	In the <b>Customer Information</b> window, enter customer information.  This window is for administrative purposes only. The system does not use this information.
--End--	

**Procedure 53**  
**Saving the system**

Step	Action
1	To save the new system you created with the IP DECT Configurator, click <b>Apply</b> , and then click <b>Save system</b> .
2	If a message appears instructing you to activate the system, click <b>OK</b> , and go to the last step in this procedure.
3	In the System Control pane in the left of the IP DECT Configurator main window, click <b>Activate/Deactivate/System Status</b> .

The **Activate/Deactivate/System Status** window appears.



4 Click the **Activate all** button.

--End--

**Procedure 54**  
**Enabling or re-enabling the DAPs**

Step	Action
------	--------

1	To enable or re-enable the DAPs, start the DAPs.
---	--

--End--

## DAP manager configuration

The following procedures are described in this section.

- “Restarting DECT Access Points” (page 125)
- “Adding number range” (page 126)
- “Subscribing a DECT handset” (page 126)


### Restarting DECT Access Points

You must restart the DECT Access Points (DAP) following software upgrades.

#### Procedure 55

#### Restarting DECT Access Points

Step	Action
1	Start DAP manager by entering the following URL into an internet browser: localhost/cds  The DAP manager IP DECT page appears.
2	Select <b>Access Points</b> from the menu on the left.  The Access Points page displays information about the DAPs.



DECT Access Points are identified by their Radio Part Number (RPN). In the DAP Manager workspace, the status of the DAPs appear. You can modify the RPN of a DAP by editing the RPN field.

In the DAP manager task area, choose one of the following options:

- Reboot—Select this option to restart a selected DAP.
- Reboot All—Select this option to restart all DAPs in the list.
- Delete—Select this option to remove a DAP from the list.

The DAP takes a few minutes to restart.

- 3 Confirm the DAP is active by checking the status of the device under the **Working** column. Active DAPs have **Yes** in this column.

---

--End--

---

### Adding number range

Add a Number Range.

#### Procedure 56 Adding Number Range

Step	Action
1	Select <b>Add Number Range</b> from the menu on the left.
2	Define DNs for the DECT handsets.  You can also import DNs from a .csv file. For information, see <a href="#">“Add a DN range” (page 158)</a> .
--End--	

### Subscribing a DECT handset

Before you can use a handset (also known as portable telephone, or portable part (PP)), you must subscribe the handset to the system, and ensure that the handset is registered by the DAP manager.

#### Procedure 57 Subscribing a DECT handset

Step	Action
1	Select <b>Subscriptions</b> from the menu on the left.  The <b>Subscriptions</b> page appears.

**DAP Manager INT - System\_1**

**Subscriptions**

Filter: No Filter

Number	Status	PIN	RPN	Multi-Site	Presence	Registration status	Handset type	SW version	Comment
3000	Subscribed		013	No	Present	Registered	4050		Edit
5001	Subscribed		010	No	Unknown	Absent	4070		Edit
5002	Subscribed		010	No	Present	Registered	4027	1.51	Edit
5003	Subscribed		010	No	Present	Registered	4027	1.51	Edit
5004	Free								Edit
5005	Subscribed		010	No	Present	Registered	4065R	89.24.30.31	Edit
5006	Subscribed		010	No	Present	Registered	4060	51.24.15.03	Edit
5007	Subscribed		010	No	Present	Registered	4060	91.24.30.37	Edit
5008	Enabled	3689							Edit
5009	Free								Edit
5010	Subscribed		010	Yes	Present	Registered	4027	1.48	Edit
5025	Subscribed		010	Yes	Present	Registered	4070		Edit

Select a Subscription and click on a task.  
Shift+Click to select a range.

Park : 31174221505508

**Nortel** © 2002-2008

2 Select the required available extension number or numbers.

If the required number is not visible, select another page.  
The page number appears in the top and bottom rows of the subscriptions table.

3 Click **Enable**.

#### ATTENTION

If you plan to create a multiple-site configuration, use the option **Enable for Multi-Site** instead of **Enable**.

The status of the subscription record changes from Free to Enabled and the Personal Identification Number (PIN) appears. The DAP manager generates a PIN when it performs each subscribe operation; the PIN appears only when the subscription status is Enabled.

You can disable or remove subscriptions. For information about subscription management, see [“Subscription management”](#) (page 149).

A DECT handset is required for the remainder of this procedure.

4 Find **System configuration** in the DECT handset menu.

5 Choose **New**, and enter the displayed PIN code.

Sometimes you must enter PARK code first. The PARK code appears on the left at the bottom of the Subscriptions page.

You must enter the PIN within 16 minutes, otherwise the subscription mode terminates for that specific extension number, and you must restart the subscription process from the beginning.

**6** Enter the name and DN of the SIP-DECT system.

The DN appears on the handset display. The status of the subscription record changes from Enabled to Subscribed.

For information, see [“Subscription management” \(page 149\)](#).

---

--End--

---

### SIP Line Gateway configuration

There are no specific SIP DECT configuration requirements for SIP LINE. For information about installing and configuring SIP Line Gateway, see (NN43001-508).

When configuring SIP Line Gateway for use with a SIPL configuration, ensure that you configure the following parameters:

- While enabling the SIP Line Service and configuring the root domain, enter a User agent DN prefix (which is required for UEXT SIPL Configuration) and root domain name that are the same as the values you entered for the SIP DECT domain name [Procedure 48 “Configuring SIP Settings” \(page 117\)](#).
- While Configuring SIP Line gateway node, enter the same domain name as you entered for SIP DECT and SIP Line service, and ensure that SIP LINE Gateway local SIP port corresponds with the Proxy port.

### Configuration of Universal Extension on a Call Server

Universal Extension (UEXT) redirects incoming calls to the DAP. Key 0 corresponds with the DN, configured on the DAP. Key 1 HOT U is the same number with a User agent DN prefix configured for SIP Line.

Use LD 15 to configure station control password length before you configure the UEXT for SIP Line users.

**Table 16**

**LD 11: Configure station control password length**

Prompt	Response	Description
REQ	CHG	
TYPE	FFC	FFC_DATA
CUST	n	n = customer number
SCPL	x	x = the maximum length of the password

Use LD 11 to configure UEXT.

Packages 139, 415, and 417 must be enabled on the Call Server.

If you plan to configure Microsoft Office Communicator for your SIP DECT handset, you must add the required settings to the UEXT block (AST 0; CLS T87A).

**Table 17**  
**LD 11: Add universal extension**

Prompt	Response	Description
REQ	NEW	Add new extension
TYPE	UEXT	Universal Extension
CUST	n	n = customer number
TN	L s c u, for example, 96 0 1 0	where L = virtual superloop, s = shelf, c = card, u = unit
UXTY	SIPL	UEXT subtype
DES	aaaa	Designator. Optionally, enter a description.
SIPU	xxxx	SIP DECT user DN
NDID	xxxx	SIP Line Node ID
SCPW	xxxx	Password configured in DAP Controller (see <a href="#">Procedure 48 "Configuring SIP Settings" (page 117)</a> )
CLS	CFXA	Call Forward All Calls to external DN Allowed -Required for MSMN configuration.
KEY	0 aaa yyyy, for example, 0 SCR 5001  1 HOT U yyyy, for example, 1 HOT U4425001	0 aaa yyyy = Primary UEXT DN: <ul style="list-style-type: none"> <li>aaa = MCN, MCR, SCN, or SCR</li> <li>yyyy = primary DN</li> </ul> 1 hot u yyyy = Target DN: <ul style="list-style-type: none"> <li>yyyy = User Agent DN prefix (configured for SIP Line)+ subscribed DN on DAP</li> </ul>

## Branch Office configuration

Use Branch Office Configuration for a Large Campus network that is split up into various (geographical) segments (branch offices), so that every branch office has its own subnet and DAPs can exchange IP multicast

packets only using routers or switches in the subnet of their local branch office. No IP multicast traffic is allowed between branch offices. In this configuration each branch office behaves as an isolated part of a larger SIP DECT system. Branch Office configuration supports seamless handover within each branch office, but not between sites. Support is unavailable for roaming between branch offices.

To configure Branch Office, see [“Basic \(simple\) SIP DECT configuration with Communication Server 1000 SIP Line Gateway” \(page 111\)](#). Use the information in this section when you require information about Branch Office configuration.

Select a Branch Office configuration.

**Procedure 58**  
**Selecting a system configuration**

Step	Action
1	Perform one of the following steps: If you were referred to this section from <a href="#">Procedure 47 “Configuring System Settings” (page 116)</a> , go to step 3. <b>OR</b> Open the IP DECT Configurator, and click <b>Modify</b> .
2	Select the SIP DECT system that you are running, and click <b>System Configuration</b> .
3	Choose <b>Main Site with Branch Office(s) for System configuration</b> , as shown in the following figure.

**IP-DECT Configurator**

General IP Settings Network Settings **System Configuration** SIP Settings DECT Settings PBX Settings Performance / Email Settings Customer Information

Home New System Modify System Import System Activate / Deactivate / System Status Export System Delete System Save System Exit Default Apply Cancel

System Configuration System 1

System configuration : Main site with Branch Office(s)

Main site with Branch Office(s) :

NOTE: Ensure that all subnets, including the main site, are entered into the list below. DAPs in subnets not included in this list will fail to complete the boot process.

IDX	Subnet	Subnetmask	RPN range	Subnet name	Time offset
001	192.168.32.0	255.255.255.0	010-011	Subnet 1	00:00
002	192.168.31.0	255.255.255.0	015-015	Subnet 2	00:00

Subnet : Subnet mask : RPN range : Subnet name : Time offset :

+0 00

Add Edit Delete Clear

Apply Cancel

Nortel Single System Mode Normal Mode

4

Configure each branch office by entering the following parameters:

- **Subnet** - the first address in the subnet range. For instance, 192.168.32.0.
- **Subnet mask** - mask to specify the subnet boundaries.
- **RPN range** - lowest RPN and highest RPN in this Branch Office.
- **Subnet name** – any name used to identify the Branch Office.
- **Time Offset** - time zone for the current subnet (branch office).

5

Perform one of the following steps:

If you were referred to this section from [Procedure 47 "Configuring System Settings" \(page 116\)](#), click **Apply** and continue configuring the SIP DECT system using [Procedure 48 "Configuring SIP Settings" \(page 117\)](#).

**OR**

Go to step 6.

- 6 Click **Save System** and deactivate the system.
- 7 Ensure that DHCP and TFTP servers are configured properly, so that DAPs can start in all Branch Offices.
- 8 Activate the system and restart all DAPs.
- 9 Start DAP Manager, open Access Points page and ensure that all DAPs are present and working.

---

--End--

---

## Routed Head Quarter configuration

In this configuration, there is more than one network segment in the Head Quarter. The routers in this configuration must forward IP multicast packages. Network components, such as switches and routers, must be correctly configured for VoIP and IP multicast. The network must support IP multicast between all network components used for IP DECT System.

You can edit the following settings:

- **Time to Live (TTL) value**—The Time to Live value is used for the multicast traffic. If the Time to Live for the multicast is set to 1, multicast traffic is not forwarded by a Router. If the Time to Live is greater than 1, multicast packages can be forwarded by the Router, depending on settings in the Router. If the TTL (for the multicast packages) is set to 1, leave this aggregated subnet mask empty. If the TTL (for the multicast packages) is set to a value greater than 1, fill in this aggregated subnet mask to signal to the system which smaller subnets are connected as one subnet using a router supporting IP multicast.
- **Aggregated Subnet mask**—The aggregated subnet mask is the subnet mask for the DAPs to determine the network boundaries for an IP DECT Network in which seamless handover is possible. Use G.711, which covers the network segments connected using routers that support IP multicast.

If there are DAPs outside this aggregated subnet mask, regard the DAP or DAPs as in a branch office. Note that the IP address of the PBX is compared with the IP address or addresses of the DAP or DAPs using this subnet mask. If the IP addresses are in various subnets according to this mask, the DAP or DAPs are supposed to be in a branch office. If the IP addresses are in the same aggregated subnet according to this mask, the system assumes that the IP addresses are in the same subnet.

The term aggregated means that the subnet consists of smaller subnets connected over a router, but according to the subnet mask, all behave as one subnet. This applies to the Routed Head Quarter network solution without branch offices.

Routed Head Quarter configuration implies that various subnets are connected through one or more routers. The subnets in the network are part of one company network.

To create a Routed Head Quarter configuration, you must configure the network components, such as the switches and the routers, for VoIP and IP multicast. Also, the network must support IP multicast between all network components used for the SIP DECT system.

Routed Head Configuration is the same as Simple configuration, but includes one additional step. For information, see [Procedure 46 "Configuring Network Settings" \(page 115\)](#).

## Configure Routed Head Quarter

Choose a system configuration.

Configure Routed Head Quarter.

### Procedure 59 Choosing system configuration

Step	Action
1	If you were referred to this procedure from <a href="#">Procedure 47 "Configuring System Settings" (page 116)</a> , skip to step 3. Open the IP DECT Configurator, and click <b>Modify</b> .
2	Select the <b>SIP DECT</b> system that you are running. Click <b>System Configuration</b> .
3	Choose <b>Routed Head Quarter Configuration</b> for System configuration.
4	Enter a <b>Time To Live Value</b> greater than 1 to have the Router forward multicast packages.
5	Calculate and enter the <b>Aggregated Subnet mask</b> . The Aggregated subnet mask is the subnet mask for the DAPs to determine the network boundaries for a SIP DECT System. The Aggregated subnet mask covers the network segments connected using routers that support IP multicast.

#### Example: DAPs in three subnets:

- 192.168.1.0/24
- 192.168.4.0/24
- 192.168.5.0/24


For this example, enter the Aggregated Subnet Mask 255.255.248.0.

6 Perform one of the following steps:

If you were referred to this procedure from [Procedure 47 “Configuring System Settings” \(page 116\)](#), click **Apply**, and continue configuring the SIP DECT system using [Procedure 48 “Configuring SIP Settings” \(page 117\)](#).

**OR**

Go to step 7.



7 Click **Save System** and deactivate the system.

8 Ensure that DHCP and TFTP servers are configured properly, so that DAPs can start in all subnets.

9 Activate the system and restart all DAPs.

10 Start DAP Manager, open Access Points page and ensure that all DAPs are present and working.

--End--

## Routed Head Quarter Configuration with Branch Office

Routed Head Quarter Configuration with Branch Office makes it possible to create Routed Head Quarter configuration in one of the branch offices. Within the Branch Office with Routed Head Quarter DAPs belong to various subnets and behave as a single site of one SIP DECT system with the full support of seamless handover. As for the whole SIP DECT system, each Branch Office (including the Branch Office with Routed Head Quarter) behaves as isolated site of that SIP DECT system. Branch Office configuration supports seamless handover within each isolated site (branch office), but not between sites. Support is unavailable for roaming between branch offices.

Configure Routed Head Quarter with Branch Office(s)

### Procedure 60 Choosing system configuration

Step	Action
1	Perform one of the following steps:  If you were referred to this procedure from <a href="#">Procedure 47 "Configuring System Settings" (page 116)</a> , go to step 3.  <b>OR</b>  Open the IP DECT Configurator, and click <b>Modify</b>
2	Select the SIP DECT system that you are running, and click <b>System Configuration</b> .
3	Choose <b>Routed Head Quarter with Branch Office(s)</b> for System configuration, as shown in the following figure.
4	Enter a <b>Time To Live Value</b> greater than 1 to have the Router forward multicast packages, calculate and enter the <b>Aggregated Subnet mask</b> corresponding to the subnets of Routed Head Quarter (see <a href="#">"Routed Head Quarter configuration" (page 132)</a> ).  Ensure that the aggregated subnet mask for RHQ doesn't cover the subnets used in the branch offices
5	Configure each branch office by entering the following parameters: <ul style="list-style-type: none"><li>• <b>Subnet</b> - the first address in the subnet range, for instance 192.168.31.0.</li><li>• <b>Subnet mask</b> - mask to specify the subnet boundaries</li><li>• <b>RPN range</b> - lowest RPN and highest RPN in this Branch Office.</li></ul>

- **Subnet name** – any name used to identify the Branch Office.
  - **Time Offset** - time zone for the current subnet (branch office).
- 6 Perform one of the following steps:
- If you were referred to this procedure in [Procedure 47 “Configuring System Settings” \(page 116\)](#), click Apply and continue configuring the SIP DECT system with [Procedure 48 “Configuring SIP Settings” \(page 117\)](#).
- OR**
- Go to step 7.
- 7 Click **Save System** and deactivate the system.
- 8 Ensure DHCP and TFTP servers are configured properly, so that DAPs can start in all Branch Offices.
- 9 Activate the system and restart all DAPs.
- 10 Start DAP Manager, open Access Points page and ensure all DAPs are present and working.

---

--End--

---

## Multiple-site mobility network configuration

A multiple-site mobility network makes it possible to use portable DECT handsets on various MCDN nodes with installed SIP DECT systems. It is possible for only one subscription to be in the handset for all SIP DECT systems when you use SARI. In this case SARI on all SIP DECT systems must be the same.

### ATTENTION

When the handset is on a remote MCDN node, the ring back tone is given to a party calling the local DN even if the handset is busy.

### ATTENTION

Before starting multi-site Configuration, perform the following steps:

- Configure SIP Line and provide the required configuration for SIP DECT on Call Server (UEXT blocks) on each MCDN node selected for MSMN.
- Create any type of SIP DECT configuration on each MCDN node selected for MSMN.

- Connect the systems configured for MSMN through trunks. Configure the uniform (UDP) or coordinated (CDP) numbering plan.

**Note:** MSMN configuration requires Multi-site Mobility Networking package 370 enabled. DECT Visitor User on SIP DECT consumes one SIPN license (NORTEL SIP LINES) from a pool of SIPN licenses that are available to all SIP clients and one DECT (wireless) Visitor license from a pool that are available to DECT clients (DMC/SIP DECT).

The sequence of actions required to configure this feature are as follows:

- [“SIP DECT Configuration” \(page 137\)](#)
- [“Call Server Configuration” \(page 137\)](#)
- [“Subscribing DECT handsets and UEXT configuration on the home site” \(page 137\)](#)
- [“Importing and exporting subscriptions” \(page 138\)](#)
- [“Configuring Universal Extension on remote sites” \(page 139\)](#)
- [“MWI for DECT visitors” \(page 140\)](#)

## SIP DECT Configuration

You can configure any kind of SIP DECT configuration on each MCDN site: Basic (simple), Routed Head Quarter, Branch Office or Routed Head Quarter with Branch Offices. Attention:

### ATTENTION

Configuring SIP DECT systems used for MSMN ensure that you use the same SARI on all of them. For more information, see [Procedure 49 “Configuring DECT Settings” \(page 119\)](#).

## Call Server Configuration

MSDN configuration requirements:

1. Uniform (UDP) or coordinated (CDP) numbering plan must be configured on all sites.
2. All sites must be connected through trunks, Private network Identifier (PNI) must be the same for all systems.
3. SPRE and FFC must be enabled, Remote call forward (FFC RCFA, RCFD, RCFV) must be configured.

## Subscribing DECT handsets and UEXT configuration on the home site

You must subscribe your DECT handset for MSMN configuration, using your DAP Manager.

**ATTENTION**

A DECT handset for MSMN must be subscribed using Enable for Multi-site option in DAP Manager. For more information, see [“Subscribing a DECT handset” \(page 126\)](#).

As for usual SIP DECT set you must also configure a UEXT block on call server.

**ATTENTION**

When you configure a UEXT block for an MSMN DECT set, enable Call Forward All Calls to external DN Allowed feature (CLS CFXA).

**Importing and exporting subscriptions**

Use the procedures in this section to export subscriptions from the home site and import subscriptions on remote sites.

**Procedure 61**  
**Exporting subscriptions in a file**

Step	Action
1	In the navigation menu, click <b>Pack Up &amp; Go</b> .
2	Select <b>Export (multi-site)</b> from the menu.
3	Move the required subscriptions from the Selection list to the Export list, using the buttons > (for one selected subscription) or >> (for all subscriptions).
4	Click <b>OK</b> , and then <b>Save</b> in the File Download Page.
5	Enter the name of the file with exported subscriptions, navigate to the folder in which to store the file, and click <b>Save</b> .
--End--	

**Procedure 62**  
**Importing subscriptions on remote systems**

Step	Action
1	Open localhost/cds in your Internet Browser (on DAP controller PC). The <b>DAP manager IP DECT</b> page appears.
2	In the navigation menu, click <b>Pack Up &amp; Go</b> .
3	Click <b>Import</b> .
4	Choose the appropriate file in the folder that stores files with subscriptions

5 Click **OK**.

--End--

### Configuring Universal Extension on remote sites

Universal Extension (UEXT) redirects incoming calls to the DAP. Key 0 corresponds with the DN, configured on the DAP. Key 1 HOT U is the same number with a User agent DN prefix configured for SIP Line.

Use LD 11 to configure UEXT.

Packages 139, 415, and 417 must be enabled on the Call Server.

Package 370 and DECT Visitor licenses are required for adding DECT visitors in MSMN configuration.

**Table 18**  
**LD 11: Add universal extension**

Prompt	Response	Description
REQ	NEW	Add new extension
TYPE	UEXT	Universal Extension
CUST	n	n = customer number
TN	L s c u, for example, 96 0 1 0	where L = virtual superloop, s = shelf, c = card, u = unit
UXTY	SIPL	UEXT subtype
DES	aaaa	Designator. Optionally, enter a description.
SIPU	xxxx	SIP DECT user DN
NDID	xxxx	SIP Line Node ID of the current section
SCPW	xxxx	password configured in DAP Controller on the current system ( <a href="#">Procedure 48 "Configuring SIP Settings" (page 117)</a> ).
VSIT	yes	Vistor - enable MSMN support for SIP DECT user
HMDN	xxxx	HoMe Directory Number sets the DN as a valid MCDN network DN (for example, DSC+DN or AC+LOC+DN) HMDN available if VSIT = YES
CLS	CFXA	Call Forward All Calls to external DN Allowed -Required for MSMN configuration

Prompt	Response	Description
KEY	0 aaa yyyy, for example, 0 SCR 5010  1 HOT U yyyy, for example, 1 HOT U 4425010	0 aaa yyyy = Primary UEXT DN: <ul style="list-style-type: none"> <li>aaa = MCN, MCR, SCN, or SCR</li> <li>yyyy = primary DN</li> </ul> 1 hot u yyyy = Target DN: <ul style="list-style-type: none"> <li>yyyy = User Agent DN prefix (configured for SIP Line)+ subscribed DN on DAP</li> </ul>

### MWI for DECT visitors

The MSMN feature makes it possible receiving the Message Waiting Indication (MWI) and voicemail messages at the visited site.

Package 175 is required for sending MWI in MSMN configuration.

To configure MWI for DECT Visitors perform the following steps:

- Configure CDN (for example, 4500) for Call pilot on the home site. Create a message box for DECT user in Call Pilot and enter the extension DNs:
  - 1) local DN, for example, 5001
  - 2) LCS + DN or HLOC+DN, for example, 7385001 - local steering code or home location code + DN
  - 3) DSC + DN or LOC + DN, for example, 5555001 - distant steering code of the remote site 1 or location code to remote site 1 + DN
  - 4) DSC + DN or LOC + DN, for example, 8955001 - distant steering code of the remote site 2 or location code to remote site 2 + DN
- Configure Automatic Call Distribution (ACD) and so on for each remote site with the following configuration:
  - ACDN XXXX, for example, 4700
  - MWC yes
  - NCFW DSC+CDN of the home system or AC+LOC+ CDN of the home system, for example, 7384500
- Enter the forward DN and enable required class of service for UEXT block of DECT visitor:
  - FDN XXXX (ACDN, configured in the above step), for example, 4700
  - cls FNA FBA MWA

**Note:** Ensure that message waiting indication is enabled in Customer Data Block (LD 15): IMS must be set to yes, MCI must be present in the OPT prompt (FTR\_DATA).

## Operating the MSMN feature

To activate the MSMN feature, perform the following steps:

- Turn the handset on within the coverage range of a visited DECT system (Remote Call Forward is activated).

**OR**

Enter the coverage range of a visited DECT system from another DECT system with the handset turned on (Remote Call Forward is activated).

To deactivate the MSMN feature, perform the following steps:

- Turn the handset off within coverage range of the visited DECT system.

**OR**

Turn the handset on at the home DECT system. (Any CFW related to the handset is cancelled.)

**OR**

Enter the coverage range of the home DECT system with the handset on. (Any CFW related to the handset is cancelled.)

## Multiple Gatekeepers Configuration

Multiple Gatekeepers is a special configuration option that allows using SIP DECT in Survivable Branch Office configuration (CS1000) or in Load Balancing configuration.

**Note:** The Multiple Gatekeepers option can be used for Survivable Branch Office configuration (CS1000) or for Load Balancing configuration, but not for both of them at the same time.

### Survivable Branch Office Configuration (Communication Server 1000)

To configure SIP DECT for Survivable Branch Office Configuration, you must enable Multiple Gatekeepers option in the IP DECT Configurator. One SIP Proxy server must be the Main Office SIP Line Gateway; the second SIP Proxy server is the Branch Office SIP Line Gateway. The SIP Line Gateways in Main Office and Branch Office must have the same configuration values for domain name for SIP Line and the user name and password for each SIP DECT user.

The primary proxy in Communication Server 1000 Survivable Branch Office is configured to the Main Office SLG IP address to reduce registration time in normal operation mode when the Main Office is operating correctly. The primary proxy is the first proxy in the list in the configuration file and in the Gatekeeper Overview window.

Use [Procedure 63 “Configuring multiple SIP proxies” \(page 142\)](#) to configure multiple SIP proxies using the IP DECT Configurator (IP settings). In the example in the following procedure, the Branch Office SIP Line Gateway IP address 192.168.32.135 is added as an Alternate Proxy for SIP DECT.

**Procedure 63**  
**Configuring multiple SIP proxies**

Step	Action
1	On the Settings pane, click <b>IP DECT Configurator IP Settings</b> . The <b>IP Settings</b> page appears, as shown in <a href="#">Figure 37 “IP DECT Configurator IP Settings window” (page 142)</a> .

**Figure 37**  
**IP DECT Configurator IP Settings window**

- 2 Select **Multiple gatekeepers**.
- 3 In the **Proxy IP address** field, enter a value for proxy IP address.
- 4 In the **Proxy port** field, enter a value for proxy port.

**Note:** The proxy port value must correspond to the proxy port value configured in SIP Line.

**5 Click Add.**

**Note:** You must save the system and restart the DAPs to activate the new configuration.

---

--End--

---

**Load Balancing for SIP DECT high capacity**

Consider the following factors when you plan the interaction between a Communication Server 1000 and SIP DECT and when the anticipated number of DECT handsets in SIP DECT systems is large (greater than 200).

- SIP Line server capacity: The SIP Line capacity calculation varies based on the Communication Server 1000 hardware type and the deployment type.
  - SIP Line requires a separate CP PM or COTS server. For more information about the CP PM platform, see *Co-resident Call Server and Signaling Server Fundamentals* (NN43001-509). For more information about COTS platforms, see *Linux Platform Base and Applications Installation and Commissioning* (NN43001-315).
  - For information about the estimated maximum number of supported SIP Line users (SIP DECT handsets) on SIP Line servers, see *Communication Server 1000E Planning and Engineering* (NN43041-220).
  - The software limit for the number of SIP Line users on one SIP Line server is 1800; a traffic capacity limit also exists. For information about calculating the number of SIP Line servers, see ["Determine the number of SIP Line servers" \(page 143\)](#) .
- SIP DECT system capacity: A SIP DECT system can support approximately 6000 SIP DECT handsets on a single system (256 DAPs with 25 subscriptions for each DAP).
- Determine the number of SIP Line servers.
- SIP DECT load balancing configuration: Communication Server 1000 SIP Lines Node does not support load balancing of SIP user registration between a Leader and Followers in the same node. An administrator must add more SIP Line Nodes on the same Communication Server 1000 system to maintain more SIP users than are allowed by a single SIP Line server.

SIP DECT system supports load balancing of DECT handsets between SIP Proxies based on a DN prefix. An administrator must calculate the overall number of SIP DECT handsets in the system and determine DN prefixes for every SIP Line Node so that every SIP Line Node (DNR

Proxy record) does not have more SIP DECT users assigned than is supported based on the number of SIP Line servers.

SIP DECT configuration is adjusted with the list of SIP Line Node IPs and DN prefixes assigned. You must select the Multiple Gatekeepers option to perform load balancing. [Figure 38 "Load balancing configuration" \(page 144\)](#) shows an example of load balancing configuration on a SIP DECT system with three SIP Line nodes. In this example

- The primary proxy for DNs starting with 50 is 192.168.32.135.
- The primary proxy for DNs starting with 51 is 192.168.32.172.
- The primary proxy for all other DNs is 192.168.32.126

**Figure 38**  
**Load balancing configuration**

The screenshot displays the 'IP Settings' configuration window for a SIP DECT system. The 'Advanced IP Settings' section is expanded, showing the 'Multiple gatekeepers' option selected. The 'Gatekeeper overview' table lists the following configurations:

ID	IP Address	Port	DN Prefix
01	192.168.32.135	5060	50, SIP
02	192.168.32.172	5060	51, SIP
03	192.168.32.126	5060	

- Configuration specifics, behavior, and limitations of SIP DECT load balancing configuration:
  - SIP Line UEXT is configured with Node ID (NDID prompt in LD 11). This configuration parameter is no longer used for SIP Line trunk designation.
  - A set of SIP Line trunks must be assigned to every SIP Line Node.
  - SIP DECT uses an alternative proxy selection approach; a SIP DECT handset can register through different SIP Line nodes if the primary node is down. A primary proxy is assigned by DNR prefix

to a DECT handset only for the first selection. If this proxy (SIP Line Node) fails, then the DAP selects the next Proxy from the list regardless of the DNR prefix. SIP DECT registrations are not strictly bound to proxies by DNR prefixes.



---

# System administration

---

This chapter contains information about the administration of the SIP DECT system.

## Navigation

- [“DAP manager overview” \(page 147\)](#)
- [“Subscription management” \(page 149\)](#)
- [“DAP management” \(page 156\)](#)
- [“Add a DN range” \(page 158\)](#)
- [“System backup” \(page 160\)](#)
- [“Subscription export and import” \(page 161\)](#)
- [“DAP reboot history” \(page 164\)](#)
- [“System archive” \(page 165\)](#)
- [“Handset firmware update” \(page 166\)](#)
- [“Central directory access tool” \(page 170\)](#)

## DAP manager overview

This section provides an overview of the DAP manager application for SIP DECT, and describes the DAP manager interface. DAP manager is a Web-based application.

To start DAP manager, open Internet Explorer and enter the following URL in the address field: localhost/cds. The DAP Manager appears.

**DAP Manager INT - System\_1**

**Subscriptions**

Filter:

Number	Status	PIN	RPN	Multi-Site	Presence	Registration status	Handset type	SW version	Comment
3000	Subscribed		013	No	Present	Registered	4050		Edit
5001	Subscribed		010	No	Unknown	Absent	4070		Edit
5002	Subscribed		010	No	Present	Registered	4027	1.51	Edit
5003	Subscribed		010	No	Present	Registered	4027	1.51	Edit
5004	Free								Edit
5005	Subscribed		010	No	Present	Registered	4065R	89.24.30.31	Edit
5006	Subscribed		010	No	Present	Registered	4060	51.24.15.03	Edit
5007	Subscribed		010	No	Present	Registered	4060	91.24.30.37	Edit
5008	Enabled	3689							Edit
5009	Free								Edit
5010	Subscribed		010	Yes	Present	Registered	4027	1.48	Edit
5025	Subscribed		010	Yes	Present	Registered	4070		Edit

Select a Subscription and click on a task.  
Shift+Click to select a range.

Park : 31174221505508

**Nortel** © 2002-2008

This DAP manager page is divided into four main panels.

## 1. Main

### — Subscriptions

Use this section for subscription management.

### — Access points

Use this section to restart DECT Access points and view the configuration data. The numbers between brackets indicate the number of present or working Access Points.

### — Add number range

Use this section to enter the available extension numbers.

### — Backup (export)

Use this section to create a backup of your system.

### — History

Use this section to view history of the DECT Access Points status.

### — Pack Up & Go

Use this section to prepare subscription data for use in another system and to export multi-site subscriptions.

## 2. Task list

The Task list shows the available tasks for a feature. For example, the feature Subscriptions has the tasks Enable, Disable, Terminate, and Delete Number.

3. Information area

Notes or additional information appear in this area.

4. Work space

You can enter or view data in the Work area.

## Subscription management

This section describes how to subscribe handsets. Before you can use a handset, you must register the handset and subscribe it to the system.

### Subscribing a handset

#### Prerequisites

- A Directory Number (DN) must be available and free. For information about making DNs available on the system, see [“Add a DN range” \(page 158\)](#).
- You also must configure the Communication Server 1000 (CS 1000) system to which the SIP DECT system is connected.

For information, see [“Call Server Configuration” \(page 137\)](#).

#### Procedure 64

##### Subscribing a handset

Step	Action
1	Open Internet Explorer and enter the following URL in the address field: <b>localhost/cds</b> .  The DAP manager IP DECT page appears.
2	Select <b>Subscriptions</b> from the menu on the left in the DAP manager IP DECT page.  The Subscriptions page appears.
3	Select the required available extension number from the list on the Subscription page, for example, select 5001.  You can subscribe the handset to the extension number only if the status of the handset is free.  If the number you require does not appear, select another page. The page number appears in the top and bottom rows of the subscriptions table.
4	Click <b>Enable</b> .

The status of the subscription record changes from Free to Enabled and the Personal Identification Number (PIN) appears. The DAP manager generates a PIN when it performs each subscribe operation; the PIN appears only when the subscription status is Enabled.

You can enable up to 10 extension numbers for subscription at the same time.

**ATTENTION**

If you plan to create a multi-site configuration, use the option **Enable for multi-site** instead of **Enable**.

- 5 Using the handset you are subscribing, Access the **System configuration** menu, and choose **New**.

For information about accessing this menu, and other handset configuration information, see the handset User Guide.

- 6 If the handset requests PARK code, enter the **PARK** code.

You can find the PARK code on the left at the bottom of the Subscriptions page. A PARK code is required only if overlapping DECT systems exist in your location; if only one DECT system is available in your location, you need not use a PARK code.

- 7 Enter the **displayed PIN code**.

You must enter the PIN within 16 minutes; otherwise, the system terminates the subscription mode for that extension number, and you must start the subscription process from the beginning.

- 8 Enter the **name of your SIP DECT system** and the **DN**.

You can find the name of the system and the DN on the handset display. The status of the configuring subscription record changes from Enabled to Subscribed.

---

--End--

---

## Edit a subscription RPN

Change the DAP RPN to which the handset is subscribed.

### Procedure 65

#### Editing a subscription RPN

Step	Action
1	Open Internet Explorer and enter the following URL in the address field: <b>localhost/cds</b> .  The DAP manager IP DECT page appears.
2	Select Subscriptions from the menu on the left in the DAP manager IP DECT page.

- The Subscriptions page appears.
- 3 Select the subscription to edit.
  - 4 Click **Edit**.
  - 5 Enter the **RPN** of the required installed DAP.
  - 6 Click **OK**.
- The maximum number of subscription records for every DAP is 25.

---

--End--

---

## Disable a subscription

Disable a subscription.

When you disable a subscription, the system attempts to remove the subscription data from the handset. If the subscription data is removed successfully, the DN is available for use by another handset, and you can register the handset again.

The handset cannot make and receive calls while the subscription is disabled.

### Procedure 66 Disabling a subscription

Step	Action
1	Open Internet Explorer and enter the following URL in the address field: <b>localhost/cds</b> .  The DAP manager IP DECT page appears.
2	Select <b>Subscriptions</b> .  The Subscriptions page appears.
3	Select the DN to delete.  If the DN you plan to disable is not visible, go to subsequent pages until you find it. The page number appears in the top and bottom rows of the subscriptions table.
4	Click <b>Disable</b> .  The status of the configuring subscription record changes from Subscribed to Black Listed. When the SIP DECT system manages to delete the subscription record from the handset, the status changes to Free.

---

--End--

---

## Removing a subscription

Remove subscription data from the system only. This procedure does not clear the subscription from the handset.

### ATTENTION

Nortel recommends that you use the following procedure only if a handset was lost or damaged beyond repair.

#### Procedure 67

#### Removing a subscription from the system

Step	Action
1	Open Internet Explorer and enter the following URL in the address field: <b>localhost/cds</b> .  The DAP manager IP DECT page appears.
2	Select <b>Subscriptions</b> .  The Subscriptions page appears.
3	Select the DN to disable.  If the DN you plan to disable is not visible, go to subsequent pages until you find it. The page number appears in the top and bottom rows of the subscriptions table.
4	Click <b>Terminate</b> .  The status of the configuring subscription record changes from Subscribed to Free.
--End--	

## Deleting a number

Delete a number from the added number range.

You can delete a number only if no handset is subscribed to that number and the status of that number is free.

#### Procedure 68

#### Deleting a number

Step	Action
1	Open Internet Explorer and enter the following URL in the address field: <b>localhost/cds</b> .  The DAP manager IP DECT page appears.
2	Select <b>Subscriptions</b> .  The Subscriptions page appears.

- 3 Select the DN to disable.  
If the DN you plan to disable is not visible, go to subsequent pages until you find it. The page number appears in the top and bottom rows of the subscriptions table.
- 4 Click **Delete**.

---

--End--

---

### Use the filter

Use a filter to display certain numbers or numbers with certain characteristics.

#### Procedure 69 Using the DNR filter

- | Step | Action   |
|------|--|
| 1    | Open the <b>DAP manager IP DECT</b> page.  |
| 2    | Select <b>Subscriptions</b> .  |
| 3    | Select the <b>Use DNR filter</b> check box at the top of the Subscriptions page. |

The Filters page appears.

**DAP Manager INT - System\_1**

**Subscriptions**

Filter: **DNR filter** (selected)  
 From:  To:   
☒ Exact match ☐ Starting with  
 OK

Number	Status	Presence	Registration status	Handset type	SW version	Comment
3000		Present	Registered	4050		Edit
5001	Subscribed	Unknown	Absent	4070		Edit
5002	Subscribed	Present	Registered	4027	1.51	Edit
5003	Subscribed	Present	Registered	4027	1.51	Edit
5004	Free					Edit
5005	Subscribed	Present	Registered	4065R	89.24.30.31	Edit
5006	Subscribed	Present	Registered	4060	51.24.15.03	Edit
5007	Subscribed	Present	Registered	4060	91.24.30.37	Edit
5008	Enabled					Edit
5009	Free					Edit
5010	Subscribed	Present	Registered	4027	1.48	Edit
5025	Subscribed	Present	Registered	4070		Edit

Select a Subscription and click on a task.  
Shift+Click to select a range.

Park : 31174221505508

**Nortel** © 2002-2008

- 4 Click the **Filter** menu, and choose the required filter type. For an explanation of the various filter types, see [Table 19 "Filter types" \(page 154\)](#).
- 5 To disable the Filter, click the Filter and select No Filter from the list.

---

--End--

---

**Table 19**  
**Filter types**

Filter type	Description
DNR filter	Use the DNR filter if a list of subscriptions is long and it is difficult to find certain extension numbers or DNRs. Also, use the DNR filter to look at only a part of the list of extension numbers or DNRs. In the case of an Exact match, enter the number range in the To field and in the From field. In the case of a Starting with, enter the first digit or digits in the From field. Select the option that applies--either Exact match or Starting with--and click OK.
RPN filter	Use the RPN filter to look at the subscription records on the specific DAP. To activate the filter select the required RPN.
Subscriptions status filter	Use the Subscriptions status filter to look at the subscription records with some specific status (for example, free, enable, subscribed, black listed). To activate the filter select the required status.
Presence status filter	Use the Presence status filter to look at the subscription records with some specific status (for example, unknown, present, absent). To activate the filter select the required status.
Registration status filter	Use the Registration status filter to look at the subscription records with some specific status (for example, registered, absent). To activate the filter select the required status.
Handset type filter	Use the Handset type status filter to look at the records subscribed on some specific handset type (for example, 4027, 4070, 4075). To activate the filter select the required handset type.

### Handset status

The Subscriptions window in the DAP manager IP DECT shows three columns indicating the status of a handset.

- **Status**

This shows the status of the handset subscription in the DECT system. If no handset is subscribed to the extension number, the status is set to Free. Free means that this number is available for handset subscription.

If the extension number is activated for subscription, the status is changed to Enabled and you must follow the procedure to subscribe the handset.

If a handset is subscribed to the number, the status is changed to Subscribed.

If the subscription is disabled, the status is changed to Black Listed. Black Listed means the subscription is deleted from the handset and then the status is set to Free.

- Presence status

This shows the presence status of the handset in the DECT system. If the SIP DECT system detects that the handset is no longer present, the status changes from Present to Absent.

The status changes to absent if one of the following cases occurs.

- The handset is switched off.
- The handset is placed in the charger in disconnected charging mode (only for 4027, 4070, and 4075 Nortel DECT handsets).
- The handset is out of reach or switched off. The system detects that the handset is no longer reachable and the status automatically changes to absent. When the presence status of the handset is absent, the software version in the column SW version can still appear, but it is not relevant until the handset is present again.

The Presence status function and timing depend on custom system settings. If Presence status is enabled in the SIP DECT system, it takes 15 to 60 minutes before the system detects that the handset is no longer reachable.

- Registration status

The Registration status indicates the status of the handset in the SIP DECT system. The status is Registered or Absent.

- If the Registration status is Registered, the handset is registered in the SIP DECT system and can make calls.
- If the Registration status is Absent, the handset is not registered in the SIP DECT system and cannot be used to make calls.

- Handset Type and SW Version

This shows the type or model of the handset subscribed to the system and the version of software installed on the handset.

**ATTENTION**

The system loses the information about handset types and software versions subscribed on a DAP when the DAP restarts. To restore this information, turn off and on the handsets subscribed to the restarted DAP or restart all DAPs using option Reboot all in DAP Manager. For information, see [“Restart all DAPs” \(page 157\)](#).

## DAP management


Manage DECT Access Points (DAP).

### Changing a DAP Radio Part Number

Change the unique Radio Part Number (RPN) of a DECT Access Point (DAP) and manually configure radio synchronization. Each DAP attempts to synchronize to the DAP with the lowest RPN.

#### Procedure 70 Changing an RPN

- | Step | Action   |
|------|--|
| 1    | Open Internet Explorer and enter the following URL in the address field: <b>localhost/cds</b> .<br>The DAP manager IP DECT page appears. |
| 2    | Click <b>Access points</b> .<br>The DECT Access Points page appears.   |



- |   |   |
|---|---|
| 3 | Select the DAP to edit.   |
| 4 | Click <b>Edit</b> .   |
| 5 | Enter the new <b>RPN</b> .<br>The RPN must be a hexadecimal two-digit number in the range 000 to 00F. |
| 6 | Click <b>OK</b> .<br>Wait until DAP restarts and starts working.                                      |

--End--

## Restarting a DAP

Restart a DAP. This can be required if you are upgrading software, or if a DAP is not functioning properly.

### Procedure 71 Restarting a DAP

Step	Action
1	Open Internet Explorer and enter the following URL in the address field: <b>localhost/cds</b> . The DAP manager IP DECT page appears.
2	Click <b>Access points</b> . The DECT Access Points page appears.
3	Select the DAP to restart.
4	Click <b>Reboot</b> . The DAP restarts. It takes several minutes for the DAP to begin working again after it restarts.

#### ATTENTION

If you use Reboot to restart a DAP, information about types and software versions of subscribed handsets is lost, and is restored after several hours. You can restore this information immediately using either of the following methods:

- Turn the handsets subscribed to the restarted DAP off, and then on again.
- Restart all DAPs using the option "Reboot all" in DAP Manager. For information, see ["Restart all DAPs" \(page 157\)](#).

---

--End--

---

## Restart all DAPs

Restart all the DAPs in a system. This can be required if you are upgrading software, or if the DAPs are not functioning properly.

### Procedure 72 Restarting all the DAPs in a system

Step	Action
1	Open Internet Explorer and enter the following URL in the address field: <b>localhost/cds</b> . The DAP manager IP DECT page appears.
2	Click <b>Access points</b> . The DECT Access Points page appears.

- 3 Click **Reboot All**.

---

--End--

---

## Deleting a DAP

Remove a DAP that is damaged beyond repair.

### Procedure 73 Deleting a DAP

Step	Action
1	Open Internet Explorer and enter the following URL in the address field: <b>localhost/cds</b> . The DAP manager IP DECT page appears.
2	Select <b>Subscriptions</b> from the menu on the left in the DAP manager IP DECT page. The Subscriptions page appears.
3	Click <b>Access points</b> .
4	Select the DAP to delete.
5	Click <b>Delete</b> .
<hr/> <p>--End--</p> <hr/>	

## Add a DN range

Assign DN range.

### Procedure 74 Assigning a DN range manually

Step	Action
1	Open Internet Explorer and enter the following URL in the address field: <b>localhost/cds</b> . The <b>DAP manager IP DECT</b> page appears.
2	Click <b>Add Number Range</b> . The Add number range page appears.

- 3 In the **From** field, enter the first number in the range.  
If you add a range consisting of one number only, proceed to step 5.
- 4 In the **To** field, enter the last number in the range.
- 5 Click **OK**.

---

--End--

---

## Importing a DN range from a .csv file

### Procedure 75

#### Importing a DN range from a .csv file

Step	Action
1	Click <b>Browse</b> . A dialog appears.
2	Browse to the .csv file that contains the extension numbers (phone book).
3	Click <b>OK</b> . The file contents is imported.
4	Click the Subscriptions menu to verify that the extension numbers imported properly.

---


--End--

---


Import a DN range from a .csv file.

Two types of .csv files are supported:

- A plain .csv file. The most simple file can be a simple text file stored as CS file. Each extension number must be preceded by two commas (,,) to indicate two empty fields.



- A Central Directory .csv file. When you use the Central Directory Access tool with an .xls file, you can convert this xls file to .csv format by using Microsoft Office Excel.



## System backup

Nortel recommends that you back up the SIP DECT system whenever you make changes to the system configuration.

### Procedure 76 Backing up a system

Step	Action
1	Open Internet Explorer, and enter the following URL in the address field: <b>localhost/cds</b> . The DAP manager IP DECT page appears.
2	Click <b>Backup</b> The File Download page appears.
3	Click <b>Save</b> .
4	Select the folder in which to store the backup file.
5	Enter a name for the file.
6	Click <b>Save</b> . The file is saved to the selected location.
7	To restore the system, see <a href="#">“Import a system” (page 191)</a> .
--End--	

## Subscription export and import

Perform the procedures in this section to transfer subscriptions between SIP DECT systems. You can import and export subscriptions on individual SIP DECT systems, and on multi-site SIP DECT systems. In both cases, the export procedure creates an xml file that you then import on the target system. The system remains operational during the export procedure.

### Export subscriptions

#### Prerequisites

- The PARI (and the SARI for multi-site subscriptions) of the host system must be different from the PARI (and the SARI) in the target system.
- The handsets to be subscribed must be within reach of the host radio signals.

#### ATTENTION


You cannot prepare a subscription using the SARI of the current system. To export subscriptions with the SARI of the current system, you must subscribe a handset enabled for multi-site in the **main menu > subscriptions** page. For information, see [“Multiple-site mobility network configuration” \(page 136\)](#).

#### Procedure 77 Exporting subscriptions

Step	Action
1	Open Internet Explorer, and enter the following URL in the address field: <b>localhost/cds</b> .

The DAP manager IP DECT page appears.

- 2 Click **Pack Up & Go**.



- 3 If you are exporting multi-site subscriptions, select **Multi-site subscriptions**.
- 4 Enter the **PARI** of the remote system.
- 5 If you are exporting multi-site subscriptions, enter the **SARI** of the remote system.
- 6 Click **OK**.
- 7 Click **Add Number Range**.
- The **Add Number Range** page appears.
- 8 In the **From** field, enter the first number in the range of DNs to which you want to export subscription data.
- If you are exporting data for one DN only, proceed to step 16.
- 9 In the **To** field, enter the last number in the range.
- 10 Click **OK**.
- 11 Select the required available extension number from the list on the Subscription page, for example, select 5001.
- If the number you require does not show, select another page. The page number appears in the top and bottom rows of the subscriptions table.

- 12 Click **Enable**  
**OR**  
Click **Enable for multi-site**, if you are exporting multi-site subscriptions.  
  
The status of the configuring subscription record changes from Free to Enabled and the Personal Identification Number (PIN) appears. The DAP manager generates a PIN when it performs each subscribe operation; the PIN appears only when the subscription status is Enabled.
- 13 Using the handset you are subscribing, access the **System configuration** menu, and choose **New system**.  
  
For information about accessing this menu, and other handset configuration information, see the handset User Guide.
- 14 If the handset requests a Portable Access Rights Key (PARK) code, enter the **PARK** code.  
  
You can find the PARK code on the left at the bottom of the page.  
  
A PARK code is required only if there are overlapping DECT systems in your location; if only one DECT system is available in your location, a PARK code is not required.
- 15 Enter the **displayed PIN code**.  
  
You must enter the PIN within 16 minutes, otherwise the system terminates the subscription mode for that extension number, and you must begin the subscription process from the beginning.
- 16 Enter the **name of the target SIP DECT system** and the **DN**.  
  
You can find the name of the system and the DN on the handset display. The status of the configuring subscription record changes from "Enabled" to "Subscribed".
- 17 Click **Export (Prepared)**.  
  
The Export page appears.
- 18 Navigate to the folder where you want to store the file.
- 19 In the **Name** field, enter a name for the new file.
- 20 Click **OK**.
- 21 Click **Clear Host**.
- 22 Click **Back to Main**.

---

--End--

---

## Import subscriptions

Prerequisites:

- All portables must be subscribed.
- For multi-site subscriptions, all systems must have the same SARI.

### Procedure 78 Importing subscriptions

Step	Action
1	Open Internet Explorer and enter the following URL in the address field: <b>localhost/cds</b> . The <b>DAP manager IP DECT</b> page appears.
2	Click <b>Pack Up &amp; Go</b> .
3	Click <b>Import</b> . The <b>Import</b> page appears.
4	Navigate to the folder where the file to be imported is stored.
5	Select the file to be imported.
6	Click <b>OK</b> .
--End--	

You must also configure the CS 1000 system to which the SIP DECT system is connected. For information, see [“Call Server Configuration” \(page 137\)](#).

## DAP reboot history

Review the log of DAP restarts. The information available includes data that is not readable; to access unreadable data, contact the Nortel help desk.

### Procedure 79 Reviewing the DAP reboot history

Step	Action
1	Open Internet Explorer and enter the following URL in the address field: <b>localhost/cds</b> . The <b>DAP manager IP DECT</b> page appears.
2	Click <b>History</b> .

The **DAP Reboot History** page appears.


--End--

## System archive

Use the procedure in this section to create an archive file containing various system settings, third line maintenance data, and performance data. The Nortel help desk can request this information if you experience certain types of problems with your SIP DECT system.

### Procedure 80 Creating a system archive

- | Step | Action  |
|------|---|
| 1    | Open Internet Explorer and enter the following URL in the address field: <b>localhost/cds</b> .<br>The <b>DAP manager IP DECT</b> page appears. |
| 2    | Click <b>Get Archive</b> .<br>The <b>Select archive file</b> requester appears.   |



- |   |   |
|---|---|
| 3 | Select <b>Generate and save a new archive file</b> to create a new archive file.<br><b>OR</b><br><b>Save the nightly generated archive file</b> to save a copy of the automatic archive, which is generated at midnight each day. |
| 4 | Click <b>OK</b> to go to the <b>File Download</b> page.   |

**OR**

Select the check box next to **Send by email to**, enter the email address to get the archive for each email and click **OK**. You must configure the SMTP server before you use this feature. For information, see [Procedure 51 “Configuring other settings—Performance/Email Settings”](#) (page 120).

- 5 Click **Save** on the **File Download** page.
- 6 Navigate to the folder where you want to store the archive file.
- 7 In the **Name** field, enter a name for the archive file.
- 8 Click **Save**.

---

--End--

---

## Handset firmware update

You can install new firmware and software on the handsets using the Handset Firmware update option.

Handset Firmware update is available only on handsets that support this feature.

Go to the Define Handset Packages and see the list of handsets for which you can upgrade the firmware.

The Firmware Upload service must be running. If the Firmware Upload service is not running, a qualified engineer must first start the service.

Update the handset firmware.

### Procedure 81 Updating the handset firmware

Step	Action
1	Click the menu <b>Handset Firmware Update</b> in the Main Window. The <b>Handset Firmware Update</b> window appears.
2	Click the option <b>Configuration</b> . The <b>Configuration</b> window appears.

**DAP Manager INT - System\_1**

**Handset Firmware Update**

Update Handsets  
Add Handsets  
Configuration  
Define Handset Packages  
Statistics  
Back To Main

FWU Service status : Running ...

☒ Pause update process

### Configuration

Maximum number of simultaneous updates (default) :

Maximum number of retries for non-fatal errors :

Retry interval (minutes) :


### Define Update Periods

Active Period	Day		Time		Max. No. of Updates
	Start	Stop	Start	Stop	
1.	Friday	Friday	17:00	24:00	2
2.	---	---	---	---	
3.	---	---	---	---	
4.	---	---	---	---	
5.	---	---	---	---	
6.	---	---	---	---	
7.	---	---	---	---	

OK

**Nortel** © 2002-2008

- 3 Enter the following items:
  - Maximum number of simultaneous updates, which is the maximum number of simultaneous updates that occur outside the time periods you define in Define Update Periods.
  - Maximum number of retries for nonfatal errors, which is the maximum number of retries for non fatal errors.
  - Retry interval, in minutes.
- 4 In the table Define Update Periods, specify the days of the week and the time period updates are to occur.  
 Nortel recommends that you have the system perform updates during out-of-office periods. The handset functions during firmware updating; however firmware updating reduces the number of available channels on a radio.
- 5 Click **OK**.
- 6 Ensure the new firmware packet is available on the hard disk.
- 7 Click the option **Define Handset Packages**.  
 The **Define Handset Packages** window appears.



8 In the **Select handset packages** window, select the handset type.

9 Browse to the new firmware package, for example, 4070\_v0133.bin, and click **Upload**.

The firmware file name must be in a specific format, for example, 4027\_vXXXX.bin, 4070\_vXXXX.bin, or 4075\_vXXXX.bin, for which XXXX is the firmware version.

Uploading means that the packet is visible in the right panel; it does not indicate an upload to the handsets is taking place.

10 On the left side next to the handset type the currently selected firmware version appears. Click the handset or package relation in the left panel to display the available firmware packages in the right column.

11 In the right pane, click the package, and then click **Select**.

12 In the menu, click **Add Handsets**.

The **Add handsets** window appears.



**13** In the **Add handsets** window, add the extension number range on which to upgrade firmware.


**14** Click **OK**.

**15** Click **Update Handsets**.

A list of the handsets that are ready to update appears.

**16** Click **Start Update** to start the update.

The update starts according to the time schedule you defined. The status of the update process appears in the **Update handsets** window, as shown in the following figure.



- After the update, the handset continues to use the old firmware packet.
- 17 Click **Remove Ready Handsets**.
- 18 To activate the new firmware, restart the handset.  
There are two options in restarting the handset.
- If the handset is in the charger, the handset automatically restarts. No manual intervention is needed.
  - If the handset is not in the charger and you want to activate the new software immediately, switch off the handset and switch it on again. After the handset switches over to the new firmware packet, the message "Firmware Update in progress. Do not switch off." appears.
- 19 After the update, clean up the handsets list by using one of the following options:
- Remove Handsets
  - Remove Ready Handsets
- 20 Click **Statistics** to view an overview of the all actions that occur. A window appears.

---

--End--

---

## Central directory access tool

The Central directory access tool connects a directory to the SIP DECT system.

The Central Directory Access feature is available only for handsets that support it.

After you install the Central directory access tool, the tool provides two services that run under Windows. No user interface is available. TCP/IP Port 30160 is open for external access from the IP DECT system.

IP DECT connects to the Central directory access tool through the TCP/IP socket defined in the IP DECT Configurator tool.

For access to the database, the handset type must support access to the database through the handset menu. If the handset menu does not offer an option to access the Central Directory, you cannot use Central Directory on that handset type. Consult your SIP DECT supplier to find the handset types that support Central Directory dialling.

## Supported database types

Nortel supports using Flat Excel database as a database type for a Central directory access tool.

### Create an Excel file for the central database

You can create a an Excel sheet to contain your central database. When you install the Central directory access tool, specify the path to the Excel file and the file name.

Create an Excel file for the central database.


#### Procedure 82

#### Creating an Excel file for the central database

Step	Action
1	Open Microsoft Office Excel.
2	Add three columns as shown in the following figure.

#### ATTENTION

It is important to use the column headers DBID, Name, and Extension. The first column contains sequence numbers and each must be unique.



3	Add as many rows as entries.
---	------------------------------

If the number of entries in the spreadsheet is small (about 10), then you can see some of the entries more than once on the handset display while scrolling the list. This is normal.

4	Change the name of the Excel sheet from Sheet1 to directory.
---	--

5	Save the database, for example, as cda_names.xls .
---	--

After you update the file, it is immediately active in the Central directory access tool. Do not change the file name as you update the file.

---

--End--

---

## Installation


Install the Central directory access tool.

### Procedure 83

#### Installing the Central directory access tool

Step	Action
1	Ensure that the IP DECT Configurator is installed on the DAP controller PC.
2	Create an Excel file for the Central Database as described in <a href="#">Procedure 82 "Creating an Excel file for the central database" (page 171)</a> .
3	Check for the Central directory access tool software.  The Central directory access tool software consists of a folder, called DISK1, which contains a setup file.
4	Run the setup.exe file, and perform one of the following steps:  If Microsoft Office Access database engine is available on your PC, the <b>Central Director Access Startup</b> window appears. Proceed to step 5. <b>OR</b>  If Microsoft Office Access database engine is not available, you are prompted to install Microsoft Office Access database engine 2007.  If you use the Microsoft Windows 2000 Server, you are prompted to install Microsoft Data Access Components 2.8 instead of the Microsoft Office Access database engine.  Click Install and perform the instructions that appear.  If you use the Microsoft Windows 2000 server, you are prompted to install Microsoft Data Access Components 2.8 instead of the Microsoft Office Access database engine.  After Microsoft Office Access database engine 2007 is installed on your PC, the Install Shield window appears.
5	Click <b>Next</b> . The <b>Database Type</b> page appears.

- 6 Select **Excel File**.
- 7 Click **Next**.  
The **Select the Excel File** page appears.
- 8 Click **Browse**, and browse to the Excel file that contains the Central Directory data. click **Next**.  
The **Ready to Install the Program** page appears.
- 9 Click **Install**.  
The system installs the software. Once the installation is complete, the **InstallShield Wizard Completed** appears.
- 10 Click **Finish**.  
As result of the installation, two new services are running, as shown in the following figure.
  - Nortel AccessService
  - Nortel DirectoryService



- 11 Ensure that **Nortel AccessService** and **Nortel DirectoryService** are present in the list, and have a Status of Started.

--End--

## Configure SIP DECT for Central directory access

You must configure SIP DECT to reach the Central directory access services.

Use the steps in the following procedure to configure SIP DECT for using Central directory access.

**Procedure 84**  
**Configuring IP DECT**

<b>Step</b>	<b>Action</b>
<b>1</b>	Open the IP DECT Configurator and click <b>Modify</b> .
<b>2</b>	Select the SIP DECT system that you are running. Click <b>IP Settings</b> .  The <b>IP Settings</b> page appears.
<b>3</b>	Click <b>More</b> . The <b>Advanced IP Settings</b> pane appears.
<b>4</b>	Enter the <b>CDA IP Address</b> and the <b>CDA port</b> .  The IP address is the IP address of the computer running the Central directory access tool. The port number is the port that is open for Central directory access on the CDA computer. The default port number is 30160.
<b>5</b>	Click <b>Apply</b> .
<b>6</b>	Click <b>Save System</b> .
<b>7</b>	Click <b>Activate / Deactivate / System Status</b> .
<b>8</b>	Restart the DDS service and restart all DAPs.

---

--End--

---

---

# System maintenance

---

This chapter contains information to help you perform system maintenance, such as replacing DECT Access Points (DAP) and managing DAP synchronization.

## Navigation

- [“DAP Web interface” \(page 175\)](#)
- [“C4710 DAP LED indications” \(page 177\)](#)
- [“Remove and replace a DAP \(if a new DAP is available\)” \(page 180\)](#)
- [“Remove and replace a DAP \(if a new DAP is not available\)” \(page 181\)](#)
- [“System synchronization analysis ” \(page 182\)](#)
- [“Export and import SIP DECT system” \(page 190\)](#)
- [“DAP Controller deactivation” \(page 192\)](#)
- [“Uninstalling DAP Controller software” \(page 193\)](#)
- [“DAP Controller software update” \(page 194\)](#)
- [“Troubleshooting” \(page 195\)](#)
- [“If you have problems” \(page 197\)](#)


## DAP Web interface

DAPs that have firmware 4910b420.dwl or later provide a Web interface. You can use the Web interface to view DAP data, and export the DAP data to a file. However, you cannot change or modify the data using the Web interface.

View DAP configuration information using the Web interface.

### **Procedure 85** **Viewing DAP configuration information**

Step	Action
1	In an Internet browser, enter the DAP IP address in the address field, for example: 192.168.32.108. The <b>General Settings</b> page appears.



- 2 Use this page to view the following DAP configuration information:
  - Click **Configurations items** to see specific PABX configuration data
  - Click **DNR Administration** to see extension number information
  - Click **Network status** to see network-related information.
- 3 Optionally, click **Home Page** to return to the general settings page.

--End--

Export DAP configuration information to a file by using the Web interface.

**Procedure 86**  
**Exporting DAP configuration information**

Step	Action
1	In an Internet browser, enter the DAP IP address in the address field. For example: 192.168.32.108. The <b>General Settings</b> page appears.
2	Click <b>Save information in file</b> The File Download page appears.
3	Click <b>Save</b> .
4	Browse to the folder where you want to save the file.
5	Enter the name of the file, and click <b>Save</b> .
6	Optionally, click <b>Home Page</b> to return to the general settings page.
--End--	

## C4710 DAP LED indications

The DAP is equipped with one LED, which can indicate six DAP statuses:

- Off: No power
- On 0.5 seconds, off 0.5 seconds: Loading software/firmware.
- Short flash every 0.25 seconds: IP Network error (not connected; no DHCP or TFTP server; or no DAP Controller)
- Fast blink: DAP is operational but trying to synchronize to another DAP
- Continuous fast blink: Hardware error
- Steady On: DAP operational (and synchronized to other DAP or is the synchronization master)

## 4720 DAP LED indications

### LED Status

The 4720 DAP is equipped with two LEDs.

### Top LED – Yellow

This LED represents the status of the 4720 DAP. The indications are equal to the status indication on the 4720 DAP LED.

**Table 20**  
**4720 DAP LED Status on top LED**

LED Status (Top LED, Yellow)	Meaning
Off	No power
0,5 seconds On - 0,5 seconds Off	Loading software/firmware
Short flash every 0,25 seconds	IP Network error (not connected, no DHCP/TFTP server, no DAP Controller)
Fast blink	DAP operational, but trying to synchronize to another DAP
Continuous fast blink	Hardware error
Steady On	DAP operational (and synchronized to other DAP, or is the synchronization master).

#### **Lower LED – Red/Green**

This LED is used to indicate the start-up and network status.

**Table 21**  
**Lower LED status on the 4720 DAP**

LED Status (lower LED, Red/Green)	Meaning
RED Steady on	Power, but FPGA starting up
RED flashing	Trying to connect to the network
Green flashing	Network status display and showing network activity
Off	4720 DAP operational

#### **LED Colours**

The color of the top LED can be different depending on the operational mode. The following operational modes are distinguished:

- **Normal (single band) mode**

In the normal single band mode, the top LED will be Yellow.

- **Dual Band Mode**

In Dual Band mode, the LED color shows the operational frequency:

- Green .... : Europe/International
- Red ..... : North America / USA

## **DAP firmware update**

Use the information in this section to load updated firmware to the DAPs.

**CAUTION****Risk of service loss**


You must update the firmware for all DAPs in the system at the same time. Ensure that all DAPs are running, and can have their firmware updated.

**CAUTION****Service loss during restart**

During the DAP firmware update, you must restart the DAPs. When you restart the DAPs, any DECT calls that are in progress are dropped, and the SIP DECT system is not available to handle calls until the DAPs finish restarting.

**Procedure 87**  
**Updating the DAP firmware**

Step	Action
1	Start IP DECT Configurator.
2	In the IP DECT Configurator main window, click <b>General</b> .
3	If you have more than one DECT system configured in IP DECT Configurator, click <b>Modify</b> , and select the system you want to update.
	<b>OR</b>
	If you have only one DECT system configured, proceed to step 4.
4	In the General Settings window click <b>Browse</b> .
5	Browse to the folder where the new firmware (the DAP package file) is stored, select the DAP package file, and click <b>Open</b> .
	The new firmware information appears in the DAP Package: field.



- 6 Click **Apply**.
- 7 Click **Save system**.
- 8 Click **Activate/Deactivate/System status**.
- 9 Ensure the DHCP and TFTP servers are running.
- 10 Click **Reboot** to restart the DAPs.
- 11 Enter the following URL in an internet browser:  
**localhost/cds**.  
The DAP Manager appears.
- 12 In the **Main** panel, click **Access Points**.  
The Access Points page appears.
- 13 On the Access Points page, ensure the new firmware (Package ID) is uploaded successfully.

---

--End--

---

## Remove and replace a DAP (if a new DAP is available)

Remove and replace a DAP.

**Replacing a DAP**

Step	Action
1	Ensure that DAP Manager is running before you begin to replace a DAP.
2	Ensure that the DHCP server and the TFTP server are running in the IP network.
3	Open the DAP Manager Web interface.
4	Click <b>Access Points</b> .
5	Disconnect the DAP you need to replace.  Do not continue this procedure until DAP Manager indicates that the DAP is not working.
6	Connect the new DAP.  Wait until you see that the new DAP is running (in the DAP Manager interface).
7	Click <b>Edit</b> for the new DAP.
8	Change the RPN number of the new DAP to the RPN number of the replaced DAP, and click <b>OK</b> .  After the DAP restarts, it has the RPN of the replaced DAP. Now the subscriptions that were active in the replaced DAP are automatically installed in the new DAP. This can take a few minutes.
9	Check that the subscriptions of the replaced DAP are on the new DAP.  After you have verified that the subscription records are placed in the new DAP, switch the handsets associated with these records off and on to make them operational again.
10	Check that you can make phone calls using the new DAP.
<hr/> --End-- <hr/>	

**Remove and replace a DAP (if a new DAP is not available)**

Replace a failed DAP.

**Procedure 88  
Replacing a DAP**

Step	Action
1	Open the DAP Manager Web interface.
2	Click <b>Access Points</b> .

- 3 Physically disconnect the DAP to replace.
- 4 From the DAP list in DAP Manager, manually record the Radio Part Number (RPN) of the DAP you are replacing.  
Wait until the status of the DAP being replaced changes to not working in the DAP Manager Web interface.
- 5 In the DAP Manager Web interface, select the DAP you are removing.
- 6 Click **Delete** to delete the DAP from the system.  
  
Wait while the system redistributes the subscription records stored on the DAP you are removing.  
The RPN of the DAP you are removing disappears from the Subscription page in the DAP manager, and is replaced by the RPNs of other DAPs.
- 7 Turn off each handset that had its subscription record stored on the DAP you are replacing.
- 8 Turn on each handset that had its subscription record stored on the DAP you are replacing.  
  
Each handset is now connected to another DAP.
- 9 When you receive a new DAP, ensure that the DHCP server and the TFTP server are available in the IP network.
- 10 Connect the new DAP.  
  
Wait until the new DAP appears in the DAP list of the DAP manager.
- 11 Click **Edit**.
- 12 In the **RPN** field of the new DAP, enter the **RPN value** you recorded after you removed the old DAP in step 4.
- 13 Click **OK**.  
  
After the new DAP restarts, verify that it has the RPN of the DAP you removed.

---

--End--

---

## System synchronization analysis

Use the information in this section to manually synchronize the DECT system, and eliminate possible synchronization problems.

An analysis tool called Synchronization Analyzer is available in the DAP Configurator. You can use this tool to generate a graphical overview of the synchronization structure in the system and to calculate the best candidate for the synchronization master. You can also use it to detect potential problems in the synchronization structure.

Synchronization Analyzer provides the following information displays:

- a hierarchical view of the DAP Synchronization using visibility files
- a three-dimensional localization of DAPs using location files
- a Traffic Bearer Control file analysis, which you can use to trace which DAPs a handset used during a call


### Synchronization Analyzer interface

This section describes the Synchronization Analyzer interface.

To access the Synchronization Analyzer, click Start > All programs > DAP controller > DAP Applications > DAP Sync Analyzer.

### Synchronization Analyzer main page

The main page of the Synchronization Analyzer, as shown in the following figure, has four panes.



- The Tree view pane shows a hierarchical view of the synchronization tree. In the tree view, you can select a DAP.
- The Visibility Information pane shows an overview of the RSSI values.
  - The RSSI (sees) column indicates the signal strength with which the selected DAP communicates with the other DAPs.
  - The RSSI (seen) column indicates the signal strength with which the other DAPs communicates with the selected DAP.

Although the radio signal connection is reciprocal, differences can exist between the seen and sees RSSI value.

The RSSI values are hexadecimal in the range: 0 to e; 0 indicates no signal. The -80 dBm boundary is found at the boundary between 3 and 4. Generally, the Phase difference must be ffffffff with a maximum deviation of 7

- The Building Information pane shows overall data related to the DECT cluster.
- The DAP Information pane shows data of the selected DAP.

**Table 22**  
**Buttons on the Synchronization Analyzer main page**

Button	Function
Load Location	Click Load Location to open a specific Location file.
View Location	Click View Location to open the Location page without specifying a Location file. For more information, see <a href="#">“Synchronization Analyzer Location page” (page 185)</a> .
Settings	Click Settings to open the Settings page, on which you can enter the RSSI threshold and the Phase Difference threshold.
Find	Click the Find button to search the RPN number, the MAC address, or Info field of all the DAPs.


**Table 23**  
**Menus on the Synchronization Analyzer main page**

Menu	Contains these options	
File	<ul style="list-style-type: none"><li>• Open to open a Visibility File.</li><li>• Compare to open a Visibility file and compare it with the current tree. One of the following symbols appears next to each DAP in the tree view.</li></ul>	
	Symbol	Meaning
	+ Red	The current level of an RPN is higher than the one in the compared file.

Menu	Contains these options									
	--Red	The current level of an RPN is lower than the one in file loaded for comparison.								
	= Green	The current level is the same as the compared level.								
	X Red	This DAP does not exist in the file that you loaded for comparison.								
	<ul style="list-style-type: none"><li>• Print to send the Tree view to a printer.</li><li>• Exit to exit from the program.</li></ul>									
View	<ul style="list-style-type: none"><li>• Problems to select the problem view, which is the default view. A number of potential problems, such as DAPs that can synchronize with only one other DAP, are defined in the program and indicated in the tree view by an exclamation mark.</li><li>• Synchronization to select the synchronization view, which shows the synchronization path of the selected DAP. One of the following symbols appears next to each DAP in the tree view.</li></ul> <table><tr><th>Symbol</th><th>Meaning</th></tr><tr><td>+ Blue</td><td>The selected DAP sees this DAP.</td></tr><tr><td>+ Red</td><td>The selected DAP is synchronized on this DAP.</td></tr><tr><td>+ Purple</td><td>The selected DAP sees and synchronizes on this DAP.</td></tr></table> <ul style="list-style-type: none"><li>• New Master to configure the currently selected DAP as cluster master in the tree view.</li><li>• Best Master to calculate what DAP is best suited to be the master.</li><li>• Expand All to expand all entries in the tree view.</li><li>• Collapse All to collapse all entries in the tree view.</li><li>• Location to open a specific Location file in the Location page.</li><li>• Settings to open the Settings page, where you can enter the RSSI threshold and the Phase Difference threshold.</li></ul>		Symbol	Meaning	+ Blue	The selected DAP sees this DAP.	+ Red	The selected DAP is synchronized on this DAP.	+ Purple	The selected DAP sees and synchronizes on this DAP.
Symbol	Meaning									
+ Blue	The selected DAP sees this DAP.									
+ Red	The selected DAP is synchronized on this DAP.									
+ Purple	The selected DAP sees and synchronizes on this DAP.									
Tools	<ul style="list-style-type: none"><li>• Track Portable to open a traffic bearer file in the Portable Tracking page.</li></ul>									
Help	<ul style="list-style-type: none"><li>• Help to access Help features.</li></ul>									

### Synchronization Analyzer Location page

Use the Location page to display a visual representation of the DAP locations in the system.



On the Location page, the color of each DAP indicates the synchronization level, as follows:

- Red = root level
- Green = first level
- Yellow = second level

After the location information is loaded into the tool from a file a Location file, the DAP positions are shown on each floor. Select a floor, or an individual DAP, and information appears to the left of the selection.


After a DAP is selected, other DAPs that the selected DAP can communicate with change color and the corresponding node in the tree view is highlighted.

The following controls are available:

- Double-click the map panel, or click Toggle View, to zoom in on a single floor.
- Right-click the map pane to access a menu of zoom controls.

### Synchronization Analyzer Portable Tracking page


Use the Portable Tracking page to follow the movement of a portable device from DAP to DAP. A portable device can be tracked only if it is in an active call. For an illustration of the parts of the Portable Tracking page see the following figure.



Analyze DAP synchronization and track portable devices in the system.

#### Procedure 89 Tracking a portable device

Step	Action
1	Click <b>Start &gt; All programs &gt; DAP controller &gt; DAP Applications &gt; IPDECT Performance Manager</b> to open the DAP Performance Management Interface.




- 2 Select the **Enable Logging** check box.  
The file pmtbc.dat is generated, and contains Traffic Bearer Control information.

#### ATTENTION

You must disable logging when you finish the synchronization analysis activities.

- 3 Click **Start > All programs > DAP controller > DAP Applications > DAP Sync Analyzer**.
- 4 Choose **Tools > Track Portable** from the menu.  
A file requestor appears.
- 5 Navigate to the directory **C:\.. \PM\** on the DAP controller or manager PC, and choose the file **pmtbc.dat**.  
The **Portable Tracking** page appears.



- 6 Click **Set Subscription Management File**.  
A file requester appears.
- 7 Navigate to the directory **C:\. \PM\** on the DAP controller or manager PC, and choose the file **sm.xml**.  
This file contains the relations between the PMIDs to the Extension numbers. After the file loads, an extra column appears in the data pane to show the extension number.
- 8 Click **Set Filter** and **Browse** to filter the data that appears in the window.

--End--

**Table 24**  
**Job aid**

Filter buttons	Description
Set filter Filter by Start time End time	Click Set Filter to apply a filter to the information that appears in the data pane.
Browse Radios Browse Calls	Click the Browse buttons to browse between calls or radios.

**Procedure 90**  
**Using DAP Synchronization Analyzer**

Step	Action
1	Click <b>Start &gt; All programs &gt; DAP controller &gt; DAP Applications &gt; DAP Sync Analyzer</b> .
2	From the menu, choose <b>File &gt; Open</b> . A file requester appears.

- 3 Select the file **visadm.txt**, and click **Open**.
- 4 Use the commands in the menu **View** to analyze the synchronization structure.
- 5 Optionally, use the commands in the menu **View** to troubleshoot the structure.
- 6 Optionally, load a location file. The location file contains a site map with buildings and floors in which the DAPs are positioned. Use the site map to quickly determine the position and range of a specific DAP. You can create a Location file using the Location Builder tool. For more information, see "[Location builder tool](#)" (page 209).
- 7 Optionally, load a Traffic Bearer Control (pmtbc.dat) data file. This file contains statistics and logging information about traffic bearers. To open this file, choose **Tools > Track Portable**. A file requestor appears.
- 8 Navigate to the directory **C:\..\PM\** on the DAP controller or manager PC, and choose the file **pmtbc.dat**. The data from the TBC file appears in a table, and the PMID of each portable appears.
- 9 Navigate to the directory **C:\..\PM\** on the DAP controller or manager PC, and choose the file **sm.xml**. An extra column appears in the data pane, to show the extension number.

---

--End--

---

## Export and import SIP DECT system

You can use the IP DECT Configurator to export your system to another computer or to back up the configuration.

After you run an Export System, all the relevant system settings, including all customer data, are exported to a compressed or zip file. To return to this configuration, import the compressed file and your system configuration including customer data, such as handset subscriptions, is restored on your DAP controller or manager PC.

### Export a system

Export a system configuration.

**Procedure 91**  
**Exporting a system configuration**

Step	Action
1	Click <b>Start &gt; All programs &gt; DAP controller &gt; DAP Applications &gt; DAP configurator</b> , to start the IP DECT Configurator tool.  The IP DECT Configurator tool appears.
2	Click <b>Modify system</b> , and select the system to export.
3	Click <b>Export system</b> .  Use the window that appears to store the file on a location of your choice and specify a file name.
--End--	

**Import a system**

Import a system configuration.

**Procedure 92**  
**Importing a system configuration**

Step	Action
1	Click <b>Start &gt; All programs &gt; DAP controller &gt; DAP Applications &gt; DAP Configurator</b> . The <b>IP DECT Configurator</b> window appears.
2	If the system is active, click <b>Activate / Deactivate / System status</b> to deactivate the system.
3	Click <b>Import System</b> .
4	Browse to the file that contains the system to import.
5	Browse through the configuration tabs, and ensure that all settings are correct.
<div style="border: 1px solid black; padding: 5px;"> <p><b>ATTENTION</b>  DAP firmware is not added to the archive of the system, so you must click <b>Browse</b> on the <b>General settings</b> tab, navigate to the folder where the firmware file is stored, select the file, and click <b>Open</b>.</p> </div>	
6	Click <b>Activate / Deactivate / System status</b> to activate the imported system.
--End--	

## DAP Controller deactivation

You can use the DAP Controller to configure the SIP DECT system. In addition, if the DAP Controller is connected and active, it can perform the following functions:

- Process messaging (Low Rate Messaging and interaction with DECT Messenger).
- Move subscriptions from a nonworking DAP to a working DAP. You can configure the number of minutes for which a DAP must be unavailable before the system considers it to be not working; the default is 10 minutes.
- Monitor the SIP DECT system and send archives and alarms by email.
- Provide the built-in DHCP and TFTP servers.

After you configure the SIP DECT system using the DAP Controller, you can perform either of the following:

- Leave the DAP Controller PC connected and active, so that it performs all the functions in the preceding list, and you can use it at any time to configure the SIP DECT system.
- Deactivate the DAP Controller software. You can then use the DAP Controller PC for other purposes, and optionally disconnect it from the network. You can reactivate the DAP Controller software at any time to configure the SIP DECT system.


### ATTENTION

If you use the built-in DHCP and TFTP servers, do not deactivate the DAP Controller software. In this case, deactivating the DAP Controller software can interrupt service when a DAP restarts, for instance during a power interruption or during a firmware upgrade.

If you disconnect your DAP controller PC from the network, you must first deactivate SIP DECT services.

### Procedure 93 Deactivating SIP DECT services

Step	Action
1	Start DAP Configurator
2	In the IP DECT Configurator main window, click <b>Activate/Deactivate/System Status</b> .
3	Click <b>Deactivate All</b> (indicated in the following figure) to stop all enabled services and programs.



4 After you deactivate the system, click **Exit**.

--End--

## Uninstalling DAP Controller software


Remove the DAP Controller software,

### Procedure 94

#### Removing DAP Controller software

Step	Action
1	Start the IP DECT Configurator. Click <b>Start &gt; All programs &gt; DAP controller &gt; DAP Applications &gt; DAP configurator</b> .
2	Click <b>Activate/Deactivate/System Status</b> .
3	Click <b>Deactivate all</b> .
4	Close the IP DECT Configurator tool.
5	Click <b>Start &gt; Settings &gt; Control Panel</b> .
6	Double-click <b>Add/Remove Programs</b> .

- 7 Click **Change or Remove programs**.  
A list of installed programs appears, as shown in the following figure.



- 8 Select **DAP Controller**.  
9 Click **Remove**.  
10 Click **Yes** to confirm DAP Controller deinstallation.

---

--End--

---

## DAP Controller software update

Update the DAP Controller software.

### Updating the DAP Controller

Step	Action
1	Export the current system. For more information, see <a href="#">“Export a system” (page 190)</a> .
2	Uninstall the DAP Controller. For more information, see <a href="#">“Uninstalling DAP Controller software” (page 193)</a> .
3	Restart your PC.
4	Install a new version of the DAP Controller. For more information, see <a href="#">“DAP Controller” (page 106)</a> , and restart your PC if required.

- 5 If the system files used by the previous version of DAP Controller remains on the hard drive, the DAP Controller uses that software, and you need only activate the system.

If the system files are no longer present on the hard drive, perform one of the following steps:

For more information, see [“Import a system” \(page 191\)](#).

**OR**

Create a new system. For more information, see [“Configuration using IP DECT Configurator” \(page 112\)](#).

---

--End--

---

## Troubleshooting

The Troubleshooting section provides settings you can check to resolve some common configuration problems.

- [“If DAP is not working” \(page 195\)](#)
- [“If you cannot make calls to or from a DECT handset with SIPL configuration” \(page 196\)](#)

### If DAP is not working Prerequisites

- The signaling server, call server, and DAP Controller are configured and connected to the Ethernet.
- SIP DECT is configured in the IP DECT Configurator.

If DAP is not working, ensure that the DHCP and TFTP servers are configured and running.

If you use the MS Windows DHCP Server, ensure:

- the scope is created
- the IP address range is added
- the scope options are configured
- the scope is activated
- Microsoft Windows DHCP Server is running

If you use the MS Windows TFTP Server, ensure

- Run TFTP Server on this PC is selected
- Windows TFTP Server on this PC is selected

- Microsoft windows TFTP Server (Trivial FTP daemon) is running
- dapcfg.txt and DAP firmware package are presented in the C:\TFTPDROOT folder

If you use a built-in DHCP Server, ensure

- Run DHCP Server on this PC is selected
- the DAP IP range is entered
- the DAP IP Range exclusive for DAPs only is selected
- the Subnet Mask is entered
- the Default gateway is entered
- the TFTP IP address (of the DAP Controller PC) is entered
- the DHCP Server is running (Activate / Deactivate / System status button)

If you use built-in TFTP Server (IP DECT Configurator), ensure

- Run TFTP Server on this PC is selected
- 3com TFTP Server on this PC is selected
- TFTP Server is running (Activate / Deactivate / System status button)

For more information, see [“DHCP and TFTP servers” \(page 91\)](#).

### **If you cannot make calls to or from a DECT handset with SIPL configuration**

Perform the following steps if you cannot make calls.

Step	Action
1	Ensure that the SIP Line Gateway, call server, and DECT system are configured and connected to the Ethernet.
2	Ensure that the DAPs are working.
3	Verify that a dial tone sounds if a handset goes off-hook. If no dial tone sounds, the SIP DECT handset is not registered on SIP Line Gateway. Verify that the following SIP settings are configured properly: <ul style="list-style-type: none"><li>• For IP DECT Configurator<ul style="list-style-type: none"><li>— ensure that the following values are configured: Proxy IP address = SIP Line Gateway node IP address. Proxy IP address port = SIP Line Gateway node IP address port.</li></ul></li></ul>

For more information, see [Procedure 45 “Configuring IP Settings” \(page 114\)](#).

- ensure that the following values are configured:  
SIP domain = root domain (SIP Line configuration)  
Realm = SIP domain in capital letters  
user and password are entered correctly  
use\_registrar = yes  
redirect=no  
multiple\_sip\_ports=yes

For more information, see [Procedure 48 “Configuring SIP Settings” \(page 117\)](#)

- For SIP Line Gateway
  - ensure the SIP DECT handset is registered to the SIP Line Gateway. To do so, issue the following command from the SIP Line Gateway CLI: **>slgSetShowAll**. A list of the SIP Lines currently registered on this SIP Line Gateway appears.
- For Call Server,
  - ensure that SIP LINE is configured with the following values:  
SIP Line domain = SIP DECT domain  
user agent prefix is entered  
SIP port = SIP Proxy port, configured in IP DECT Configurator
  - ensure that UEXT is configured with the following values:  
node id = sip line gateway node ID  
sipu = SIP DECT user DN  
scpw = password is entered according to settings in SIP DECT  
key 1 hot u = <user agent prefix> + <DN>

---

--End--

---

## If you have problems

If you have problems with your SIP DECT system, first review [“Troubleshooting” \(page 195\)](#). The Troubleshooting section lists and describes the settings you can check to resolve some common configuration problems. If you cannot resolve the issue, collect the necessary information including a system survey, system archive, and network traces. Describe the issue and contact the Nortel help desk.

**System survey**

Complete a system survey for your SIP DECT configuration. Provide the information outlined in the following sections to describe your hardware, IP addresses, software version, configuration, and numbering plan. If you have problems with your SIP DECT system, send your completed system survey with the system archive to the Nortel help desk.

**Hardware**

- Call server:
- Number of DAPs:

**IP addresses**

- Signaling server or SIP Line gateway (Node IP):
- DAP Controller PC:
- DHCP server (if different from DAP controller PC):
- TFTP server (if different from DAP controller PC):

**Software version**

- Call server release:
- Microsoft Windows (installed on DAP Controller PC):
- DAP controller software:
- DAP firmware package:
- Central Directory access tool (if any):

**Configuration**

- Single or multiple system (as selected during DAP controller software installation):
- Simple or Routed Head Quarter, or MSMN:
- Microsoft Windows or built-in DHCP server:
- Microsoft Windows or built-in TFTP server:

**Numbering plan**

- CDP or UDP:
- Number range for SIP DECT handsets:

- Twinned configuration in use (yes or no):
- CallPilot in use (yes or no):

### **DAP information file**

The DAP information file contains the main configuration parameters for the current DAP; the Nortel help desk can use it for detailed access. For more information, see [Procedure 85 “Viewing DAP configuration information” \(page 175\)](#) for information about how to access the information file.

### **System archive**

The System archive contains important information about your SIP DECT system; you can send it to the Nortel help desk if problems occur. For more information, see [“System archive” \(page 165\)](#) to learn how to create an archive.

The Nortel help desk may direct you to temporarily enable logging for your SIP DECT system before you test a specific call scenario. For more information, see steps 1 and 2 of [Procedure 89 “Tracking a portable device” \(page 187\)](#). Enabling logging before testing a specific call scenario adds extra information to the system archive.

### **Network packet capture traces**

The Nortel help desk may ask you to collect network traces if some call scenarios fail on your SIP DECT system. Traces contain SIP messages and RTP packets sent over the Ethernet. You can collect traces from a computer connected to the network (when hubs are in use or if port mirroring is configured on IP switches). In some cases, you can trace SIP messages from Signaling Servers. The Nortel help desk can help you collect network traces if you need assistance.

You can be requested by the Nortel help desk to temporarily enable logging for your SIP DECT system before you capture traces for a specific call scenario. For more information, see steps 1 and 2 of [Procedure 89 “Tracking a portable device” \(page 187\)](#).



---

# Appendix

---

This chapter contains information about procedures to mount the G.729 daughterboard and 4720 DECT Access Point (DAP) against the wall, and adjust the antenna position.

## Navigation

- [“Mount the G.729 daughterboard” \(page 201\)](#)
- [“Adjusting the antenna position” \(page 203\)](#)
- [“Mounting the 4720 DAP on a wall” \(page 205\)](#)

## Mount the G.729 daughterboard

Use this procedure to install the G.729 daughter board.


### Procedure 95 Mounting the G.729 daughterboard

Step	Action
1	Make sure that you have the G.729 Daughter board.
2	Open the cabinet.
3	Take the PWB out of the cabinet.

**ATTENTION**

Use caution when handling the PWB; the light conductor for the LEDs can drop off.


**Figure 39**  
**Light conductor for LEDs**



Now the 4720 DAP Printed Wiring Board (PWB) and the G.729 Daughter Board are separate items.


- 4 Remove the protection foil from the sticky part on the G.729 Daughter Board.

**Figure 40**  
**G.729 Daughter Board with sticky foam**



- 5 Mount the G.729 Daughter Board onto the main PWB. Push the Daughter Board carefully onto the main board. The white connector should fit well. Ensure the adhesive portion sticks to the Main Board.

**Figure 41**  
**Mounting the G.729 Daughter Board onto the Main board**



**Figure 42**  
**G.729 Daughter Board on the Main Board**



- 6 Put the 4720 DAP together by mounting the PWB into the cabinet and assembling the cabinet. Do not forget to mount the two screws back into the rear side of the cabinet.


--End--

## Adjusting the antenna position

### ATTENTION

You only need to change the antenna position when you mount the 4720 DAP horizontally. In all other cases you do not need to change the antenna position.


**Figure 43**  
**4720 mounted horizontally**



### ATTENTION

The antenna position can be changed once. Do not change the antenna position after the initial change.

1. Remove the two screws from the rear side of the cabinet.




2. Open the cabinet carefully. Ensure that you shift the cover of the antenna carefully from the antenna.
3. Remove the antenna cover from the 4720 DAP cover.
4. Carefully bend the antennas to position them vertically, as shown in [Figure 44 "Bend Antennas carefully into vertical position" \(page 204\)](#).

**Figure 44**  
**Bend Antennas carefully into vertical position**




5. After the antennas are put in the vertical position, replace the 4720 DAP cover and secure the screws at the rear side of the cabinet.

**Figure 45**  
**Antennas locked into Cover**



6. Ensure that the antennas are properly locked into the locks in the 4720 DAP cover, as shown in [Figure 46 "Antenna in locked position" \(page 205\)](#).

**Figure 46**  
**Antenna in locked position**



7. Move the antenna cover carefully over the antennas in the vertical position and make sure that the antennas do not bend. When the antenna cover is in place, attach it by pushing it into its position in the 4720 DAP cabinet.

**Figure 47**  
**Cover installed**




8. The 4720 DAP is now ready to install.

## **Mounting the 4720 DAP on a wall**

Use this procedure to mount the 4720 DAP to the wall:

1. Remove the mounting plate from the 4720 DAP cabinet.

**Figure 48**  
**How to take the mounting plate off**



2. Attach the mounting plate to the wall.

**Figure 49**  
**Mounting plate**



3. Ensure the Cat 5 cable to the cabinet is the correct length.
4. If necessary, mount the RJ45 connector to the cable using the tool for mounting an RJ45 connector plug to a Category 5 cable. For more information about standard color schemes, see [“Wire Color Coding for category 5 cables”](#) (page 30).
5. Lead the Cat 5 cable to the 4720 DAP cabinet and connect the RJ45 connector. Push the cable into the groove.

**Figure 50**  
**Cable at rear side of the cabinet**



6. Push the cabinet onto the mounting plate.

**Note:** When pushing the 4720 DAP on to the mounting plate, make sure that you hear/feel a distinct click. This indicates that the 4720 DAP is firmly mounted to the mounting plate.





---

## Appendix

# Location builder tool

---


Use the Location Builder tool to create a site map within buildings and inside the building floors and, if necessary, lines to indicate contours or other elements that you want to draw. In this map you indicate the DAPs according to their position in the real site. The map provides an overview of the DAP structure in a building. You can store this information in a file, and import the file into the DAP Sync Analyzer tool to create an overview of the synchronization structure.

### Use the Location builder tool

Use the steps in the following procedure to start the Location builder tool.

#### Procedure 96 Starting the Location builder tool

Step	Action
1	To start the IP DECT Configurator tool through the Start menu, choose <b>Start &gt; All programs &gt; DAP controller &gt; DAP Applications &gt; Location Builder</b> . The <b>Location builder</b> window appears.



When the Location Builder initially loads, all fields are blank. The preceding figure shows example data in the fields.

2

The main window contains the following component:

- Use the **Map** pane to view a map of the area. There are two view modes:
  - **Location view** shows one whole floor with multiple buildings visible.
  - **Building view** shows a floor inside a building.

Switch between Location view and Building view by double-clicking a building. You can select either a DAP, a building, or a line.

Right-click the map to access menu commands to perform on the selected item.

The Location Builder uses coordinates for the localization of DAPs, buildings, and lines. The coordinates of the mouse pointer appear if you hover the mouse pointer over the map. The origin (0,0) of the coordinate system is in the bottom left corner of the map.

- Use the **DAP list view mode** pane to select the view mode for the DAP list:

- RPN numbers
- MAC addresses
- Info field

The DAP list shows a list of DAPs not yet on the map. You can drag these DAPs onto map.

To add values to the DAP list click **File > Import**, and add new DAPs to the **RPNadm.txt file**.

- In the **Edit box** area, you can edit properties of the selected location, building, or DAP. After editing the values in the Edit box, click **Set** to save your changes.
- Use the **Floor controls** to add or delete a floor or assign the location of a floor.
- Use the **Draw controls** to add a DAP, a building, or a line.
- Use the **View controls** to change the view of the Map pane.
- Use the **Options** controls to customize display options.

---

--End--

---

## Create a location file

Create a location file.


### Prerequisites

- Ensure that you have up-to-date maps of the building(s). You can import a map of a building or floor from a bmp, .gif and .jpg file.
- Ensure that you have a clear understanding of the sizes of the area and the buildings. Ensure that the maps use a common scale; if they do not, ensure that you understand how they differ.


### Procedure 97

#### Creating a location file

Step	Action
1	<p>To start the IP DECT Configurator tool through the Start menu, choose <b>Start &gt; All programs &gt; DAP controller &gt; DAP Applications &gt; Location Builder</b>.</p> <p>The <b>Location builder</b> window appears.</p>



- 2 Click **Create Area** to initialize the Location. The **Create Area** dialog box appears.



- 3 In the Size fields, enter values large enough to encompass all the buildings in your location.

The size values used in the location builder do not correspond to real-world units, such as meters or feet. However, Nortel recommends that you consistently enter values that equal the measurements in meters to make your location map easy to understand.

- 4 Click **Building** to add a building to the Location.
- Alternatively, you can add a building by drawing it in place; click the left mouse button to indicate the lower left corner of the building, and then click the right mouse button to access the menu, and choose **Add Building**.

The **Add Building** window appears.

- 5 Enter values for the location and the size.
- In the **x** and **y** fields, define the position of the lower left corner of the building.
  - In the **w** field, define the width (x size) of the building. Nortel recommends that you enter the actual width of the building in meters.
  - In the **h** field, define the depth (y size) of the building. Nortel recommends that you enter the actual depth of the building in meters.

After entering values for the building size and location, you can make changes by selecting the building and editing the values that appear in the **Edit** pane.

- 6 To add lines to a building, double-click on the building to which to add lines.

The **Building** view is activated.

Lines are used to add contours and shapes to buildings. The lines can provide a reference to items on the maps like stairwells, elevator shafts or oddly shaped (non rectangular) buildings.

- 7 In the **Building** view, add lines using either of the following methods:

- Add lines using the **Add lines** tool:
  - Right click in the Location area.  
A menu appears.
  - Choose **Add lines** from the menu.

**OR**


- Add lines in freehand mode:
  - Click **Line** in the draw controls box.
  - With your mouse pointer in the position where you want the line to begin, click and hold down the left mouse button.
  - Move your mouse pointer to the point where you want the line to end, and release the mouse button.
  - Repeat these steps to draw additional lines.

To make it easier to create straight lines in freehand mode, first click **snap to grid**, which will make it easier to draw straight lines. Optionally, adjust the **Grid Size**.

- 8 If your buildings have only one floor, skip this step.

To add a floor, double-click the border line of the building to which to add a floor.

A view of the building appears in the map panel. The Control pane in the bottom part of the Location Builder shows the Floor controls, as shown in the following figure.



- 9 Click **Add Floor**.

The **Add Floor** dialog box appears.

- 10 Enter the relevant data in the **Add Floor** dialog box, and click **OK**.

You can add multiple floors at one time and copy the lines of the current floor to the newly created floors. As well, you can add lines to the new floors or edit existing lines.

At this point the location is filled with buildings, the buildings have floors and the floors have lines. This is all the information you require to provide a reference framework for the position of the DAPs.

- 11 Choose one of the following:

- If you have not added information to a RPNadm.txt file, go to step 17, and manually add DAPs.

If you have added information to a PRNadm.txt file, go to step 12. and import the PRNadm.txt file

- 12 In the menu, choose **File > Import**.  
The **Import** dialog box appears.

- 13 Browse to the **RPNadm.txt** file, and select it. Click **Open**.

A dialog box appears and prompts you to indicate your preferences for the importing the RPNadm.txt file.

- 14 Ensure that **Update DAPs already located** is not checked, and click **OK**.

A list of DAPs appears on the left side of the program window.

15

Change the view mode by using the view mode selection box above the DAP list.


To move a DAP to the map, drag it onto the map. If you accidentally release a DAP on the wrong position, you can reposition it.

You can remove a DAP from the map, and return it to the DAP list. Right-click the DAP, and choose the menu command **Move To**.

After you place a DAP on the map, an autonumber function for the Info field is activated. This function works only if the following two items are true.

- The previous DAP added must have an Info field in the form {current floor number}{string}{number}, for example, 0R05. These notations are used in the Site Survey; therefore, consult the Site Survey manual for more information about the notations.
- The current DAP must have an empty Info field.


If both requirements are met, the current DAP has an Info field assigned in the form {current floor number}{string}{number + 1}, for example, 0R06. The following figure shows the RPN data and the Info field data in the Edit box pane, titled Current DAP.



16

Continue placing the DAPs until the DAP list is empty.

- 17 To manually add a DAP, right-click a point on the Map, and select **Add DAP** from the menu.  
The Add DAP dialog box appears.



The RPN and Info values are automatically filled in. Ensure that the values are correct, and click **OK**.

A DAP is created at the position you specified in the Add DAP dialog box.

- 18 Select one or more of the following options.
- Choose **File > Save** to save the location file as an .xml file. You can later import this file into the DAP Sync Analyzer tool.
  - Export the location file as a .csv file for use in the DAP Sync Analyzer. This file does not contain building information. This .csv file contains DAP information only.
  - Export the Dummy visibility file as a .txt file. This creates a flat synchronization hierarchy. Use the .txt file only if you cannot obtain a realistic visibility file.
  - Export the RPNadm file as a .txt file. This file contains the RPN data that you configured in the Location Builder tool. Normally the RPNadm file contains the RPN information from the imported RPNadm.txt file.

---

--End--

---

## Maintenance

You can change the Location configuration after you create the Location file, for example:

- You can make minor configuration changes, excluding RPNadm data. To make minor changes in the configuration, you can import

the Location file, and then select the item to update. You can edit the properties of the selected item using the Edit box.

- You can update the RPNadm.txt data by using the update utility that is part of the RPNadm.txt import function. To do so, import an updated RPNadm.txt file, and select the Update DAPs already located option. Optionally, select whether the MAC address or RPN is to take precedence. Choosing between RPN and MAC Address is necessary if, for example, a number of RPNs changed in the DAP manager, but the radios are still identical, thus having identical MAC addresses.



---

## Appendix

# Site survey example

---

The site survey is an information gathering process. The information determines customer requirements and the number of cells required to support traffic.

### Site planning example: Able-Studio

This section describes a site survey for Able-Studio, a fictitious company. Follow this example to conduct the site survey.

#### The facts for Able-Studio

- The contact is Rolf Sundby at 555-0000. A guest lab coat is necessary to be on the site. Get this lab coat from Rolf.
- The sales representative has recommended DECT.
- The location of user offices with wired IP phones often changes within the coverage area.
- Not all users have offices and desk phones. Some users only have handsets.
- The customer does not need coverage in the washrooms.
- The telephone switch room is next to the washrooms.
- The customer has no installation restrictions.

#### The site survey for Able-Studio

The technician must gather the following information to conduct a site survey.

- [“Gather survey items” \(page 220\)](#)
- [“Identify site contacts” \(page 220\)](#)
- [“Obtain site plans” \(page 220\)](#)
- [“Gather building information” \(page 221\)](#)

- “Identify existing cabling” (page 222)
- “Profile handset use” (page 223)

### **Gather survey items**

Obtain the following items before you start the site survey. The items are not customer supplied.

- Pick up the DECT tool kit (consisting of tripod and deployment tool kit).
- Get the appropriate DECT provisioning record.
- Gather a pencil, an eraser, a ruler, and colored pencils.

### **Identify site contacts**

Gather the following information and enter it into the work order and the provisioning records. The installer requires the following information.


#### **Procedure 98 Identifying site contacts**

<b>Step</b>	<b>Action</b>
1	Record company name.
2	Record the company address.
3	Record the contact name.
4	Record the contact telephone number.
5	Obtain and record scheduling times and date.
6	Obtain access to controlled areas.
7	Obtain keys or codes you need for secured site areas where radio coverage is required.
8	Obtain and record additional contact information, if required.
9	Obtain the safety equipment you require, such as a hard hat or safety glasses.
10	Record information regarding existing DECT systems in the radio coverage area.
<hr/> <b>--End--</b> <hr/>	

### **Obtain site plans**

Obtain two scaled plans. You need a scale to check wiring distances from the controller to the basestations. The scale is in the form of a measured line so it remains in proportion to the floor plan through reduction copiers.

**Figure 51**  
**Example of a site coverage floor plan**



**Procedure 99**  
**Obtaining site plans**

Step	Action
1	Obtain two site plans or maps with dimensions marked. Use one working copy to identify critical points, cell centers, and cell boundaries. Use one clean copy to attach to the site provisioning record for the installer, customer, or maintenance.
--End--	

**Gather building information**

Gather the following information and enter it into the work order.

**Procedure 100**  
**Gathering building information**

Step	Action
1	Obtain and record building identification.
2	Obtain and record information about construction materials, such as walls, floors, and ceilings.
3	Record the type facilities, such as office, hotel, factory, store.
4	Record the number of floors in the building.

If the building contains atriums, multiple floors, or floors not all the same shape or unusual conditions, see [“Deploying on multiple floors”](#) (page 63).

- 5 Record the height of floors.
- 6 Record as much information as you can obtain about the partitioning of floors.
- 7 Discuss and record the details of furniture, cupboards, and machinery in the interior of buildings on every floor.
- 8 Ask about other building details as necessary and record this information.

---

--End--

---

### Identify existing cabling

Gather the following information and enter it into the work order.

#### Procedure 101

##### Identifying existing cabling

Step	Action
1	Obtain the location of the telephone switching room.
2	Determine the total length of the existing cable.
3	Ask about the existing cabling from the DAPs to the IP Switch.  The wiring from the DAPs to the IP Switch must be at least UTP Cat 5.

---

--End--

---

### Assess radio coverage

If the customer requires the basestations be installed out of sight, this can reduce the coverage capability of each basestation. Obstacles can limit the performance of the system and increase costs.

Gather the following information and enter it into the work order.

#### Procedure 102

##### Assessing radio coverage

Step	Action
1	Record areas where radio coverage is required.
2	Record areas where radio coverage is not required.

- 3 Record external or outdoor radio coverage.
- 4 Record where radio coverage is not feasible or requires specific basestations.
- 5 Record areas excluded from radio coverage due to the proximity of sensitive electronic equipment.
- 6 Record objects inside buildings that can affect radio coverage.
- 7 Record unsuitable basestation locations, such as stone columns, air ducts or horizontally on the ceiling.
- 8 Discuss which basestations are to be installed out of sight.
- 9 Inquire about areas of special coverage, such as, elevators, stairwells, and washrooms.

---

--End--

---

### **Profile handset use**

Areas of above-average traffic density can have a low number of incumbent users but many incoming users. These can include areas such as cafeterias, restaurants, canteens, and meeting room areas where handset users tend to gather.

Another example of above-average traffic density is an environment where all occupants of an area use handsets. This area requires special planning.

Areas of below average traffic density are areas users access infrequently, such as store rooms and maintenance areas.

Obtain the following information and enter it into the work order.

### **Procedure 103 Profiling handset users**

Step	Action
1	Record the number of handset users.
2	Record an estimate of the potential growth of handset users.
3	Locate and record areas of above-average and below-average traffic density.
4	Determine and record which users have a wired IP phone in their office.
5	Determine and record the locations of user offices.

- 6 Ask about and record the mobility of the users. For example, do the users move from cell to cell, or is the area of movement restricted, such that the users remain within one cell?

---

--End--

---

---


## Appendix

# Deployment tool


---

The DECT Deployment Tool (deployment tool) determines cell centers and cell boundaries. If you have the Deployment tool shown in the following figure, read the instructions in this section.

**Figure 52**  
**Deployment tool carrying case and packing details**



**Figure 53**  
**Assembled deployment tool**



## Prepare the tool for deployment

Preparing the tool for deployment involves the following activities:

- “Charging the deployment tool battery” (page 227)
- “Charging the deployment handset battery” (page 228)

- “Assembling the deployment tool” (page 229)
- “Testing the deployment handset” (page 232)

### Charging the deployment tool battery

Charge the deployment tool battery for at least six hours before using.



#### CAUTION

##### Equipment Damage

Use the Nortel battery charger. This charger is a separately ordered item. Failure to use an automatic shutoff battery charger can damage the battery.


Do not use the battery supplied with the CT2 deployment tool. The CT2 and DECT batteries are not interchangeable.

The deployment tool charger has the following components:

- battery charger (must be ordered separately)
- battery charger cable

The following figure shows the charger for the deployment tool.

**Figure 54**  
**Deployment tool battery charger**



#### Procedure 104

##### Charging the deployment tool battery

Step	Action
1	Set up the deployment tool battery charging equipment. Remove the deployment tool battery, charger, and charger cord from the yellow case.
2	Charge the deployment tool battery. Connect the charger cord plug into the battery. Connect the red alligator clip to the positive lead of the charger and the black clip

to the negative lead of the charger. Connect the battery charger to the AC mains.

- 3 Remove the deployment tool battery from the charger after it is charged.

The battery must charge for at least 6 hours.

---

--End--

---


## Charging the deployment handset battery

### Charging time

Charge the deployment handset battery for at least 12 hours before the first use. Charge the handset at least 6 hours before subsequent use.

**Figure 55**

**Deployment handset battery charger**



### Procedure 105

#### Charging the deployment handset battery

Step	Action
1	Set up the deployment handset battery charging equipment. Remove the deployment handset battery, charger and charger cord from the yellow case.
2	Charge the deployment tool battery. Connect the charger cord to the charging stand. Connect the charger cord to the AC mains. Place the handset into the

charging stand. The red LED flashes while the handset is charging.

- 3 Remove the handset from the charger after it is ready for use.


--End--

### Assembling the deployment tool

The deployment tool is composed of the following parts (letters correspond to labels on the following figure):

- a--adjustable tripod
- b--extender arm connector
- c--extender arm swivel
- d--detente stop
- e--detente
- f--extension thumb screw
- g--telescopic extension
- h--Allen key
- i--basestation attaching thumb screw
- j--basestation
- 

**Figure 56**  
Deployment tool extension details




Charge the deployment tool battery and the deployment handset battery for at least 6 hours before use.

The deployment tool battery is composed of the following parts (letters correspond to labels on the following figure):

- a--battery mount
- b--Allen screws
- c--thumb screw
- d--battery pack
- e--guides
- f--thumb screw nut
- g--power cord
- h--power cord receptacle
- i--tripod

**Figure 57**  
**Deployment tool battery details**



**Procedure 106**  
**Assembling the deployment tool**


Step	Action
1	<p>Set up the tripod.</p> <p>Remove the tripod from the carrying case and place it upright. Lock the casters.</p>
2	<p>If required, install the extension arm fitting on the tripod. If not required, go to step 4.</p>
3	<p>If required, secure the extension arm fitting.</p> <p>Use the Allen key attached to the extender arm to secure the extension arm fitting Allen screw.</p>
4	<p>Mount the extension arm on the tripod.</p> <p>Place the brass end of the extension arm into the fitting, so that the keying hole of the extension arm mates with the retaining thumb screw locking device of the tripod fitting. The thumb screw locking device clicks into the keying hole of the extension arm.</p>
5	<p>Position the extension arm.</p> <p>Orient the arm into the proper position. Secure the tripod fitting and the extension arm thumb screw.</p>
6	<p>Affix the basestation to the extension arm.</p> <p>Remove the basestation from the yellow case. Mount the basestation onto the end of the arm. Screw the brass thumb screw on the arm into the bottom of the basestation and secure it in place with the grey lock thumb screw.</p>
7	<p>Position the antenna.</p> <p>Rotate the antenna from the stowed position, against the body of the basestation, to the upright operating position.</p>
8	<p>Position the basestation. The normal position is with the antenna pointing upwards.</p> <p>Secure the basestation with the arm thumb screw.</p>
9	<p>Mount the battery fixture on the tripod.</p> <p>Remove the battery bracket, shown in <a href="#">Figure 57 "Deployment tool battery details" (page 230)</a>, from the yellow case. Screw the battery bracket onto the tripod caster brace by using the two machine screws.</p>
10	<p>Mount the battery.</p> <p>Pull the release pin on the bracket back and slide the battery grooves on to the bracket. Ensure the bracket pin locks into the battery.</p>

- 11
- Connect the basestation to the battery.  
Plug the basestation power cord connector into the upper right edge of the battery.

--End--

Testing the deployment handset

Figure 58  
Handset display and keypad details



Procedure 107  
Entering the monitor mode

Step	Action
1	Ensure that the basestation is installed and supplied with power.
2	To turn the handset on, press the <b>Shift</b> key and press the <b>ON/OFF</b> button. <b>DECT HANDSET</b> appears on the handset display.



- 3 To select system mode, press the **shift** key and press the **local** key.  
**SYSTEM** appears on the handset display.
- 4 To select monitor mode, press the **star (\*)** key.  
**MONITOR MODE** appears on the handset display.
- 5 To select the monitor mode code, press the **lock** button. The handset displays  
**CODE** appears on the handset display.
- 6 To enter the monitor mode code, on the dial pad, enter **2530**. Press the **Lock** button.
- 7 Interpret the handset RSSI display and test tone.  
See the explanation in [“How the deployment tool works”](#) (page 233) and [“Using the deployment tool”](#) (page 234).

---

--End--

---

## How the deployment tool works

The deployment tool basestation and the deployment handset establishes a radio link under the following circumstances:

- the handset is in the deployment mode
- the handset and basestation are within range of one another

The closer the handset is to the basestation the stronger the link. As the handset moves away from the basestation, a point is reached where the signal is no longer reliable for telephone conversations.

After a link is established, the handset emits a continuous 1.4 kHz tone and displays an RSSI value.

**Figure 59**  
**Deployment handset link display**



553-8069.EPS

The display, shown in [Figure 59 "Deployment handset link display" \(page 233\)](#), indicates the following.

- A dot within a circle indicates a locked signal.
- The antenna symbol indicates a link establishment.
- The number 10 indicates an RSSI value.
- The dash, equal sign and shaded box icons indicate signal strength.

The maximum RSSI is 10. As signal strength diminishes, the number 10 decreases and the icons disappear. For example, at signal strength 7, the three shaded boxes that are on the right side of the display disappear. At signal strength 5, all the shaded boxes and one of the equal sign icons disappear.

The signal strength diminishes as the distance between the handset and the basestation increases. The tone remains unchanged until the handset is out of range of the basestation.

## Using the deployment tool

Assemble the deployment tool as shown in [Figure 53 "Assembled deployment tool" \(page 226\)](#), with the extension arm parallel to the floor. Position the basestation antenna upwards. Place the basestation as close to the wall as possible and at the height recommended for basestations.

To test the deployment tool, stand in an open area approximately 3 to five 5 from the deployment tool tripod. Establish a link between the basestation and the handset. Keep the deployment tool basestation in plain view. Ensure no obstructions exist (including people).

Walk away from the basestation and observe the deployment handset link display. As the deployment handset moves away from the basestation, the RSSI value changes. After the RSSI value changes from 7 to 6 (–80 dBm to –85 dBm) and the last shaded block disappears, the cell boundary is reached.

After the cell boundary is reached, stop and listen to the tone. Ensure the tone is clear with no tone changes, tone breakup, modulation, mutes or clicks.

Do not select a cell edge that has an RSSI reading of less than 6. However, keep the following in mind:

- Some environments can cause poor tone at a RSSI meter reading of 7 to 10. In this case, contact the Nortel Help desk for assistance.
- The tone stops after the radio link is lost.

For more information about deployment requirements, see [“Radio synchronization” \(page 21\)](#).

### Handset tones interpretation

The handset tones indicate how close the handset is to the deployment tool basestation.

- Steady tone--the handset is within the cell boundary, or at the cell boundary edge.
- Tone change, tone breakup, modulation, mute or click--the handset is beyond cell boundary edge.

Take the following precautions:

- Do not use the deployment tool on windy days.
- Do not use the deployment tool in bad weather.
- Keep all personnel away from the apparatus.
- Follow all safety requirements.
- Use batteries to power the deployment tool.
- Charge the batteries indoors.

### Rules for outdoor deployment

#### Procedure 108

#### Complying with the rules for outdoor deployment

Step	Action
1	Cover outdoor areas before covering indoor areas. Use the deployment tool to determine outdoor cell centers.
2	Use the deployment handset to determine the outdoor coverage provided by a basestation located indoors.
3	External housings for outdoor basestations must be mounted directly on walls or similar vertical surfaces.
4	If you use the deployment tool outdoors, ensure the deployment tool does not fall over or come in contact with electrical wires and cables.
5	If an outdoor critical point cannot be reached, inform the customer.

---

--End--

---



## Appendix

# Install the external housing

### ATTENTION

The cabling to the C4710/4720 is Category 5 Ethernet cabling. However, the cabling and C4710E/4720E is submitted to the following safety restriction: The cabling and/or the C4710E/4720E may never be exposed to over-voltages (for example, lightning). Therefore, the C4710E/4720E and cabling associated with it may never be installed outdoors. However there is an exception: if installed in the Outdoor Cabinet, and the Outdoor Cabinet is mounted against a wall and the cable is led directly indoors, it is permitted.

Consult the work order, and perform the steps in this section as required:

- [“Installing 4720 DAP with internal antennas” \(page 237\)](#)
- [“Installing a C4710 basestation in an external housing” \(page 248\)](#)
- [“Installing a C4710E basestation in an external housing with an external antenna” \(page 251\)](#)
- [“Mounting the cabinet on a wall” \(page 253\)](#)
- [“Mounting the cabinet on a pole” \(page 254\)](#)

## Installing 4720 DAP with internal antennas


Installing the Outdoor Box with 4720 DAP with internal antennas:

### Procedure 109

#### Installing the Outdoor Box with 4720 DAP with internal antennas


Step	Action
1	Open the Cabinet. To open the cabinet, use a screw driver that fits into the four plastic screws at the front side of the cabinet. Unfasten the screws.
2	Remove the cover from the cabinet. The contents of the cabinet is shown in <a href="#">Figure 60 "Contents of the box" (page 238)</a> .

**Figure 60**  
**Contents of the box**



- 3 Remove the foam contents from the cabinet.
- 4 At the right hand side of the cabinet, you must drill a hole for the cable inlet. Mark the hole as shown in [Figure 61 "Position of the hole in the cabinet"](#) (page 238).

**Figure 61**  
**Position of the hole in the cabinet**



- 5 Drill a hole for the swivel. Use a 12 mm drill.

**Figure 62**  
**Drilling the hole (12 mm)**



- 6 Mount the swivel in the hole that you have drilled. Do not forget to install the rubber ring to seal the conjunction between the swivel and the cabinet. The conjunction must be waterproof.

**Figure 63**  
**Swivel with black rubber ring**




**Figure 64**  
**Swivel mounted to the cabinet**



- 7 Put the foam back into the cabinet.
- 8 Keep the cabinet in the correct position against the wall and mark the mounting holes in the corners of the cabinet on the wall. If necessary, use the template that was delivered with the cabinet.


**Figure 65**  
**Marking the corner holes on the wall**



- 9 Drill the holes in the wall using an appropriate drill that is applicable for the wall.


- 10 Mount the cabinet to the wall. Use appropriate screws and plugs.

**Figure 66**  
**Mounting the cabinet to the wall**



- 11 Push the special nuts that came with the cabinet into the corner holes of the cabinet.

**Figure 67**  
**Pushing the special nuts in place in the corners of the cabinet**




- 12 Lead the cable via the swivel into the cabinet.

**Note:** The cable length in the cabinet must be 20 cm (this includes the RJ45 connector which you must mount to the cable later).

**Note:** At the outside of the box, the cable must lead directly from the cabinet into the building to avoid exposing the cable to lightning.

- 13 Tighten the cable inlet on the swivel and make sure that the cable inlet is waterproof.
- 14 Lead the cable to the 4720 DAP and mount the RJ45 connector to it using the tool for mounting an RJ45 connector plug to a Category 5 cable. For more information on standard color schemes, see ["Wire Color Coding for category 5 cables"](#) (page 30)


**Figure 68**  
**Cable run in the Cabinet**



**15** Connect the RJ45 connector to the 4720 DAP (at the rear side) and push the Category 5 Ethernet cable into the round foam-free area in the rear side of the cabinet.


**16** Push the 4720 DAP into its position in the foam.

**Figure 69**  
**4720 DAP in position in the cabinet**



**17** Mount the cover of the cabinet onto the cabinet with the four plastic screws in each corner of the cover. The cabinet is now closed.

**Figure 70**  
**Mounting the cover**



---

--End--

---

**Installing a DAP/RFP with external antennas**


Before you start installing the cabinet, make sure you have the installation materials as described below.

Also make sure you have the 4720E version together with the directional antenna and two equal cables for connecting the directional antenna to the 4720E.

**Procedure 110**  
**Installing the Outdoor Box with 4720E with directional antenna**

Step	Action
1	Open the Cabinet. To open the cabinet, use a screw driver that fits into the four plastic screws at the front side of the cabinet. Unfasten the screws.
2	Remove the cover from the cabinet. The contents of the cabinet is shown in the figure


**Figure 71**  
**Contents of the box**



3            Remove the foam contents from the cabinet.

- 4 At the right hand side of the cabinet, you will have to drill a hole for the cable inlet. Mark the hole as follows:

**Figure 72**  
**Position of the hole in the cabinet**



- 5 Drill a hole for the swivel. Use a 12 mm drill.

**Figure 73**  
**Drilling the hole (12 mm)**



- 6 Mount the swivel in the hole that you have drilled. Do not forget to install the rubber ring to seal the conjunction between the swivel and the cabinet. The conjunction must be waterproof.

**Figure 74**  
**Swivel with black rubber ring**




**Figure 75**  
**Swivel mounted to the cabinet**




- 7 Put the foam back into the cabinet.
- 8 Keep the cabinet in the correct position against the wall and mark the mounting holes in the corners of the cabinet on the wall. If necessary use the template that was delivered with the cabinet.

**Figure 76**  
**Marking the corner holes on the wall**



- 9 Drill the holes in the wall using an appropriate drill that is applicable for the wall.
- 10 Mount the cabinet to the wall. Use appropriate screws and plugs.


**Figure 77**  
**Mounting the cabinet to the wall**



- 11 Push the special nuts that came with the cabinet into the corner holes of the cabinet.

Figure 78

Pushing the special nuts in place in the corners of the cabinet



- 12 Lead the cable via the swivel into the cabinet.


**Note:** The cable length in the cabinet must be 20 cm (this includes the RJ45 connector which you have to mount to the cable later on).

**Note:** At the outside of the box, the cable must be led directly from the cabinet into the building to avoid exposing the cable to lightning.


- 13 Tighten the cable inlet on the swivel and make sure that the cable inlet is waterproof.
- 14 Mount the RJ45 connector to the cable using the tool for mounting an RJ45 connector plug to a Category 5 cable. For more information on standard colour schemes, see ["Wire Color Coding for category 5 cables"](#) (page 30).
- 15 Open the 4720E box by means of removing the two screws at the rear side of the 4720E.
- 16 Use a small pair of tongs to open the predefined holes in the 4720E cabinet.

Figure 79

4720 DAP cabinet and pair of tongs




**Figure 80**  
Detail of the 4720 DAP of predefined hole in the 4720 cabinet



- 17** Connect the RJ45 ethernet plug to the 4720E and mount the antenna cables to it. Also connect the other end of the cables to the directional antenna.

**Note:** Use the SMA Torque Wrench to fasten the coax nuts on the 4720E. Otherwise you can easily damage the screw-thread.

**Figure 81**  
Connecting the cables to the 4720E



- 18** Close the 4720E box and mount the two screws at the rear side of the 4720E box.
- 19** Connect the RJ45 connector to the 4720 DAP (at the rear side).
- 20** Push the 4720E into its position in the foam.
- 21** Lead the coax antenna cables via the top side of the foam and determine the position of the directional antenna. Note that the hole in the foam is not big enough for the antenna. This is done on purpose, in order to allow various positions of the direction antenna.

**Figure 82**  
**Antenna does not fit into the hole**



**22** Cut the hole for the directional antenna to the correct size, to be able to push the antenna in the hole.

**Figure 83**  
**Cutting the foam to allow the antenna to fit into it, in the required position**



**Figure 84**  
**Cutting the foam to allow the antenna to fit into it, in the required position**



**23** Lead the coax cables to the antenna via the groove in the top of the foam and push the antenna into its final position into the foam.


**Note:** You can change the position of the antenna to the required position in the foam, by means of turning the antenna or giving it some tilt.

**Figure 85**  
**4720 DAP and directional antenna in their positions**



- 24** Mount the cover of the cabinet onto the cabinet with the four plastic screws in each corner of the cover. The cabinet is now closed.

**Figure 86**  
**Mounting the cover**



---

--End--

---

## Installing a C4710 basestation in an external housing

Install a C4710 basestation in an external housing

### Procedure 111 Installing a C4710 basestation in an external housing

Step	Action
1	Unlock the cabinet, and open the cabinet door.
2	Remove the foam cover and foam blocks from the cabinet.
3	Mount the swivel, and route the incoming cable through the swivel.
4	Verify that the cable fits snugly into the waterproof inlet housing.
5	Connect the incoming cable to the connection box that is delivered with the outdoor cabinet.

- 6 Connect the CAT5 cable that is inside the outdoor cabinet to the connector box.



- 7 Place the foam below the foam blocks.



- 8 Connect the Ethernet CAT5 to the basestation as shown.



- 9 Push the basestation into the foam.



- 10 Place the cover foam into position.



- 11 Close and lock the cabinet.

---


--End--

---


## Installing a C4710E basestation in an external housing with an external antenna

Install a C4710E basestation in an external housing with an external antenna.

Step	Action
1	Unpack the C4710E basestation.
2	Open the cabinet of the basestation: <ul style="list-style-type: none"><li>• Remove the two screws at the rear side of the cabinet.</li><li>• Separate the cover and the rear side from each other.</li><li>• The cabinet is held shut by four click parts, two on each long side of the cabinet. If necessary, use a small screwdriver to carefully open the click parts one at a time.</li></ul>
3	Drill two holes (10 mm in diameter) in the rear side of the cabinet.



- 4 Connect the antenna cables to the connectors on the printed circuit board. Secure the nuts with an SMA Torque Wrench.



- 5 Snap the cover of the C4710E basestation to the rear side, to close the basestation cabinet. Fasten the cabinet by mounting the two screws into the two holes in the rear side of the cabinet.
- 6 Unlock the cabinet, and open the cabinet door.
- 7 Remove the foam cover and foam blocks from the cabinet.
- 8 Mount the swivel, and route the incoming cable through the swivel.
- 9 Verify that the cable fits snugly into the waterproof inlet housing.
- 10 Connect the incoming cable to the connection box that is delivered with the outdoor cabinet.
- 11 Connect the CAT5 cable that is inside the outdoor cabinet to the connector box.



- 12 Connect the Ethernet CAT5 cable to the C4710E basestation. Place the basestation in the outdoor cabinet and install the foam.



- 13 Connect the antenna cables to the antenna.
- 14 Place the cover foam in position then place the antenna in the foam.
- 15 Close and lock the outdoor cabinet.

**ATTENTION**

Ensure that the C4710E basestation is line powered through the Ethernet cable. Local power provision is not possible in this outdoor cabinet.

---


--End--

---

## Mounting the cabinet on a wall

Mount the cabinet on a wall.

Step	Action
1	<p>Install the wall mount set on the back of the cabinet.</p> <p>You can configure the wall mount set for vertical or horizontal mounting; select the mounting style before you install the mounting set on the cabinet.</p>
2	<p>Use the drilling jig to mark the positions where holes are needed on the wall, and drill the holes.</p> <p>You can configure the wall mount set for vertical or horizontal mounting; ensure that you orient the jig to match the mounting orientation you selected in the previous step.</p>
3	<p>Mount the cabinet to the wall.</p>



---


--End--

---

## Mounting the cabinet on a pole

Mount the cabinet on a pole.

Step	Action
1	Mount the bracket to the back of the cabinet.
2	Connect the metal strip to the bracket using the bolt that is provided for this purpose.
3	Place the cabinet against the pole.
4	Route the metal strip around the pole and connect the metal strip to the other side of the bracket using the supplied bolt.
5	Ensure that the cabinet is at the desired height, and tighten the metal strip around the pole by twisting the bolt.
6	Secure the metal strip with the lock-nuts.



--End--



## Appendix


# Upgrade a SIPN connection to a SIPL connection

---

Prior to Communication Server 1000 (CS 1000) Release 7.0 SIP clients could connect by using the SIPN connection method. Beginning in CS 1000 Release 7.0, support is no longer available for the SIPN connection method; however, you can migrate your SIPN connection to a SIPL connection.

[Figure 87 "Upgrade to a SIPL connection" \(page 258\)](#) shows the high-level tasks for migrating to a SIPL connection.

**Figure 87**  
**Upgrade to a SIPL connection**



## SIPL deployment

To upgrade to the SIPL connection method, you must deploy the SIP Line application to a server. For information about deploying the SIP Line application, see *Linux Platform Base and Applications Installation and Commissioning* (NN43001-315).

## Convert SIPN/SIP3 TNs to SIPL UEXT TNs

You must convert all SIPN TNs to SIPL UEXT TNs to upgrade to a SIPL connection. You can manually configure new values for the TNs, or you can use the SIP Line Conversion Utility (SIPLCU) to configure values for multiple TNs. Nortel recommends that you use the SIPLCU when you configure values for 25 or more TNs. For information about installing the SIPLCU, see (NN43001-508).

[Procedure 112 “Configuring new TN values using the SIPLCU” \(page 259\)](#) provides a high-level procedural view of the steps to convert SIPN TNs to SIPL UEXT TNs by using the SIPLCU.

**Note:** The SIPLCU includes a built-in Help menu, that provides detailed operating instructions for using the utility.

### Procedure 112 Configuring new TN values using the SIPLCU

Step	Action
1	Connect to the CS 1000 Call Server.
2	Retrieve the current configuration details for the SIPN UEXT TNs, and store the configuration details in a temporary file.
3	Modify the file to provide the required new details for SIPL UEXT (SIPU, ZONE, NDID, SCPW, HOT U DN).
	<b>Note:</b> For more information about UEXT configuration, see <a href="#">“Configuration of Universal Extension on a Call Server” (page 128)</a> .
4	Convert the TNs on the CS 1000 Call Server.
--End--	

## SIP DECT system upgrade

To upgrade your SIP DECT system from SIPN to SIPL connection type (through SIP Line Gateway), perform the following:

Step	Action
1	Upgrade your DAP Controller to version 5.0. For more information, see <a href="#">“DAP controller software” (page 83)</a> .
2	Select SIP on CS1000 SIPL and the required firmware package as described in the procedure <a href="#">Procedure 44 “Adding a new system using the IP DECT Configurator” (page 113)</a> .

- 3 Enter the Proxy IP address, which is the SIP LINE Gateway Node IP address as described in the procedure [Procedure 45 “Configuring IP Settings”](#) (page 114).
- 4 Enter SIP settings as described in the procedure [Procedure 48 “Configuring SIP Settings”](#) (page 117).
- 5 Enter PBX setting for conference as described in the procedure [Procedure 50 “Configuring other settings—PBX Settings”](#) (page 120).
- 6 Save your system and reboot DAPs as described in the procedure [Procedure 53 “Saving the system”](#) (page 123).

---

--End--

---

---

## Appendix

# Third Party Software

---

Within the SRTP and TLS, open libraries are applied. The following text applies to these open libraries:

### SRTP

For SRTP the libSRTP library version 1.4.4 is applied. The following license text is applicable to the SRTP library:

Copyright (c) 2001-2006 Cisco Systems, Inc. - All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the Cisco Systems, Inc. nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE

OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

## TLS

For TLS the OpenSSL library version OpenSSL 0.9.8e is applied. The following license text is applicable to the OpenSSL Library:

OpenSSL License:

Copyright (c) 1998-2007 The OpenSSL Project. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgment: "This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit. (<http://www.openssl.org/>)"
4. The names "OpenSSL Toolkit" and "OpenSSL Project" must not be used to endorse or promote products derived from this software without prior written permission. For written permission, please contact [openssl-core@openssl.org](mailto:openssl-core@openssl.org).
5. Products derived from this software may not be called "OpenSSL" nor may "OpenSSL" appear in their names without prior written permission of the OpenSSL Project.
6. Redistributions of any form whatsoever must retain the following acknowledgment: "This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (<http://www.openssl.org/>)"

THIS SOFTWARE IS PROVIDED BY THE OpenSSL PROJECT "AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OpenSSL PROJECT OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS

INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This product includes cryptographic software written by Eric Young (eay@cryptsoft.com).

This product includes software written by Tim Hudson (tjh@cryptsoft.com).

Original SSLeay License Copyright (C) 1995-1998 Eric Young (eay@cryptsoft.com). All rights reserved.

This package is an SSL implementation written by Eric Young (eay@cryptsoft.com). The implementation was written so as to conform with Netscape SSL.

This library is free for commercial and noncommercial use as long as the following conditions are adhered to. The following conditions apply to all code found in this distribution, be it the RC4, RSA, lhash, DES, etc., code; not just the SSL code.

The SSL documentation included with this distribution is covered by the same copyright terms except that the holder is Tim Hudson (tjh@cryptsoft.com).

Copyright remains Eric Young's, and as such any Copyright notices in the code are not to be removed. If this package is used in a product, Eric Young should be given attribution as the author of the parts of the library used. This can be in the form of a textual message at program startup or in documentation (online or textual) provided with the package.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgement: "This product includes cryptographic software written by Eric Young (eay@cryptsoft.com)"

The word 'cryptographic' can be left out if the routines from the library being used are not cryptographic related.

4. If you include any Windows specific code (or a derivative thereof) from the apps directory (application code) you must include an acknowledgement: "This product includes software written by Tim Hudson (tjh@cryptsoft.com)"

THIS SOFTWARE IS PROVIDED BY ERIC YOUNG "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The licence and distribution terms for any publicly available version or derivative of this code cannot be changed. i.e. this code cannot simply be copied and put under another distribution licence, including the GNU Public Licence.

---

# Index

---

## A

Adding a DN range 158  
 Adding number range 126  
 Assess radio coverage 222

## B

Basic (or Simple) Configuration 31  
 Built-in DHCP and TFTP servers 101  
 Built-in DHCP server 102  
 Built-in TFTP server 103

## C

Call server software 83  
 CallPilot and Message Waiting  
     Indication (MWI) support 16  
 Central directory access tool 170  
 Change a DAP RPN 156  
 Check IIS on PC with Windows 2000 85  
 Check IIS on PC with Windows XP 90  
 Checking IIS on a PC with Windows  
     2003 88  
 Choice of system configuration 133  
 Configuration of settings using IP DECT  
     Configurator 112  
 Configuration of Universal Extension on  
     a Call Server 128  
 Configuration without a DHCP or  
     TFTP 103  
 Configuring SIP DECT for Central  
     directory access 173  
 Configuring Universal Extension 139  
 Create a location file 211  
 Creating an Excel file for the central  
     database 171

## D

DAP AC adaptor part numbers 29  
 DAP Controller 106  
 DAP controller software 83  
 DAP Controller software deinstallation 193  
 DAP controller software, internet  
     information services 84  
 DAP management 156  
 DAP manager configuration 125  
 DAP manager overview 147  
 DAP restart history  
     DAP reboot history 164  
 DECT handset features 15  
 Deleting a number 152  
 DHCP and TFTP servers 91  
 Disabling a subscription 151

## E

Editing a subscription RPN 150  
 Export a SIP DECT system 190  
 Export and import SIP DECT system 190  
 Export subscriptions 161

## G

Gather building information 221  
 Gather survey items 220

## H

Handset firmware update 166  
 Handset status 154

## I

Identify existing cabling 222  
 Identify site contacts 220  
 Import a SIP DECT system 191

Import and export subscriptions 138  
Import subscriptions 164  
Install and maintain IIS on Microsoft  
Windows 2000 84  
Install and maintain IIS on Microsoft  
Windows 2003 86  
Install and maintain IIS on Microsoft  
Windows XP 89  
Install IIS on PC with Windows 2000 85  
Install IIS on PC with Windows XP 89  
Installation of the Central directory  
access tool 172  
Installing IIS on a PC with Windows  
2003 86  
Internet information services 84  
IP DECT configuration tools 11

## M

Maintenance 216  
Microsoft Windows 2000 and 2003  
DHCP and TFTP servers 92  
Multiple-site mobility network  
configuration 136

## N

Network packet capture traces 199

## O

Obtain site plans 220  
Overview of SIP DECT 11

## P

Product overview 11  
Profile handset use 223

## R

Remove and replace a DAP 181  
Removing a subscription 152  
Restarting a DAP 157  
Restarting all DAPs 157  
Restarting DECT Access Points 125  
Restarting IIS on a PC with Windows  
2003 88  
Reviewing DAP reboot history 164  
Routed Head Quarter configuration 31  
, 132  
Routed Head Quarter Configuration  
with Branch Office 135

## S

Signaling server software 83  
Simple SIP DECT configuration 111  
SIP DECT capacity limitations 17  
SIP DECT configuration figure 13  
SIP DECT five main components 11  
SIP Line Gateway configuration 128  
Site planning example (Able-Studio) 219  
Site survey process 219  
Software deinstallation 193  
Software requirements 83  
Software requirements, call server  
software 83  
Software requirements, DAP controller  
software 83  
Software requirements, signaling server  
software 83  
Subscribing a DECT handset 126  
Subscribing a handset 149  
Subscription export and import 161  
Subscription management 149  
Supported database types 171  
Synchronization analyzer interface 183  
Synchronization analyzer location  
page 185  
Synchronization analyzer main page 183  
Synchronization analyzer portable  
tracking page 187  
System administration 147  
System archive 165, 199  
System backup 160  
System configuration (SIPL) 111  
System maintenance 175  
System survey 198  
System synchronization analysis 182

## T

TFTP server 98

## U

Universal extension support 14  
Using the filter 153  
Using the location builder tool 209



Nortel Communication Server 1000

## SIP DECT Fundamentals

Release: 7.0

Publication: NN43120-123

Document revision: 03.01

Document release date: 4 June 2010

Copyright © 2008-2010 Nortel Networks. All Rights Reserved.

While the information in this document is believed to be accurate and reliable, except as otherwise expressly agreed to in writing NORTEL PROVIDES THIS DOCUMENT "AS IS" WITHOUT WARRANTY OR CONDITION OF ANY KIND, EITHER EXPRESS OR IMPLIED. The information and/or products described in this document are subject to change without notice.

Nortel, Nortel Networks, the Nortel logo, and the Globemark are trademarks of Nortel Networks.

All other trademarks are the property of their respective owners.

To provide feedback or to report a problem in this document, go to [www.nortel.com/documentfeedback](http://www.nortel.com/documentfeedback).

[www.nortel.com](http://www.nortel.com)

