

0  
0  
0

297-2121-228  
VINTAGE 02.01  
STANDARD

0

---

0 DIGITAL SWITCHING SYSTEMS

0 DMS\*-100 FAMILY DATAPATH\*

0 3270 NETWORK SWITCHED ACCESS WITH 3194  
0 DISTRIBUTED FUNCTION TERMINALS SUPPORT

0 INSTALLATION AND MAINTENANCE

0

---

0 \* DMS and DATAPATH are trademarks of Northern Telecom.

0 297-2121-228  
0 VINTAGE 02.01

0 (c) Northern Telecom 1988, 1989

CONTENTS

0 CHAPTER 1: INTRODUCTION TO 3270 NETWORK SWITCHED ACCESS

0 | PRACTICE APPLICATION . . . . . 1-1

0 | REASON FOR REISSUE . . . . . 1-1

0 SOFTWARE IDENTIFICATION . . . . . 1-1

0 3270 NETWORK SWITCHED ACCESS . . . . . 1-1

0 CAPABILITIES . . . . . 1-1

0 CONFIGURATION . . . . . 1-2

0 Switched Configuration . . . . . 1-2

0 Non-switched Configuration . . . . . 1-4

0 Compatibility . . . . . 1-4

0 APPLICATIONS . . . . . 1-5

0 Control Units . . . . . 1-5

0 CUT Mode Devices . . . . . 1-5

0 CUT Mode Features . . . . . 1-6

0 DFT mode Devices . . . . . 1-6

0 DFT Mode Features . . . . . 1-6

0 DMS-100 Features . . . . . 1-7

0 | Printer Support . . . . . 1-9

0 REFERENCES . . . . . 1-10

0 CHAPTER 2: EQUIPMENT DESCRIPTION AND SPECIFICATIONS

0 CONTROL UNIT INTERFACE SHELF - DESCRIPTION . . . . . 2-1

0 SHELF - SPECIFICATIONS . . . . . 2-3

0 Mechanical Specifications . . . . . 2-3

0 Electrical Specifications . . . . . 2-4

0 Environmental Specifications . . . . . 2-4

0 Regulatory Compliance . . . . . 2-4

0 CONTROL UNIT INTERFACE - DESCRIPTION . . . . . 2-5

0 CONTROL UNIT INTERFACE - SPECIFICATIONS . . . . . 2-6

0 Mechanical Specifications . . . . . 2-6

0 Electrical Specifications . . . . . 2-6

0 Environmental Specifications . . . . . 2-6

0 Regulatory Compliance . . . . . 2-7

0 iii

0	297-2121-228	
0	VINTAGE 02.01	
0	TERMINAL INTERFACE - DESCRIPTION . . . . .	2-8
0	TERMINAL INTERFACE - SPECIFICATIONS . . . . .	2-9
0	Mechanical Specifications . . . . .	2-9
0	Electrical Specifications . . . . .	2-9
0	Environmental Specifications . . . . .	2-10
0	Regulatory Compliance . . . . .	2-10
0	CABLE SPECIFICATIONS . . . . .	2-11
0	Coax Cable . . . . .	2-11
0	Twisted-pair Cable . . . . .	2-11
0	CHAPTER 3:  INSTALLING A DATA LINE FOR 3270 NETWORK SWITCHED	
0	ACCESS	
0	SWITCHED CONFIGURATION . . . . .	3-3
0	Datafill . . . . .	3-3
0	Twisted-pair Cabling Requirements . . . . .	3-6
0	NON-SWITCHED CONFIGURATION . . . . .	3-8
0	Cabling Requirements . . . . .	3-8
0	CHAPTER 4:  INSTALLING THE 3270 NETWORK SWITCHED ACCESS EQUIPMENT	
0	INSTALLING THE CONTROL UNIT INTERFACE SHELF . . . . .	4-1
0	Equipment Required . . . . .	4-1
0	Installation Procedure . . . . .	4-1
0	INSTALLING THE CONTROL UNIT INTERFACE . . . . .	4-2
0	Equipment Required . . . . .	4-2
0	Installation Procedure . . . . .	4-2
0	INSTALLING THE TERMINAL INTERFACE . . . . .	4-5
0	Equipment Required . . . . .	4-5
0	Installation Procedure . . . . .	4-5
0	CHAPTER 5:  VERIFYING THE DATA CONNECTION	
0	SWITCHED CONFIGURATION . . . . .	5-1

0 Data Call . . . . . 5-1  
0 Terminal Display . . . . . 5-1  
0 SETTING UP A DATA CALL . . . . . 5-4  
0 Setting Up a Data Call Using Datapath Keyboard Dialing 5-4  
0 Setting Up a Data Call Using Automatic Dialing . . . 5-4  
0 Setting Up a Data Call Using Speed Dialing . . . . . 5-5  
0 Ringing a Directory Number Again . . . . . 5-6  
0 Aborting a Data Call Prior to Connection . . . . . 5-6  
0 Taking Down a Data Call . . . . . 5-7  
0 Programming the Number to be Auto Dialed . . . . . 5-7  
0 Programming the List of Speed Dialing Directory Numbers 5-8  
0 NON-SWITCHED CONFIGURATION . . . . . 5-8

0 CHAPTER 6: DIAGNOSTICS AND TROUBLESHOOTING

0 EQUIPMENT SELF-TESTS . . . . . 6-1  
0 Control Unit Interface Circuit Pack Self-Test . . . . 6-1  
0 Terminal Interface Self-Test . . . . . 6-1  
0 PHYSICAL CHANNEL CHECKS . . . . . 6-3  
0 TROUBLESHOOTING . . . . . 6-5  
0 TROUBLESHOOTING FROM THE MAP . . . . . 6-14

0 CHAPTER 7: ACRONYMS AND ABBREVIATIONS

0 ILLUSTRATIONS

0 FIGURES

0 1.1 Switched Configuration . . . . . 1-3  
0 1.2 Non-switched Configuration . . . . . 1-4  
0 1.3 Data Unit Compatibility . . . . . 1-5  
0 2.1 Control Unit Interface Shelf - Front View . . . . . 2-1  
0 2.2 CUIF Shelf - Mounting Hole Dimensions . . . . . 2-2  
0 2.3 Control Unit Interface Shelf - Rear View . . . . . 2-3  
0 2.4 CUIF Circuit Pack - Front and Side View . . . . . 2-5  
0 2.5 Terminal Interface - Rear and Top View . . . . . 2-8  
0 3.1 Switched Configuration vs Non-switched Configuration 3-2  
0 3.2 Connection from TIF Modular Jack to DLC . . . . . 3-6  
0 3.3 Connections to CUIF Pairs . . . . . 3-7  
0 3.4 Connection from TIF to CUIF . . . . . 3-8  
0 4.1 SW1 Switch Settings . . . . . 4-2

0	297-2121-228		
0	VINTAGE 02.01		
0	4.2	SW2 Switch Slide Settings . . . . .	4-3
0	5.1	KBD Screen Display . . . . .	5-2
0	6.1	Screen Display of Channel Errors . . . . .	6-3
0	TABLES		
0	3.1	SERVORD Entries for 3270 Network Switched Access . .	3-3
0	6.1	3270 Network Switched Access Troubleshooting . . . .	6-5

0  
0

297-2121-228  
VINTAGE 02.01

0

---

0 CHAPTER 1

0 INTRODUCTION TO 3270 NETWORK SWITCHED  
0 ACCESS

0

---

0 297-2121-228  
0 VINTAGE 02.01

PRACTICE APPLICATION

The information contained in this Practice applies to offices having Batch Change Supplement release 29 (BCS29) software.

It also applies to offices having a BCS release greater than 29, unless reissued. The application of all Northern Telecom Practice (NTP) editions with respect to a given BCS release is given in 297-1001-001, Master Index of Practices.

REASON FOR REISSUE

This Practice has been reissued to include printer support for 3287 type printers, as described in this chapter.

SOFTWARE IDENTIFICATION

Datapath 3270 Network Switched Access features are contained in the software package NTX250AA.

3270 NETWORK SWITCHED ACCESS

3270 Network Switched Access (NSA) is a means of connecting IBM\* type terminals to cluster control units using single twisted-pair wiring.

3270 NSA requires two units: a Control Unit Interface (CUIF), and a Terminal Interface (TIF). The CUIF connects to the IBM control unit. The TIF connects to the IBM terminal.

3270 NSA with 3194 Distributed Function Terminals (DFT) functionality supports both the Control Unit Terminal (CUT) devices and the 3194 DFT devices, and uses the NT4X25DA CUIF and NT4X25AL TIF. 3270 NSA without 3194 DFT support uses the NT4X25AM CUIF and NT4X25AL TIF, and is described in 297-2121-225.

CAPABILITIES

3270 Network Switched Access:

---

\*IBM is a trademark of International Business Machines.

0 297-2121-228  
0 VINTAGE 02.01

- 0 \* provides switched access to different IBM mainframes or non-switched access to specific IBM mainframes
- 0 \* reduces coaxial (coax) cable length requirements
- 0 \* uses twisted-pair connections to extend the allowable separation distance between the terminal and the control unit.
- 0 \* provides a single, unified wiring plan, and maintains integrity by using single twisted-pair wiring
- 0 \* provides IBM control unit port sharing
- 0 \* allows for easier and simpler moves and changes of equipment
- 0 \* provides full screen Man-Machine Interface
- 0 \* provides full support for Systems Network Architecture (SNA) protocol
- 0 | \* supports IBM 3287 type printers.

## 0 CONFIGURATION

0 3270 NSA can be configured for two kinds of operation:

- 0 \* switched
- 0 \* non-switched


0 Both configurations allow the reduction of coax cable, yet maintain flexibility in the design of the network of terminals.

### 0 Switched Configuration

0 The switched configuration (as shown in Figure 1.1 on page 1-3) connects the display terminals and control units through a DMS-100 Family switch.

0 Using 3270 NSA in a switched configuration means that the number of installed terminals does not have to match the number of ports on the IBM control unit. The exact ratio of terminals to ports is determined for each installation, depending on local requirements and usage patterns.

0 A terminal can have DMS access to any mainframe with a port connected via a CUIF to the DMS-100 Family switch.



DLC is an NT6X71AB  
data line card


Figure 1.1 Switched Configuration

0 297-2121-228  
0 VINTAGE 02.01

### 0 Non-switched Configuration

0 The non-switched configuration (also known as back-to-back), as  
0 shown in Figure 1.2, connects the display terminal and control  
0 unit directly.

0 \_\_\_\_\_



0 \_\_\_\_\_

0 Figure 1.2 Non-switched Configuration

### 0 Compatibility

0 The TIF (NT4X25AL) is fully compatible with CUIF (NT4X25DA) to  
0 provide the DFT functionality. It is also compatible with CUIF  
0 (NT4X25AM), described in 297-2121-225. Compatibility is shown in  
0 Figure 1.3 on page 1-5.



0 297-2121-228  
0 VINTAGE 02.01

0 \* IBM 3180 display station in 3278 mode  
0 \* IBM 3191/3192 monochrome display station  
0 \* IBM 3194  
0 \* IBM 3270 PC (control unit terminal mode)  
0 \* IBM 3278 models 2, 3, 4, and 5 (monochrome)  
0 \* IBM 3279 color display without convergence  
0 \* IBM PC AT and XT with IRMA (up/downloading is not supported)  
0 \* Beehive ATL-178  
0 \* Memorex 2178

0 CUT Mode Features

0 3270 NSA supports the following CUT mode features:

0 \* extended character set (extended attribute buffer) (program-  
0 mable symbols not supported)

0 \* APL/text  
0 \* audible alarm  
0 \* all supported keyboard types  
0 \* selector light pen  
0 \* security keylock

0 Note: 3270 NSA does not support IBM printers, or color conver-  
0 gence.

0 DFT mode Devices

0 The TIF is also compatible with the following DFT devices:

0 \* IBM 3194 Intelligent Display Station  
0 \* 3270 PC (DFT mode of operation)

0 DFT Mode Features

0 3270 NSA supports the following DFT features:

0 \* user customization of up to four (logical) host mainframe  
0 sessions on one 3194 terminal configuration

0 \* up/downloading of information with host mainframe

0 1-6

0 \* full support for both Systems Network Architecture (SNA) and  
0 non-SNA protocols

0 \* graphics on the 3270 PC in DFT mode.

#### 0 DMS-100 Features

0 When 3270 NSA is used in a switched configuration, the Datapath  
0 keyboard dialing feature is available. The following additional  
0 features can be added:

0 \* automatic line

0 \* automatic dial

0 \* ring again

0 \* data-port hunting

0 \* speed dialing

0 \* idle time out

0 \* maintenance from the central office

0 The datapath keyboard dialing feature lets the user establish  
0 calls to multiple locations or multiple applications from the  
0 terminal. It is also useful for system maintenance and trouble-  
0 shooting.

0 The automatic line feature automatically connects the user with a  
0 predetermined destination. The terminating location's directory  
0 number is entered at the DMS-100 Family switch using Service  
0 Orders. It can represent a line on the same switch or a line on  
0 another switch. The directory number can be up to 15 digits  
0 long.

0 Note: When this feature is used, all other call setup features  
0 are disabled.

0 The automatic dial feature lets the user program one frequently  
0 dialed directory number so that it can be automatically dialed  
0 using the auto dial keyboard sequence.

0 The ring again feature is used when the CUIF the user has called  
0 is busy. The system monitors the called CUIF and alerts the user  
0 when the busy CUIF becomes idle. Ring again only applies if the  
0 originating and terminating units are served by the same DMS-100  
0 Family switch, and are both in the same customer group.

0 The data port hunting feature lets the user dial one directory  
0 number to gain access to one of several available control unit  
0 ports. The DMS-100 Family switch hunts for the first available  
0 data port.

0 297-2121-228  
0 VINTAGE 02.01

0 The speed dialing feature lets the user program a list of direc-  
0 tory numbers. Each number can then be dialed using a one- or  
0 two-digit code. Two types of speed dialing lists are available:

0 \* a short list of up to 10 directory numbers for which 1-digit  
0 codes are used

0 \* an individual list of up to 30, 50, or 70 directory numbers  
0 for which 2-digit codes are used

0 \* a group list of up to 30, 50, or 70 directory numbers for  
0 which 2-digit codes are used

0 The operating company determines the type of speed dialing avail-  
0 able to the TIF user when the associated data line card (DLC)  
0 line equipment number (LEN) is datafilled.

0 The idle time out feature is used to automatically take down a  
0 data call if the data line remains idle for a predetermined peri-  
0 od of time. The idle time is determined by the operating company  
0 when the associated DLC LEN is datafilled. The idle time out  
0 feature is available in markets where profile downloading is  
0 available.

0 The central office based maintenance feature allows remote diag-  
0 nostics to be performed on the TIF and the CUIF from the central  
0 office.

Printer Support

3270 NSA supports IBM 3287 type printers. When the TIF is assigned Automatic Line (AUL) option and is connected to a 3287 printer, it goes into Virtual Private Line (VPL) mode of operation automatically. The VPL feature allows the TIF to maintain a semi-permanent data connection during call setup on the 3287 printers. The TIF sends an originate message to the DMS when one of the following occurs: the TIF

- \* powers up
- \* regains TCM synchronization
- \* re-establishes communication with the attached DTE
- \* receives a reset message from the DMS.

When the DMS sends a reset message to the TIF, the following conditions are checked before the TIF sends the originate message to the DMS: that the

- VPL feature is active
- TIF is the originator of the data call
- TIF is not under test from the DMS

If these conditions are met, the TIF sends the originate message to the DMS to re-establish the data connection. There is a two second delay period to allow for the release of DMS resources involved in the previous call. When the originate message is sent after the delay period, a 40 second timer is started. If the T-link synchronization or data mode with the far end has not been established in this period, the call is dropped. After two seconds, another attempt is made to establish the data connection and this process is repeated until one of the following occurs:

- \* the TIF establishes T-link synchronization with the far end
- \* the 3287 printer is turned off or disconnected
- \* the TIF is placed under test by the DMS.

The VPL feature and the timer allow the TIF to continue trying to establish the data connection when the network resources are unavailable for a period of time.

Note: 3287 printer support in the SNA environment requires the use of a locally attached 3174 control unit, with the Attention Delay Value set to a minimum of 40 msec. This value is configured in panel 223 of the 3174 customization procedure. The default value is 10 msec.

0 297-2121-228  
0 VINTAGE 02.01

0 REFERENCES

0 The following documents will provide you with additional informa-  
0 tion on the datapath products and some of the installation proce-  
0 dures:

0 297-1001-001 Master Index of Practices  
0 297-1001-100 System Description  
0 297-1001-114 Operational Measurements (OM)  
0 297-1001-320 Operational Measurements Reference Manual  
0 297-1001-451 Common Customer Data Schema  
0 297-1001-455 Office Parameters Reference Manual  
0 297-2101-451 Local Customer Data Schema  
0 297-2101-516 Line Maintenance Reference Manual  
0 297-2121-100 Guide to Documentation  
0 297-2121-225 3270 Network Switched Access

0  
0

297-2121-228  
VINTAGE 02.01

0

---

0 CHAPTER 2

0 EQUIPMENT DESCRIPTION AND SPECIFICATIONS

0

---

0 297-2121-228  
0 VINTAGE 02.01

This chapter provides descriptions and specifications for the following equipment:

- Control Unit Interface Shelf (NT4X25BS)
- Control Unit Interface (NT4X25DA)
- Terminal Interface (NT4X25AL)
- Cabling

CONTROL UNIT INTERFACE SHELF - DESCRIPTION

The Control Unit Interface (CUIF) shelf (NT4X25BS) is a standard 48.26 cm (19 in) wide rack-mount unit that houses up to 16 circuit packs. The front of the shelf has a safety bar that secures the CUIFs in place (see Figure 2.1).





Figure 2.1 Control Unit Interface Shelf - Front View

0 297-2121-228  
0 VINTAGE 02.01

0 The shelf has eight pre-drilled mounting holes, four on each  
0 side. The dimensions of the holes are shown in Figure 2.2 on  
0 page 2-2.



---

0  
0 Figure 2.2 CUIF Shelf - Mounting Hole Dimensions

0 A power supply (NT part # A0320852, CPC code NPS50422-10L3)  
0 mounted on the rear of the shelf provides power for the circuit  
0 packs. The AC power cord connects to a receptacle on the rear of  
0 the shelf. The shelf has an ON/OFF switch to control the power,  
0 and a 7 A fuse to protect against overload.

0 There are 16 BNC connectors on the rear of the shelf that provide  
0 the connections from the CUIFs to the IBM control units. A 50-pin  
0 Amphenol connector provides the interface to the data lines (see  
0 Figure 2.3 on page 2-3).



0 297-2121-228  
0 VINTAGE 02.01

0 Weight: 22 kg (48.5 lbs)

0 Connectors: 16 BNC connectors

0 1 female Amphenol (AMP2-102935-8)  
0 connector

0 1 power cord connection

0 Color: grey

#### 0 Electrical Specifications

0 Inputs: 110 V ac nominal (92 - 130 V ac)  
0 60 Hz 4.0 A

0 Outputs: +5 V 50 A

0 +12 V 5 A

0 -12 V 5 A

0 Fuse: 7 A

0 Minimum Loading Requirements: 5 A (2 CUIF circuit packs)

#### 0 Environmental Specifications

0 Operating Temperature: 0 to 50<sup>0</sup>C (32 to 122<sup>0</sup> F)

0 Storage Temperature: -40 to 70<sup>0</sup>C (-40 to 158<sup>0</sup> F)

0 Relative Humidity: (operating) 95% at 40<sup>0</sup> C (104<sup>0</sup> F)

0 The maximum differential air temperature rise within the shelf is  
0 15 C<sup>0</sup> (27 F<sup>0</sup>)

#### 0 Regulatory Compliance

0 EMI: FCC Part 15 Class A

0 Interconnect: CS-03 Issue 6


0 The shelf is Canadian Standards Association (CSA) approved and  
0 Underwriters' Laboratories (UL) listed.

0  
 0

0 CONTROL UNIT INTERFACE - DESCRIPTION

0 The CUIF (NT4X25DA) is a circuit pack that connects the IBM con-  
 0 trol unit to the twisted-pair data line (see Figure 2.4).

0



0

0 Figure 2.4 CUIF Circuit Pack - Front and Side View

0

0 297-2121-228  
0 VINTAGE 02.01

0 The front of the CUIF has two status LEDs:

0 Conn  
0 Poll

0 These LEDs indicate the status of the CUIF connection, data ses-  
0 sion, synchronization, and self-test.

0 Each time the CUIF is powered-up the integrity of the hardware is  
0 tested. For a detailed explanation of the self-test and failure  
0 reporting, see Control Unit Interface Circuit Pack Self-Test on  
0 page 6-1.

0 Pull tabs on the faceplate allow for easy insertion and removal  
0 of the CUIF from the shelf.

0 There are two DIP switches on the circuit pack. They are used to  
0 configure the CUIF for either switched or non-switched operation  
0 (SW1 and SW2 in Figure 2.4 on page 2-5).

## 0 CONTROL UNIT INTERFACE - SPECIFICATIONS

### 0 Mechanical Specifications

0 Size: 25.4 cm long x 30.5 cm high (10 in  
0 x 12 in)

0 Connectors: card edge connectors

### 0 Electrical Specifications

0 Inputs: +5 V dc 2.5 A

0 +12 V dc 0.1 A

0 -12 V dc 0.1 A

0 ESD (faceplate only): 20 kV with no call drop

0 25 kV with no permanent damage

### 0 Environmental Specifications

0 Operating Temperature: 0 to 50<sup>0</sup>C (32 to 122<sup>0</sup>F)

0 Storage Temperature: -40 to 70<sup>0</sup>C (-40 to 158<sup>0</sup>F)

0 Relative Humidity: (operating) 95% at 40<sup>0</sup>C (104<sup>0</sup>F)

0  
0

297-2121-228  
VINTAGE 02.01

0 MTBF: greater than 10 years

0 Regulatory Compliance

0 EMI: FCC Part 15 Class A

0 Interconnect: CS-03 Issue 6

0 The CUIF is CSA approved and UL listed.



0 The toggle switch labeled RLS is used to terminate a data session  
0 and release the data line.

0 The TIF has two female TELADAPT\* jacks on its rear face. The  
0 jack closest to the BNC connector is used to connect the TIF to  
0 the data line. If the operating company provides a voice line  
0 connection, the jack closest to the power cord can be used to  
0 connect a telephone.

0 Each time the TIF is powered-up, and upon completion of a call,  
0 the integrity of the TIF hardware is tested. If a hardware fail-  
0 ure is detected, the failure is indicated by the status LED. For  
0 a detailed explanation of the self-test and failure reporting,  
0 see Terminal Interface Self-Test on page 6-1.

0 TERMINAL INTERFACE - SPECIFICATIONS

0 Mechanical Specifications

0 TIF

0 Size: 31.7 cm long x 19.0 cm wide x 6.3  
0 cm high (12.5 in x 7.5 in x 2.5  
0 in)

0 Weight: 1.82 kg (4.0 lbs) (including power  
0 supply)

0 Connectors: 1 BNC connector  
0 2 female Teladapt jacks

0 Color: grey

0 Power Supply

0 Size: 12.5 cm long x 8 cm wide x 6 cm  
0 high (4.9 in x 3.1 in x 2.4 in)

0 Color: black

0 Electrical Specifications

0 TIF

0 Inputs: +5 V dc 1.5 A  
0 +12 V dc 0.2 A

0 \_\_\_\_\_  
0 \*TELADAPT is a trademark of Northern Telecom

0 297-2121-228  
0 VINTAGE 02.01

0 -12 V dc 0.2 A

0 Electrostatic Discharge: 20 kV with no call drop  
0 25 kV with no permanent damage

0 Power Supply

0 Inputs: 110 V ac nominal (92 - 130 V ac)  
0 60 Hz 20 W

0 Outputs: +5 V dc 1.5 A  
0 +12 V dc 0.2 A  
0 -12 V dc 0.2 A

0 Environmental Specifications

0 Operating Temperature: 0 to 50<sup>0</sup>C (32 to 122<sup>0</sup>F)  
0 Storage Temperature: -40 to 70<sup>0</sup>C (-40 to 158<sup>0</sup>F)  
0 Relative Humidity: (operating) 95% at 40<sup>0</sup>C (104<sup>0</sup>F)  
0 MTBF: greater than 10 years

0 Regulatory Compliance

0 EMI: FCC Part 15 Class A  
0 Interconnect: CS-03 Issue 6

0 The TIF is CSA approved and UL listed.

0 CABLE SPECIFICATIONS

0 Coax Cable

0 Type: RG62A/U

0 Maximum Lengths: 1.5 km (4900 ft) from TIF to terminal

0 1.5 km (4900 ft) from CUIF to control unit

0 Twisted-pair Cable

0 TIF to DLC

0 Maximum Lengths: 4.34 km (2.69 miles) with non-loaded 26-gauge  
0 wire

0 5.47 km (3.39 miles) with non-loaded 24- or  
0 22-gauge wire

0 CUIF to DLC

0 Maximum Lengths: 4.34 km (2.69 miles) with non-loaded 26-gauge  
0 wire

0 5.47 km (3.39 miles) with non-loaded 24- or  
0 22-gauge wire

0 TIF to CUIF

0 Maximum Lengths: 4.34 km (2.69 miles) with non-loaded 26-gauge  
0 wire

0 5.47 km (3.39 miles) with non-loaded 24- or  
0 22-gauge wire

0 297-2121-228  
0 VINTAGE 02.01

0  
0

297-2121-228  
VINTAGE 02.01

0

---

0 CHAPTER 3

0 INSTALLING A DATA LINE FOR 3270 NETWORK  
0 SWITCHED ACCESS

0

---

0 297-2121-228  
0 VINTAGE 02.01

0  
0

297-2121-228  
VINTAGE 02.01

0 The installation of 3270 Network Switched Access equipment is  
0 separated into two specific areas:

- 0 \* installation of the data line
- 0 \* installation of the 3270 Network Switched Access hardware

0 This chapter deals only with the installation of the twisted-pair  
0 data line between the Terminal Interface (TIF) and the Control  
0 Unit Interface (CUIF).

0 As shown in Figure 3.1 on page 3-2, the data line can be either  
0 switched through the DMS-100 Family switch, or a direct con-  
0 nection from the TIF to the CUIF.





0 297-2121-228  
0 VINTAGE 02.01

0 TABLE 3.1 (Continued)  
0 SERVORD ENTRIES FOR 3270 NETWORK SWITCHED ACCESS

---

0 FIELD	0 DESCRIPTION
0 NCOS	0 Network Class of Service
	0 Enter as required.
0 SNPA	0 Service Numbering Plan Area
	0 Enter as required.
0 RINGING	0 Ringing
	0 Determines whether ringing is applied to the line.
	0 For the TIF enter N (no ringing).
	0 For the CUIF enter N (no ringing).
0 CLASSDU	0 Class of Data Unit
	0 Determines the class of the DU associated with the
	0 directory number.
	0 For the TIF enter TCU (terminal coax unit).
	0 For the CUIF enter CCU (controller coax unit).
0 DOWNLOAD	0 Download Profile
	0 Determines whether the data stored in the DPROFILE
	0 table is downloaded to the DU.
	0 Enter N (No) or Y (Yes) as required.
	0 When profile downloading is enabled, you can specify
	0 the TIF idle time out. You must, however, use the
	0 NT6X71AB DLC.
0 IDLETO	0 Idle Time Out
	0 Determines the length of time the TIF may remain idle
	0 before the device times out and the data connection
	0 is lost.
	0 Enter either of the following:
	0 0 for no time out
	0 1 for 15 minutes idle before time out

---

0 Table Continued

0 TABLE 3.1 (Continued)  
0 SERVORD ENTRIES FOR 3270 NETWORK SWITCHED ACCESS

---

0 FIELD	0 DESCRIPTION
0	2 for 30 minutes idle before time out
0	3 for 60 minutes idle before time out

0 The download must be enabled (Y) if 1, 2, or 3 are  
0 entered as the idle time out.

0 This prompt does not appear if CCU has been entered in the CLASS-  
0 DU field indicating that a CUIF is being datafilled.

---

0 KBDTYP	0 Keyboard Type
----------	-----------------

0 Determines the type of keyboard dialing for the TIF.  
0 Enter SYMB (symbolic).

0 This prompt does not appear if CCU has been entered in the CLASS-  
0 DU field indicating that a CUIF is being datafilled.

---

0 DPOPTS	0 DATAPATH Options
----------	--------------------

0 Determines the list of Datapath options that the DU  
0 is to have. A CUIF must have Auto Answer. There are  
0 no TIF options required for 3270 Network Switched  
0 Access.  
0 The default entry is AUTOANS \$  
0 The \$ indicates the end of the option list.

---

0 297-2121-228  
0 VINTAGE 02.01

0 Twisted-pair Cabling Requirements

0 The length of the twisted-pair cable connecting the DU to the  
0 corresponding DLC varies with the wire gauge. Use the following  
0 list as a guide for maximum cable lengths:


0 22- 24-gauge maximum length - approximately 5.47 km (3.39  
0 miles)

0 26-gauge maximum length - approximately 4.34 km (2.69  
0 miles)

0 1. Make the connections from the DLC to the TIF modular wall  
0 jack as shown in Figure 3.2.

0 2. Make the connections from the DLC to the appropriate twist-  
0 ed-pair of the CUIF interface connector as shown in  
0 Figure 3.3 on page 3-7.

---



---

0 Figure 3.2 Connection from TIF Modular Jack to DLC

0  
0

0	CUIF	Twisted		CUIF	Twisted	
0	Slot #	Pair	Pin#	Slot #	pair	Pin#
0	1	— T - BL1W —	1	9	— T - BR1R —	9
0		— R - BL2W —	26		— R - BR2R —	34
0	2	— T - O1W —	2	10	— T - S1R —	10
0		— R - O2W —	27		— R - S2R —	35
0	3	— T - G1W —	3	11	— T - BL1BK —	11
0		— R - G2W —	28		— R - BL2BK —	36
0	4	— T - BR1W —	4	12	— T - O1BK —	12
0		— R - BR2W —	29		— R - O2BK —	37
0	5	— T - S1W —	5	13	— T - G1BK —	13
0		— R - S2W —	30		— R - G2BK —	38
0	6	— T - BL1R —	6	14	— T - BR1BK —	14
0		— R - BL2R —	31		— R - BR2BK —	39
0	7	— T - O1R —	7	15	— T - S1BK —	15
0		— R - O2R —	32		— R - S2BK —	40
0	8	— T - G1R —	8	16	— T - BL1Y —	16
0		— R - G2R —	33		— R - BL2Y —	41

0 Color Code  
0 AANBB where AA indicates the primary color  
0 (one or two letters)  
0 B indicates the number of stripes  
0 CC indicates the color of the stripe  
0 (one or two letters)

---

0  
0 Figure 3.3 Connections to CUIF Pairs

0

0 297-2121-228  
0 VINTAGE 02.01

0 NON-SWITCHED CONFIGURATION

0 A non-switched data line is a direct connection from the TIF to  
0 the CUIF and does not require any type of datafill.

0 Cabling Requirements


0 The length of the twisted-pair cable connecting the TIF to the  
0 CUIF varies with the wire gauge. Use the following list as a  
0 guide for maximum cable lengths:

0 22- 24-gauge maximum length - approximately 5.47 km (3.39  
0 miles)

0 26-gauge maximum length - approximately 4.34 km (2.69  
0 miles)

0 Make the connections from the modular jack to the appropriate  
0 CUIF pair as shown in Figure 3.4, and Figure 3.3 on page 3-7 .

0 \_\_\_\_\_



0 \_\_\_\_\_

0 Figure 3.4 Connection from TIF to CUIF

0  
0

297-2121-228  
VINTAGE 02.01

0

---

0 CHAPTER 4

0 INSTALLING THE 3270 NETWORK SWITCHED ACCESS  
0 EQUIPMENT

0

---

0 297-2121-228  
0 VINTAGE 02.01



0 297-2121-228  
0 VINTAGE 02.01

0 INSTALLING THE CONTROL UNIT INTERFACE

0 The CUIF connects the IBM control unit to the twisted pair data  
0 line.

0 Equipment Required

0 To install the CUIF, you need the following equipment:

- 0 \* CUIF (NT4X25DA)

0 Note: A minimum of two CUIFs must be installed in the shelf  
0 to satisfy the minimum load requirements of the shelf power  
0 supply.

- 0 \* one data line (see Chapter 3 on page 3-1)


- 0 \* one coax cable, terminated with BNC connectors, to connect  
0 the CUIF to the IBM control unit. Each of the cable pairs  
0 must be terminated with a BNC connector.

0 Installation Procedure

- 0 1. Remove the safety bar from the front of the CUIF shelf.
  - 0 2. Set DIP switches SW1 and SW2 on the CUIF for switched or non-  
0 switched operation. See Figure 2.4 on page 2-5 to locate the  
0 DIP switches on the CUIF. Set the switches as follows:
    - 0 \* SW1 according to Figure 4.1
    - 0 \* SW2 according to Figure 4.2 on page 4-3
- 

0 Switched Configuration

0 Non-switched Configuration




---

0 Figure 4.1 SW1 Switch Settings

---

Switched Configuration                      Non-switched Configuration



\* indicates position of switch slide.

---

Figure 4.2 SW2 Switch Slide Settings

- Slide the CUIF into one of the slots on the shelf and lock the card extractor tabs into place. The components should be facing the right side of the shelf.

If this is the first CUIF being installed, install a second CUIF immediately. Place the power switch located on the rear of the CUIF shelf in the ON position.

The Conn LED on the CUIF should flash to indicate that the CUIF is not connected to the data line.

The Poll LED should flash to indicate that the CUIF is not connected to the IBM control unit.

If only the Conn LED flashes then goes out, the CUIF has failed its diagnostic self-test. See Control Unit Interface Circuit Pack Self-Test on page 6-1 for an explanation of the diagnostic self-test.

If both the Conn and Poll LEDs light steadily before you have established connections to the control unit or DLC, the hardware is faulty. Replace the unit.

- Connect the appropriate BNC connector on the back of the CUIF shelf to the IBM control unit using the length of coax cable. Each BNC connector on the shelf is numbered so that you can correlate the connector to the circuit pack slot.

The Poll LED should light steadily to indicate that the CUIF is connected to an IBM control unit. If the Poll LED continues to flash, check that the coax cable connectors are prop-

0 297-2121-228  
0 VINTAGE 02.01

0 erly mated. If the Poll LED does not light, check the port  
0 on the IBM control unit.

0 If you have difficulty reaching the BNC connector, temporarily  
0 lower the power supply to move it out of the way. To  
0 lower the power supply:

0 a. Loosen, but do not remove, the four hexagonal nuts that  
0 secure the power supply to the CUIF shelf.

0 b. Slide the power supply down by following the cutout pattern  
0 on the brackets that secure the power supply to the  
0 CUIF shelf.

0 c. When you have finished working with the BNC connectors,  
0 replace the power supply by reversing these steps.

0 5. Connect the CUIF to the data line using the appropriate pair  
0 from the 25-pair cable that is terminated with an Amphenol  
0 connector and connected to the back of the CUIF shelf. The  
0 cable pair should be connected to the data line using the  
0 appropriate connection (see Chapter 3 on page 3-1). The Conn  
0 LED on the CUIF circuit pack extinguishes to indicate that  
0 the CUIF is now connected to a data line.

0 6. Replace the safety bar on the front of the CUIF shelf.



0 297-2121-228  
0 VINTAGE 02.01

0 have TCM synchronization. If this prompt does not appear on  
0 the screen of the terminal, check that the coax cable connec-  
0 tors are properly mated.

0 4. Connect the TIF to the data line using the line cord. The  
0 Teladapt connector plugs into the line jack closest to the  
0 BNC connector on the back of the TIF.

0 The LED located on the top of the TIF should light steadily  
0 to indicate that the TIF is connected to a data line, and has  
0 TCM synchronization. The prompt "READY FOR INPUT COMMAND"  
0 appears on the screen to indicate that the terminal is ready  
0 for your input.

0 Consult Chapter 5 on page 5-1, and Chapter 6 on page 6-1 for  
0 information on testing the system.

0  
0

297-2121-228  
VINTAGE 02.01

0 

---

0 CHAPTER 5

0 VERIFYING THE DATA CONNECTION

0 

---

0 297-2121-228  
0 VINTAGE 02.01

0  
0

0 This chapter describes the procedures for establishing a data  
0 connection. Try to establish a data connection once you have  
0 finished installing the data line and the 3270 Network Switched  
0 Access hardware, to verify that all equipment is operating prop-  
0 erly. Try to establish a connection again when you are perform-  
0 ing routine maintenance or troubleshooting the system to help  
0 isolate any problems.

## 0 SWITCHED CONFIGURATION

0 If 3270 Network Switched Access is used in a switched configura-  
0 tion, data connections are always established from the terminal  
0 using the Terminal Interface (TIF). The Control Unit Interface  
0 (CUIF) can not be used to originate calls.

### 0 Data Call

0 A typical data call consists of three different stages:

- 0 \* call setup
- 0 \* data transfer
- 0 \* call take down

0 Data calls can be initiated using either Datapath keyboard dial-  
0 ing or automatic dialing. (See Setting Up a Data Call on page  
0 5-4). The DMS-100 Family switch provides the TIF with messages  
0 reporting the progress of the call. These messages are decoded  
0 and displayed as text strings on the terminal. (See Terminal  
0 Display).

0 The CUIF answers the call automatically.

0 Once the CUIF receives the terminal identification information  
0 automatically from the TIF, it initiates a data session with the  
0 host control unit. The terminal screen displays the host logo.

0 After the session, the call is taken down by logging off from the  
0 host computer and then toggling the RLS switch on the TIF.

### 0 Terminal Display

0 When you power up the terminal, the successful initiation of key-  
0 board dialing (KBD) is indicated by the KBD screen display on the  
0 terminal. See Figure 5.1 on page 5-2.

0



0 LOST SYNC CHECK CONNECTIONS indicates that TCM sync has been  
0 lost; check connections between TIF and wall jack.

0 TEST IN PROGRESS DO NOT ENTER indicates that the DMS switch has  
0 initiated maintenance test on TIF and no inputs are  
0 allowed.

0 The following is a list of the user inputs that can be entered  
0 during Datapath keyboard dialing.

0 + Initiate or answer a call  
0 ! Abort call prior to call connection  
0 @ Auto Dial  
0 = Speed Call  
0 % Ring Again  
0 PA1 Display HDLC errors and TCM sync loss  
0 PA2 Clear display of HDLC errors and TCM sync loss  
0 0-9, \*, # Valid digits  
0 A-Y, a-y Alphas as on keyboard (Q and Z are not valid). These  
0 alphas are translated into digits for dialing according  
0 to the digits associated with these letters on a stand-  
0 ard keypad.

0 Note: In DFT mode, you can use the full editing capabilities of  
0 the terminal.

0 The PF keys on the terminal can be used to send number codes to  
0 the switch without pressing the ENTER key. The PF keys correspond  
0 to the keypad numbers as follows:

0 PF1/PF13 Sends the digit 1.

0 PF2/PF14 Sends the digit 2.

0 PF3/PF15 Sends the digit 3.

0 PF4/PF16 Sends the digit 4.

0 PF5/PF17 Sends the digit 5.

0 PF6/PF18 Sends the digit 6.

0 PF7/PF19 Sends the digit 7.

0 PF8/PF20 Sends the digit 8.

0 PF9/PF21 Sends the digit 9.

0 PF10/PF22 Sends the \* character.

0 PF11/PF23 Sends the digit 0.

0 297-2121-228  
0 VINTAGE 02.01

0 PF12/PF24 Sends the # character.

0 All valid inputs are echoed on the terminal; a beep is given if  
0 input is invalid.

## 0 SETTING UP A DATA CALL

### 0 Setting Up a Data Call Using Datapath Keyboard Dialing

0 Keyboard dialing in DFT mode allows you to edit your entries.  
0 If you enter a wrong character or digit while setting up a call,  
0 correct the input before pressing the ENTER key. It cannot be  
0 edited after the command has been entered.

0 The terminal and the TIF power should be on. The LED on the top  
0 of the TIF should be lit.

0 1. Toggle the RLS switch on the TIF to reset the TIF and initi-  
0 ate a self-test. If the TIF fails the self-test, the LED on  
0 its cover flashes, and then goes out. See Chapter 6 on page  
0 6-1 for a detailed explanation of the failure code.

0 If the TIF passes the self-test, the terminal displays READY  
0 FOR INPUT COMMAND to indicate that it is ready to receive  
0 Datapath keyboard dialing commands.

0 2. Enter + . The terminal displays ENTER NUMBER TO DIAL to  
0 indicate that it is ready to receive the directory number.

0 3. Dial the appropriate directory number using the numerical or  
0 alpha keys on the keyboard. The terminal displays CON-  
0 NECTION IN PROGRESS to indicate that the connection is in  
0 progress.

0 When the called party answers, the terminal displays CONNECTED  
0 to indicate that a data call has been established. The host logo  
0 appears on the terminal screen immediately. You may proceed with  
0 your data session.

0 If the terminal receives a busy signal from the called party, it  
0 displays LINE BUSY % PROGRAMS RING AGAIN. You can abort the  
0 call or activate the ring again feature.

### 0 Setting Up a Data Call Using Automatic Dialing

0 If the automatic dialing feature is active, you can place a call  
0 using automatic dialing.

0 Keyboard dialing in DFT mode allows you to edit your entries.  
0 If you enter a wrong character or digit while setting up a call,



0 297-2121-228  
0 VINTAGE 02.01

0 3. Enter = followed by the one- or two-digit code that identi-  
0 fies the directory number you want to dial. The terminal  
0 displays CONNECTION IN PROGRESS to indicate that the con-  
0 nection is in progress.

0 If the one- or two-digit code that you enter is not a valid  
0 code, the terminal displays INVALID ATTEMPT - TRY AGAIN .  
0 Abort the call and begin again.

0 When the called party answers, the terminal displays CONNECTED  
0 to indicate that a data call has been established. The host logo  
0 appears on the terminal screen immediately. You may proceed with  
0 your data session.

0 If the terminal receives a busy signal from the called party, it  
0 displays LINE BUSY % PROGRAMS RING AGAIN . You can abort the  
0 call or activate the ring again feature.

#### 0 Ringing a Directory Number Again

0 1. Enter % . The terminal displays READY FOR INPUT COMMAND  
0 and monitors the busy number.

0 You can place another call, or wait until the busy number  
0 becomes idle. If you want to cancel the ring again request  
0 at this point, enter % again. The terminal displays READY  
0 FOR INPUT COMMAND to indicate that the ring again request  
0 has been cancelled, and it is ready to receive user input.

0 When the busy directory number becomes idle, the terminal  
0 displays RING AGAIN LINE IS FREE +% RE-DIALS.

0 2. Enter + to indicate that you want to continue. The termi-  
0 nal displays ENTER NUMBER TO DIAL.

0 3. Enter % to ring the directory number again. The terminal  
0 displays CONNECTION IN PROGRESS to indicate that the con-  
0 nection is in progress.

0 When the called party answers, the terminal displays CONNECTED  
0 to indicate that the data call has been established. The host  
0 logo appears on the terminal screen immediately. You may proceed  
0 with your data session.

#### 0 Aborting a Data Call Prior to Connection

0 Note: This procedure can only be used to abort a call during  
0 dialing, before the CONNECTED prompt is displayed.

0 Enter ! or press the CLEAR key. The terminal displays READY  
0 FOR INPUT COMMAND.



0 297-2121-228  
0 VINTAGE 02.01

### 0 Programming the List of Speed Dialing Directory Numbers

0 The speed dialing feature lets the user program a list of direc-  
0 tory numbers that can be dialed by simply entering a one- or two-  
0 digit code.

0 The terminal and the TIF power should be on. The LED on the top  
0 of the TIF should be lit.

0 1. Toggle the RLS switch on the TIF to reset the TIF and initi-  
0 ate a self-test. If the TIF fails the self-test, the LED on  
0 its cover flashes, and then goes out. See Chapter 6 on page  
0 6-1 for a detailed explanation of the failure code.

0 If the TIF passes the self-test, the terminal displays READY  
0 FOR INPUT COMMAND to indicate that it is ready to receive  
0 Datapath keyboard dialing commands.

0 2. Enter = . The terminal displays ENTER NUMBER TO DIAL to  
0 indicate that it is ready to receive the speed dial number.

0 3. Enter a one- or two-digit speed dial code, the directory num-  
0 ber you want to store, and = . The terminal displays READY  
0 FOR INPUT COMMAND to indicate that it has stored the direc-  
0 tory number and is ready to receive Datapath keyboard dialing  
0 commands.

### 0 NON-SWITCHED CONFIGURATION

0 If 3270 Network Switched Access is used in a non-switched config-  
0 uration, each terminal is connected to a control unit port via  
0 the TIF and the CUIF. To begin a data session, simply logon to  
0 the terminal as usual.

0  
0

297-2121-228  
VINTAGE 02.01

0

---

0 CHAPTER 6

0 DIAGNOSTICS AND TROUBLESHOOTING

0

---

0 297-2121-228  
0 VINTAGE 02.01



0 297-2121-228  
0 VINTAGE 02.01

0 1 = address decoding  
0 2 = ROM checksum  
0 3 = 8031 bus drivers  
0 4 = external RAM  
0 5 = 8031 CPU (including on-chip RAM)  
0 6 = X14 TCM-LSI  
0 7 = TCM 64 kbps data loopback  
0 10 = coax loopback

0 This test can also be initiated from the MAP. See Troubleshoot-  
0 ing from the MAP on page 6-14.

0 If the TIF circuit pack fails its self-test, repeat the test to  
0 verify the results. If it fails the self-test a second time,  
0 replace the TIF.

0  
0


0 PHYSICAL CHANNEL CHECKS

0 In a switched configuration, the data line connection between the  
0 TIF and the CUIF is based on a protocol that ensures reliable,  
0 error-free data transmission between the two devices. If bit  
0 errors do occur, the data is retransmitted. Two separate counts  
0 are kept. The first one records the number of data errors  
0 detected and corrected. The second one records the number of  
0 idle line errors that resulted in the TIF re-establishing idle  
0 line synchronization.

0 To access the peg counts and determine channel quality, press the  
0 PA1 key when no data connection is established. The peg counts  
0 are displayed, as shown in the bottom part of Figure 6.1, in hex-  
0 adecimal numbers which may have any value from 00 to FF. The  
0 display, Cyclic Redundacy Check (CRC) error count, indicates the  
0 number of link errors detected since the count was last cleared.  
0 The display, SYNC loss count, indicates the number of line errors  
0 that required line synchronization to be re-established since the  
0 count was last cleared. To clear the peg counts, press the PA2  
0 key.

0

0 COMMANDS: + dial ALLOWED ENTRIES  
0 ! abort FOR DIALING  
0 @ auto-dial  
0 = speed call  
0 % ring again



0 STATUS: READY FOR INPUT COMMAND

0 > <

0 INPUT:

CRC error count:00  
SYNC loss count:00

0

0 Figure 6.1 Screen Display of Channel Errors

0

0 297-2121-228  
0 VINTAGE 02.01

0 If a non-zero number is displayed, perform a bit error rate test  
0 (BERT) to check the integrity of the data line card (DLC), the  
0 loop, and the associated TIF or CUIF (see Troubleshooting from  
0 the MAP on page 6-14 ).



0 TABLE 6.1 (Continued)  
0 3270 NETWORK SWITCHED ACCESS TROUBLESHOOTING

0 SYMPTOM	0 PROBLEM	0 ACTION
0	0	0 Verify that the CUIF is properly connected to its data line.
0	0	0 (Non-switched Configuration) Verify that the TIF is properly connected to its data line.
0	0	0 Verify the integrity of the data line.
0	0	0 Verify that the CUIF is properly connected to its data line.
0 The terminal does not display the KBD banner with READY FOR INPUT COMMAND before a data call is established. (Switched configuration only)	0 The terminal is not receiving power.	0 Verify that the terminal is receiving the required power levels from the electrical outlet (see Terminal Interface - Description on page 2-8)  0 Verify that the terminal power switch is in the On position.  0 Verify that the terminal is operating correctly. (Consult the manufacturer's documentation for further information.)
0	0 The terminal is not properly connected to the TIF.	0 Verify that the coax cable between the TIF and the terminal is properly connected.
0	0 The coax cable connecting the terminal to the TIF is defective.	0 Replace the length of coax cable.

0 Table Continued

TABLE 6.1 (Continued)  
 3270 NETWORK SWITCHED ACCESS TROUBLESHOOTING

SYMPTOM	PROBLEM	ACTION
	The central office is performing maintenance.	Wait until the response "TEST IN PROGRESS DO NOT ENTER" disappears from the terminal.
	There is a communication error between the TIF and the terminal.	Toggle the RLS switch on the TIF to reset the unit and initiate a self-test. See Terminal Interface Self-Test on page 6-1 for information on the TIF self-test.
When you set up a call and enter + , the terminal does not display ENTER NUMBER TO DIAL . (Switched configuration only)	A call can not be set up from the TIF.	Abort the call by entering ! and try setting up the call again.  Initiate a self-test on the TIF. See Terminal Interface Self-Test on page 6-1 for information on the TIF self-test.
The terminal displays CONNECTION IN PROGRESS prompt but nothing more. (Switched configuration only)	The called CUIF is busy.	Abort the call by entering ! and try setting up the call again.
	The CUIF you have dialed is not responding.	Abort the call by entering ! and try setting up the call again.  Verify that the CUIF is properly configured (see Installing the Control Unit Interface on page 4-2).

Table Continued

0 TABLE 6.1 (Continued)  
0 3270 NETWORK SWITCHED ACCESS TROUBLESHOOTING

0 SYMPTOM	0 PROBLEM	0 ACTION
0 Terminal dis- 0 plays an unin- 0 telligible 0 string of char- 0 acters.	0 The connection 0 between the TIF 0 and the termi- 0 nal is bad.	0 Verify that the coax 0 cable between the termi- 0 nal and the TIF is prop- 0 erly connected.  0 Toggle the RLS switch on 0 the TIF to terminate the 0 call and initiate a self- 0 test on the TIF. See 0 Terminal Interface Self- 0 Test on page 6-1 for 0 information on the TIF 0 self-test.  0 Press PA1, to view the 0 channel quality peg 0 counts. See Physical 0 Channel Checks on page 0 6-3 for information on 0 interpreting the peg 0 counts.  0 Initiate a self-test on 0 the terminal. See the 0 manufacturer's documenta- 0 tion for more informa- 0 tion.  0 Check for possible fail- 0 ures at the CUIF.  0 The CUIF DIP 0 switches are 0 not properly 0 set. 0 Check that the CUIF DIP 0 switches are correctly 0 set for switched or non- 0 switched operation. (See 0 Installing the Control 0 Unit Interface on page 0 4-2.)

0 Table Continued

TABLE 6.1 (Continued)  
 3270 NETWORK SWITCHED ACCESS TROUBLESHOOTING

SYMPTOM	PROBLEM	ACTION
Both the CUIF Conn and Poll LEDs light steadily before you have established connections from the CUIF to the control unit or the data line.	The CUIF card is faulty.	Replace the CUIF card.
The CUIF POLL LED flashes continuously.	There is no communication between the CUIF and the control unit.	Verify that the coax cable between the CUIF and the control unit is properly connected.  Verify that the CUIF is properly installed and configured (see Installing the Control Unit Interface on page 4-2).  Verify that the control unit is operating properly. See the manufacturer's documentation for more information.
The Conn LED on the CUIF flashes continuously.	There is no TCM synchronization between the CUIF and the DLC (switched configuration) or the TIF (non-switched configuration).	Check that the CUIF is properly connected to the data line.  Check that the CUIF DIP switches are correctly set for switched or non-switched operation.

Table Continued

0 TABLE 6.1 (Continued)  
0 3270 NETWORK SWITCHED ACCESS TROUBLESHOOTING

0 SYMPTOM	0 PROBLEM	0 ACTION
0 The LEDs on one 0 CUIF are not 0 lit.	0 The CUIF is not 0 receiving 0 power.	0 Initiate a self-test on 0 the affected CUIF circuit 0 pack by removing and 0 replacing it in the 0 shelf. See Control Unit 0 Interface Circuit Pack 0 Self-Test on page 6-1 for 0 information on interpret- 0 ing the CUIF self-test 0 results.  0 If the LEDs still do not 0 light up, replace the 0 CUIF with a known good 0 unit to determine if the 0 problem is with the 0 shelf.
0 The CUIF LEDs 0 flash, then 0 extinguish.	0 The CUIF has 0 failed its 0 self-test.	0 Replace the CUIF with a 0 known good unit.
0 None of the 0 CUIF LEDs are 0 lit.	0 The CUIF shelf 0 is not receiv- 0 ing power.	0 Check that the power sup- 0 ply cord on the rear of 0 the shelf is properly 0 plugged in at the shelf 0 and at the electrical 0 outlet.  0 Check that the power 0 switch on the rear of the 0 shelf is in the ON posi- 0 tion.  0 Check that the 7 A fuse 0 on the rear of the shelf 0 is not blown. If the 0 fuse is blown, replace 0 it. If the fuse blows 0 again, replace the power 0 supply by following the 0 procedure described 0 below.

0 Table Continued

TABLE 6.1 (Continued)  
3270 NETWORK SWITCHED ACCESS TROUBLESHOOTING

SYMPTOM	PROBLEM	ACTION
		Remove the metal plate on the rear of the shelf. Check that the correct voltages are present at each of the terminals.
		If these voltages are present, replace the CUIF shelf (see Installing the Control Unit Interface Shelf on page 4-1 for information on installing the shelf.)
		If these voltages are not present, the power supply must be replaced. To replace the power supply:
		1. Turn off the power switch located on the rear of the shelf, and unplug the power cord.
		2. Remove any tie-wraps securing the wires and leads.
		3. Disconnect the terminal strip wires. Note the order of the connections so that you can properly connect the wires of the replacement power supply.
		4. Disconnect the AC filter leads. Note the order of the connections so that you can properly connect the wires of the replacement power supply.

Table Continued

0 TABLE 6.1 (Continued)  
0 3270 NETWORK SWITCHED ACCESS TROUBLESHOOTING

0 SYMPTOM	0 PROBLEM	0 ACTION
		5. Disconnect the lead connected to the 7 A fuse.
		6. Remove the hexagonal nuts that secure the power supply to the shelf.
		7. Remove the power supply.
		Replace the power supply with a known good unit by reversing the above procedure.
0 Response time from the mainframe is unusually long. (Switched configuration only)	0 The host computer is busy.	0 Contact the host computer support services.
	0 The TIF and terminal are not properly connected.	0 Verify that the coax cable between the TIF and the terminal is properly connected.
	0 The CUIF DIP switches are not properly set.	0 Check that the CUIF DIP switches are correctly set for switched or non-switched operation. (See Installing the Control Unit Interface on page 4-2.)
	0 The current switched connection is poor.	0 Toggle the RLS switch to terminate the call and initiate a self-test on the TIF. See Terminal Interface Self-Test on page 6-1 for information on the TIF self-test.

0 Table Continued



0 297-2121-228  
0 VINTAGE 02.01

## 0 TROUBLESHOOTING FROM THE MAP

0 Troubleshooting procedures can be invoked from the Line Test  
0 Position of the Maintenance and Administration Position (MAP).

0 The following tests are accessed from the MAP:

- 0 \* diagnostics (DIAG) from the LTP level
- 0 \* bit error rate test (BERT) from the LTPDATA level
- 0 \* loopback (LOOPBK) from the LTPDATA level
- 0 \* subscriber status (SUSTATE) from the LTPDATA level

0 The DIAG command performs an integrity test and a self-test on  
0 the data line card, and tests communication with the associated  
0 TIF or CUIF.

0 The BERT command transmits a bit pattern through the network to  
0 the two-wire data facility and the 3270 Network Switched Access  
0 equipment. The transmitted bit pattern is compared to the  
0 received bit pattern to determine the quantity of bit errors and  
0 synchronization slips.

0 The bit error rate test will not function when the data unit  
0 under test is communicating with another data unit.

0 The LOOPBK command interrupts a bit pattern at a specified loop-  
0 back point and returns the pattern to the source. The transmitted  
0 bit pattern is compared to the received bit pattern to determine  
0 the quantity of errors and synchronization slips between the  
0 source and the loopback point.

0 The SUSTATE command reports the status of the CUIF, the TIF, and  
0 the associated two-wire loop.

0 For details on how to initiate these tests and interpret the  
0 results, see NTP 297-2101-516, Lines Maintenance Reference Manu-  
0 al.

0  
0

297-2121-228  
VINTAGE 02.01

0

---

0 CHAPTER 7

0 ACRONYMS AND ABBREVIATIONS

0

---

0 297-2121-228  
0 VINTAGE 02.01

0  
0  
0 APL A Program Language  
0 BCS Batch Change Supplement  
0 BNC Bayonet 'N' Series Coax Connector  
0 CI Command Interpreter  
0 CCU Controller Coax Unit  
0 Coax coaxial  
0 Conn Connect  
0 CRC Cyclic Redundancy Check  
0 CSA Canadian Standards Association  
0 CUIF Control Unit Interface  
0 CUT Control Unit Terminals  
0 DFT Distributed Function Terminals  
0 DLC Data Line Card  
0 DMS Digital Multiplex System  
0 DN Directory Number  
0 DU Data Unit  
0 EMI Electro Magnetic Interference  
0 ESD Electro Static Discharge  
0 FCC Federal Communication Commission  
0 HDLC High-Level Data Link Control  
0 IBM International Business Machines  
0 KBD Keyboard Dialing  
0 LCC Line Class Code  
0 LED Light Emitting Diode  
0 LEN Line Equipment Number  
0 MAP Maintenance and Administration Position  
0 MTBF Mean Time Between Failure  
0 NSA Network Switched Access  
0 NTP Northern Telecom Practice  
0 PC Personal Computer  
0 RLS Release  
0 SNA Systems Network Architecture  
0 TCM Time Compression Multiplexing  
0 TCU Terminal Coax Unit  
0 TIF Terminal Interface  
0 UL Underwriters' Laboratories  
0 VLC Voice Line Card